
TABLE OF CONTENTS

SECTION		SUB-SECTION	
01	SUSPENSION	01 — Bogie wheel (refer to '78 Shop Manual 02 — Slide suspension 03 — Rear hub (refer to '78 Shop Manual) 04 — Drive axle 05 — Track (refer to '78 Shop Manual)	
02	TRANSMISSION	01 — Pulley guard 02 — Drive belt 03 — Drive pulley (refer to '78 Shop Manual) 04 — Driven pulley and countershaft 05 — Pulley alignment 06 — Brake 07 — Chaincase 08 — Gearbox (refer to '78 Shop Manual) 09 — Drive chain	
03	STEERING/SKI	01 - Steering system 02 - Ski system	
04	ENGINE	01 — Engine tolérances measurement 02 — Engines 03 — Rewind starter (refer to '78 Shop Manual) 04 — Timing 05 — Carburetor 06 — Air intake silencer and fuel tank	
05	ELECTRICAL	01 — Electrical charts 02 — Spark plugs 03 — Test procedure 04 — Electric starter (refer to '78 Shop Manual) 05 — Battery (refer to '78 Shop Manual) 06 — Alternator (refer to '78 Shop Manual)	
06	CAB & FRAME	01 — Cab 02 — Frame	
07	TOOLS		
08	TECHNICAL DATA		
09	WARRANTY		



BOGIE WHEELS

Refer to the 1978 Bombardier Shop Manual

1979 ELAN

1979

ALPINE 640 ER

refer to _____ 1978 ____ ELAN

refer to _____ 1978 ____ ALPINE





SLIDE SUSPENSION

Models covered in this section:


1979 BLIZZARD 5500 1979 GRAND PRIX SPECIAL 1979 BLIZZARD 9500

1979	ELAN	refer to 1978 ELAN
1979	SPIRIT	refer to 1978 SPIRIT
1979	OLYMPIQUE	refer to 1978 OLYMPIQUE
1979	NUVIK	refer to 1978 NUVIK
1979	CITATION	refer to 1978 CITATION
1979	MIRAGE	refer to 1978 MIRAGE
1979	EVEREST	refer to 1978 EVEREST
1979	FUTURA	refer to 1978 FUTURA
1979	BLIZZARD 7500 Plus / CROSS COUNTRY	refer to 1978 BLIZZARD 6500 Plus
1979	SUPER SONIC / CROSS COUNTRY	refer to 1978 BLIZZARD 6500 Plus
1979	ALPINE 640 ER	refer to 1978 ALPINE 640 ER
1979	ELITE 450 LC	refer to 1978 ELITE












DISASSEMBLY & ASSEMBLY

② ③ To replace a worn slider shoe, remove the rear spirol pin. Slide the shoe rearwards out of the runner.


(4) (5) (6) To remove the rivets securing the adjustment plate on the front arm supports, cut off the rivet heads using a cold chisel.

At assembly, position the rivet head on a suitable metal bloc and hold the assembly firmly in place. With a flat head punch and hammer secure the rivet in place.




To remove rivet use a 3/16" dia. drill. At assembly, secure reinforcement bracket to runner with two (2) 10-32 x 1/2" bolts and nuts.


4 10 10 The front idler shaft must be positioned in the front hole of the front arm bracket.



② At assembly, adjustment cam must be installed that hexagonal projection on cam is located toward front of vehicle.



(a) Sliding support must be installed with offset toward front.



(6) Clean all traces of plastic from threads. Prior to assembly, apply a light coat of "Loctite" thread locking compound or equivalent, on threads.

INSTALLATION


Detach front stopper strap and shock absorber of the suspension. Lift the rear of vehicle off the ground.

Place suspension within the track and align front arm of suspension with front holes of frame and secure using bolts and washers. Torque to 43 N•m (32 ft-lbs).

Raise the rear section of the suspension and track into the tunnel and align rear arm with rear holes in frame. Secure to frame using bolts and washers. Torque to 43 N•m (32 ft-lbs).

Reposition vehicle on the ground. Position the adjustment cams at the lowest elevation then apply downward pressure on the seat of vehicle and connect the shock absorber. Attach front stopper strap.






NOTE: There are many installation positions for the stopper strap. The recommended position provides maximum traction and steering efficiency for almost every snow condition. However, for very special purposes or snow condition, it may become necessary to alter this setting. Lengtening the strap (1st hole) has the same effect as shifting the weight toward rear of vehicle; as a result, traction is increased but steering efficiency is decreased. Inversely, by shortening the strap length (last hole), traction is decreased while steering efficiency and effort are increased.


ADJUSTMENT

Track tension

Lift rear of vehicle and support it off the ground, Allow track to extend normally. There must be a gap of 13 mm (1/2") between slider shoe and bottom inside of track, on each side.



To adjust tension, loosen or tighten adjuster bolts located on inner side of rear idler wheels.




NOTE: Track tension, track alignment and ride adjustment are interrelated adjustments. The measurement given for ride adjustment is initial. When ride adjustment is finalized for snow condition and driver suitability, it may be necessary to readjust track tension and alignment to specifications.

Track alignment

After track tension has been corrected start the engine and accelerate slightly so that track turns **slowly**. Check that track is well centered.

The distance between the edges of the track guides and the slider shoes should be equal on both sides.



WARNING: Before checking track alignment, ensure that the track is free of all particles which could be thrown out while track is rotating. Keep hands, feet, tools and clothing clear of track.

Ride adjustment

The front adjustment cams are used for snow condition, and the rear for driver's weight. The front adjustment cams should be positioned at the lowest elevation for deep snow conditions. A higher elevation is preferred when negociating icy snow.

The rear adjuster blocks should be adjusted until a distance of 1 4-16 cm (5 1/2" - 6 1/2") is obtained between rear of footboard and ground when the customer is seated on the vehicle.

CAUTION: Always turn left side adjustment cams in a clockwise direction, the right side cams in a counter-clockwise direction. Left and right adjustment cams of each adjustment (front and rear), must always be set at the same elevation.


SECTION 01 SUB-SECTION 03 (REAR AXLE)

Refer to the 1978 Bombardier Shop Manual

 1979
 ELAN
 refer to _____ 1978 ____ ELAN

 1979
 SPIRIT
 refer to _____ 1978 ____ SPIRIT

 1979
 ALPINE 640 ER
 refer to _____ 1978 ____ ALPINE 640 ER



DRIVE AXLE


Models covered in this section:

1979 BLIZZARD 5500 1979 GRAND PRIX SPECIAL 1979 BLIZZARD 9500

For all other models, refer to the 1978 Bombardier Shop Manual.

1979	ELAN	refer to	_ 1978	_ ELAN
1979	SPIRIT	refer to	_ 1978	_ SPIRIT
1979	OLYMPIQUE	refer to	_ 1978	_ OLYMPIQUE
1979	NUVIK	refer to	_ 1978	_ NUVIK
1979	CITATION	refer to	_ 1978	_ CITATION
1979	MIRAGE	refer to	1978	_ CITATION
1979	EVEREST	refer to	_ 1978	_ EVEREST
1979	FUTURA	refer to	_ 1978	_ FUTURA
1979	BLIZZARD 7500 Plus / CROSS COUNTRY	refer to	_ 1978	_ BLIZZARD 6500 Plus
1979	SUPER SONIC / CROSS COUNTRY	refer to	_ 1978	BLIZZARD 6500 Plus
1979	ALPINE 640 ER	refer to	_ 1978	_ ALPINE 640 ER
1979	ELITE 450 LC	refer to	1978	_ ELITE

(1979 SUPPLEMENT)



REMOVAL

Drain the oil from the chaincase.

Raise and block the rear of the vehicle off the ground.

Remove the suspension.

Remove the oil seals.

Remove the speedometer angle drive unit and coupling cable.

Release the drive sprocket teeth from the track notches, at the same time, pulling the drive axle towards the end bearing housing side of frame.

Remove the drive axle from the vehicle.


ASSEMBLY

6 When assembling drive axle, always position a new oil seal on each end of drive axle. The seal lip must face the sprocket.

(7) Always pull or push bearing by inner race.

The bearing on the splined side of axle must be installed as per given specifications. The bearing housing must be flush with end of drive axle. Each bearing must have its shield facing the sprocket.

(9) If the drive axle to be installed is a new component, and the vehicle is equipped with a speedometer, a correct size speedometer drive insert must be installed into the axle end. Ensure that the insert is flush with the end of axle.



0


DRIVE SPROCKET REPLACEMENT

Drive sprockets are of press fit design.


When reassembling, make sure to align the embossments of the sprockets.

The center to center distance of the drive sprockets must be as specified. Refer to illustration for proper installation.

GRAND PRIX SPECIAL BLIZZARD 5500



BLIZZARD 9500



INSTALLATION

Position the drive axle assembly with new oil seals into location.

Install the end bearing housing.

Reinstall the sprockets, chain, flat washers.


Install the tab locks as illustrated.

Install the screws and torque to 9.5 N•m (7 ft-lbs)

Bend the tab locks.



CAUTION: Lock tabs should be replaced if bent more than twice. If in doubt, replace.




Reinstall the chaincase cover.

Refill with chaincase oil.


Install the suspension. Apply track tension and carry out track alignment procedure.

(1979 SUPPLEMENT) (DRIVE AXLE) PAGE 5



TRACK

Refer to the 1978 Bombardier shop manual



PULLEY GUARD


Models covered in this section:

1979 BLIZZARD 5500 1979 GRAND PRIX SPECIAL 1979 BLIZZARD 9500

For all other models, refer to the 1978 Bombardier Shop Manual.

1979	ELAN	refer to 1978 ELAN	
1979	SPIRIT	refer to 1978 SPIRIT	
1979	OLYMPIQUE	refer to 1978 OLYMPIQUE	
1979	NUVIK	refer to 1978 NUVIK	
1979	CITATION	refer to 1978 CITATION	
1979	MIRAGE	refer to 1978 CITATION	
1979	EVEREST	refer to 1978 EVEREST	
1979	FUTURA	refer to 1978 FUTURA	
1979	BLIZZARD 7500 Plus / CROSS COUNTRY	refer to 1978 BLIZZARD 6500 Plus	S
1979	SUPER SONIC / CROSS COUNTRY	refer to 1978 BLIZZARD 6500 Plus	5
1979	ALPINE 640 ER	refer to 1978 ALPINE 640 ER	
1979	ELITE 450 LC	refer to 1978 ELITE	

(1979 SUPPLEMENT) (PULLEY GUARD) PAGE 1



REMOVAL

Remove the two hair pins and the retainer pins, then remove the belt guard.



WARNING: Never start the engine without the pulley guard secured in place and the cab closed.

INSPECTION

Check all parts for wear and tear. Replace as required.

(PULLEY GUARD) PAGE 2 (1979 SUPPLEMENT)

DRIVE BELT


REMOVAL & INSTALLATION

When removing a drive belt, always mark the rotation direction. Reinstall in the same direction.


Drive Belt Removal

WARNING: Never start or run engine without the drive belt installed. Running an unloaded engine is dangerous.


- 1. Tilt the cab and remove the belt guard.
- Open the driven pulley by twisting and pushing the sliding half. Hold in fully open position.



3. Slip the belt over the top edge of the sliding half.



 Slip the belt out from the drive pulley and remove completely from the vehicle. To install the drive belt, reverse the procedure.



TENSION ADJUSTMENT


For proper drive belt use, See Technical Data.

If a drive belt does not have the minimum recommended width, performance will be affected.

Adjust belt tension as follows:

"V" Belt tension tester method P / N 414 3482 00

- Slide lower "O" ring of deflection distance scale to 32 mm (1 1/4").
- Slide upper "O" ring to zero distance on the deflection force scale.
- Using wooden rule and tester, apply pressure until lower "O" ring is flush with edge of rule.
- Read deflection force on the upper scale (at top edge of "O" ring). Reading of 6.8 kg (15 pounds) should be obtained.



To correct, decrease or increase between pulleys.

TROUBLE SHOOTING

1. Uneven belt wear on one side only.



CAUSE

- a) Loose engine mount.
- b) Pulley misalignment.
- c) Rough or scratched pulley surfaces.

REMEDY

- a) Tighten engine mount nuts equally.
- b) Alian pulleys.
- Repair or replace pulley half.

2. Belt glazed excessively or having baked appearance.



CAUSE


Excessive slippage caused by:

- a) Insufficient pressure on belt sides.
- b) Rusted drive or driven pulley shafts.
- c) Oil on pulley surfaces.
- d) Incorrect centrifugal governor.

REMEDY

- Check drive pulley for worn or missing flyweights/ rollers
- b) Clean shaft with steel wool.
- c) Clean pulley surfaces with fine emery cloth and clean cloth.
- d) Install correct governor.

3. Belt worn excessively in top width.




CAUSE

- a) Excessive slippage due to irregular outward actuation movement of drive pulley.
- b) Rough or scratched pulley surfaces.
- c) Improper belt angle.
- d) Considerable use.

REMEDY

- a) Carry out inspection.
- b) Repair or replace pulley.
- c) Using unspecified type of belt.
 Replace belt with correct Bombardier belt.
- d) Replace belt if 3 mm (1/8") less than recommended width (see Technical Data).

4. Belt worn narrow in one section.



CAUSE

Excessive slippage in drive pulley caused by:

- a) Frozen or too tight track.
- b) Drive pulley not functioning properly.
- c) Engine idle speed too high.
- d) Incorrect belt length.
- el Incorrect pulley distance.

REMEDY


- a) Liberate track from ice or check track tension and alignment.
- b) Repair or replace drive pulley.
- c) Reduce engine RPM.
- d) Using unspecified type of belt. Replace belt with correct Bombardier belt.
- e) Readjust to specifications.

SECTION 02 SUB-SECTION 02 (DRIVE BELT)

5. Belt sides worn convave.			
Original angle	cause a) Rough or scratched pulley surfaces. b) Unspecified type of belt.	REMEDY a) Repair or replace. b) Replace belt with correct Bombardier belt.	
6. Belt desintegration.			
	a) Excessive belt speed. b) Oil on pulley surfaces. c) Incorrect gear ratio.	a) Using unspecified type of belt. Replace belt with proper type of belt. b) Clean pulley surfaces with fine emery cloth. c) Install specified sprocket (correct gear ratio).	
7. Belt edge cord breakage.	CAUSE	REMEDY	
	a) Pulley misalignment.	a) Align pulleys.	
8. Flex cracks between cogs.	4		
	CAUSE a) Considerable use, belt wearing out.	REMEDY a) Replace belt.	
9. Sheared cogs, compression section fractu	re or torn.		
	a) Improper belt installation, b) Belt rubbing stationary object on pulleys, c) Violent engagement of drive pulley.	REMEDY a) Refer to Installation section b) Check drive components. c) Replace spring or duralon bushing	

(1979 SUPPLEMENT) (DRIVE BELT) PAGE 3

SECTION 02 SUB-SECTION 02 (DRIVE BELT)



(DRIVE BELT) PAGE 4 (1979 SUPPLEMENT)

DRIVE PULLEY

Refer to the 1978 Bombardier Shop Manual

1979	ELAN	refer to 1978 _	ELAN
1979	SPIRIT	refer to 1978 _	SPIRIT
1979	OLYMPIQUE	refer to 1978 _	OLYMPIQUE
1979	NUVIK	refer to 1978 _	NUVIK
1979	CITATION	refer to 1978 _	CITATION
1979	MIRAGE	refer to 1978 _	CITATION
1979	EVEREST	refer to 1978 _	EVEREST
1979	FUTURA	refer to 1978 _	FUTURA
1979	BLIZZARD 5500	refer to 1978 _	BLIZZARD 6500 Plus
1979	GRAND PRIX Special	refer to 1978 _	BLIZZARD 6500 Plus
1979	BLIZZARD 7500 Plus / CROSS COUNTRY	refer to 1978 _	BLIZZARD 6500 Plus
1979	SUPER SONIC / CROSS COUNTRY	refer to 1978 _	BLIZZARD 6500 Plus
1979	BLIZZARD 9500 Plus	refer to 1978 _	BLIZZARD 6500 Plus
1979	ALPINE 640 ER	refer to 1978 _	
1979	ELITE 450 LC	refer to 1978 _	


DRIVEN PULLEY

Models covered in this section:

1979 BLIZZARD 5500 1979 GRAND PRIX SPECIAL 1979 BLIZZARD 9500


For all other models, refer to the 1978 Bombardier Shop Manual.

1979	ELAN	refer to 1978 ELAN
1979	SPIRIT	refer to 1978 SPIRIT
1979	OLYMPIQUE	refer to 1978 OLYMPIQUE
1979	NUVIK	refer to1978 NUVIK
1979	CITATION	refer to 1978 CITATION
1979	MIRAGE	refer to 1978 CITATION
1979	EVEREST	refer to 1978 EVEREST
1979	FUTURA	refer to 1978 FUTURA
1979	BLIZZARD 7500 Plus / CROSS COUNTRY	refer to 1978 BLIZZARD 6500 Plus
1979	SUPER SONIC / CROSS COUNTRY	refer to 1978 BLIZZARD 6500 Plus
1979	ALPINE 640 ER	refer to 1978 ALPINE 640 ER
1979	ELITE 450 LC	refer to 1978 ELITE



REMOVAL

- Loosen upper footrest bolt and remove lower one.
- Pull out the side of the bottom plate. Remove pulley assembly.



CAUTION: Always apply anti-seize compound on the countershaft before final pulley installation (Loctite anti-seize lubricant P/N 413 7010 00).

DISASSEMBLY & ASSEMBLY


DRIVEN PULLEY BUSHING REPLACEMENT

To replace the outer and inner bushings of the floating type driven pulley, proceed as follows:

Remove and disassemble driven pulley assembly.

Outer bushing:

Remove the three (3) screws on sliding half.
Remove the bushing with a pin punch, as illustrated




Clean the bushing seat with Bombardier Stripper No 57. Coat the seat with Loctite No 271 (high strength) red. Install the new bushing (gently tap in place).

Reinstall screws, using Loctite 242 (medium strength) blue.

Reassemble pulley.


Inner bushing:

Remove the bushing with a pin punch, as illustrated.




SECTION 02 SUB-SECTION 04 (DRIVEN PULLEY)

Round out punch marks to permit new bushing to fit in.




Clean the seat with Bombardier Stripper No 57. Coat the seat with Loctite No 271 (high strength) red. Install a new bushing (gently tap in place).

Secure bushing in place by punching the bushing shoulder rib (as illustrated).



Reassemble pulley.

In order to measure driven pulley spring tension, the pulley halves must be separated. To do this, insert a length of 1/8" dia. rod between the halves. Check tension using a fish scale positioned 90° with pulley axle. (Refer to Technical Data for correct spring tension).



To correct spring tension either relocate spring end in sliding pulley half, or gradually rotate outer cam.

INSTALLATION


Reinstall pulley, outer shims, lockwasher and bolt. Torque to 9 N•m (7 ft-lbs).

IMPORTANT: Maximum free-play should not exceed 3 mm (1/8").

CAUTION: Always apply anti-seize (Loctite antiseize lubricant P/N 413 7010 00) compound on countershaft before final pulley installation.

(DRIVEN PULLEY) PAGE 4 (1979 SUPPLEMENT)

COUNTERSHAFT



REMOVAL

Remove the suspension, brake caliper ass'y, air intake silencer, belt guard and drive belt.

Remove the shaft protector plate.

Remove the chaincase ass'y (chaincase cover, sprockets, chain, drive axle seal, chaincase).


Remove the driven pulley ass'y and all shims.

Unlock the countershaft bearing (loosen the Allen screw then turn counter-clockwise). Disassemble the bearing and the bearing flange and remove.


Remove the countershaft and the brake disc ass'y.

INSTALLATION

- Reinstall the countershaft and the flange bearing ass'y. (Do not fully tighten the bearing flange until the alignment of the countershaft is completed).
- Reinstall the chaincase, oil seal, sprockets, drive chain, tab locks. Torque sprocket retaining bolts to 9 N•m (7 ft-lbs). Bend tab locks.
- To align the countershaft use a 6" (approx) plastic square. (Cut out a 1" x 2" section as illustrated.




Apply the square on the countershaft and on the side of the frame. The square must be horizontal.



Adjust the countershaft so that it is perpendicular to the frame. (Use a plastic hammer to adjust, to not tap on the keyway).

When the shaft is well adjusted, tighten all nuts.

Tighten bearing collar against bearing seat until well seated, then lock in place by tightening the Allen set screw. (Loctite 242 blue medium strength).



Lubricate the countershaft with antiseize lubricant.

Install the pulley ass'y and shims, chaincase cover, chaincase oil.

Reinstall the countershaft protector plate.

Install the air intake silencer and the brake caliper ass'y. Check the pulley alignment.

Install the drive belt.

CAUTION: When adjusting the pulley alignment, never tamper or modify the countershaft adjustment. Use the engine support bolts to obtain correct pulley distance.

Install the belt guard.

Install the suspension.

Check the track tension and alignment.

PULLEY ALIGNMENT

Models covered in this section:


1979 BLIZZARD 5500 1979 GRAND PRIX SPECIAL 1979 BLIZZARD 9500


For all other models, refer to the 1978 Bombardier Shop Manual.

1979	ELAN	refer to 1978 ELAN
1979	SPIRIT	refer to 1978 SPIRIT
1979	OLYMPIQUE	refer to 1978 OLYMPIQUE
1979	NUVIK	refer to 1978 NUVIK
1979	CITATION	refer to 1978 CITATION
1979	MIRAGE	refer to 1978 CITATION
1979	EVEREST	refer to 1978 EVEREST
1979	FUTURA	refer to 1978 FUTURA
1979	BLIZZARD 7500 Plus / CROSS COUNTRY	refer to 1978 BLIZZARD 6500 Plus
1979	SUPER SONIC / CROSS COUNTRY	refer to 1978 BLIZZARD 6500 Plus
1979	ALPINE 640 ER	refer to 1978 ALPINE 640 ER
1979	ELITE 450 LC	refer to 1978 ELITE

PULLEY ALIGNMENT PROCEDURE

With 1/16" shim in place, push assembly in against bearing plate





OFFSET

- dimension x & y (offset) 34 mm (1 11/32")

Floating type driven pulley requires a special procedure to correctly measure offset.

- Install a 1/16" gauge between pulley and bearing plate.
- Then measure offset (usual method).

IMPORTANT: Make sure driven pulley assembly is fully seated against bearing flange when measuring offset.

- Adjust the offset by adding or removing shims.
- NOTE: To add or remove shims, pulley assembly must be removed as per driven pulley removal procedure.
- When alignment is completed, remove 1/16" gauge.


If pulley was removed:

Reinstall the pulley, outer shims, lockwasher and bolt. Torque to 9 N•m (7 ft-lbs).

IMPORTANT: Maximum free-play should not exceed 3 mm (1/8").

CAUTION: Always apply anti-seize compound (Loctite anti-seize lubricant P/N 413 7010 00) on the countershaft before final assembly.

NOMINAL DISTANCE




- Dimension "X" must never exceed dimension "Y".
- Dimension "Y" can exceed dimension "X" by 1.6 mm (1/16").


To obtain maximum vehicle performance, adjust pulley distance as follows:

- 1. Adjust pulley distance to nominal distance.
- 2. Prior to final adjustment, the drive belt must have a break-in period time of one to two minutes.
- The final adjustment of pulley distance should be performed by using the belt deflection method that follows:

V-Belt tension tester (part no. 414 3482 00).


- 1. Slide lower "O" ring of deflection distance scale to 32 mm (1 1/4").
- Slide upper "O" ring to zero distance on the deflection force scale.
- 3. Using wooden rule and tester, apply pressure until lower "O" ring is flush with edge of rule.
- Read deflection force on the upper scale (at top edge of "O" ring). Reading of 6.8 kg (15 lbs) should be obtained.






To correct, decrease or increase distance between pulleys by moving engine bracket as required.

IMPORTANT: If engine bracket was moved, offset alignment should be rechecked.





BRAKE


Models covered in this section:

1979 BLIZZARD 5500 1979 GRAND PRIX SPECIAL 1979 BLIZZARD 9500

For all other models, refer to the 1978 Bombardier Shop Manual.

1979	ELAN	refer to 1978 ELAN
1979	SPIRIT	refer to 1978 SPIRIT
1979	OLYMPIQUE	refer to 1978 OLYMPIQUE
1979	NUVIK	refer to 1978 NUVIK
1979	CITATION	refer to 1978 CITATION
1979	MIRAGE	refer to 1978 CITATION
1979	EVEREST	refer to 1978 EVEREST
1979	FUTURA	refer to 1978 FUTURA
1979	BLIZZARD 7500 Plus / CROSS COUNTRY	refer to 1978 BLIZZARD 6500 Plus
1979	SUPER SONIC / CROSS COUNTRY	refer to 1978 BLIZZARD 6500 Plus
1979	ALPINE 640 ER	refer to 1978 ALPINE 640 ER
1979	ELITE 450 LC	refer to 1978 ELITE

BOMBARDIER SELF-ADJUSTING TYPE



REMOVAL


Disconnect brake switch and brake cable.

Remove nuts and/or bolts securing brake support to chaincase.

Slide brake caliper ass'y from brake support.

DISASSEMBLY & ASSEMBLY

10 12 To ease hair pin assembly, activate lever and wedge two (2) screwdriver blades between caliper and brake pad to release lever tension.



(5) Apply low temperature grease on threads and spring seat prior to installation. At assembly, fully tighten then back off 1/2 turn.

1) At assembly, torque to 20 Nom (15 ft-lbs).

CLEANING AND INSPECTION


Measure thickness of brake pad. If less than 3 mm (1/8''), the pad should be replaced


Clean all metal components in a general purpose solvent. Dry using clean cloth.

INSTALLATION & ADJUSTMENT

Slide caliper ass'y onto its support then secure support to vehicle.


- Activate lever by hand until ratchet klick is no longer heard.
- Secure brake cable housing to lever, slide spring over cable then attach cable to housing with adjuster nut.
- Using adjuster nut, adjust until there is no free-play between the brake lever and its housing, and there is a gap of 50 mm ⁺/₋ 3 (2" ⁺/₋ 1/8") between lever and caliper.






NOTE: It may be necessary to change brake light switch support position to obtain recommended gap between lever and caliper housing.

Connect brake light switch and check operation. Adjust if necessary using two (2) adjuster nuts.



COUNTERSHAFT AND BRAKE DISC



COUNTERSHAFT REMOVAL PROCEDURE:

Procedure:

Remove the suspension, brake caliper ass'y, air intake silencer, belt guard and drive belt.


Remove the shaft protector plate.

Remove the chaincase ass'y (chaincase cover, sprockets, chain, drive axle seal, chaincase).

Remove the driven pulley ass'y and all shims.


Unlock the countershaft bearing (loosen the Allen screw then turn counter-clockwise). Disassemble the bearing and the bearing flange and remove.

Remove the countershaft and the brake disc ass'y.



BRAKE DISC REPLACEMENT PROCEDURE:

To remove the disc, shear off the rivets (from disc side) using a cold chisel.





CAUTION: To prevent damage to the hub ass'y always shear off the rivets on the disc side.

- Punch out the rivets with a pin punch.




CAUTION: To prevent enlarging the holes do not drill out the rivets.

Reassemble the new disc using 6 screws P/N 345 7063 00) and elastic stop nuts (P/N 398 2113 00).



CAUTION: The disc must be installed with the sharp edges facing outward from the hub.



Tighten and torque the nuts to 3.2 N•m (28 inch-lbs), in a criss-cross pattern.


IMPORTANT: Do not overtighten.

NOTE: Brake hubs and countershafts are not available as separate units.


IMPORTANT: Whenever servicing the disc brake ass'y always check components for excessive wear or looseness.

INSTALLATION

- Reinstall the countershaft and the flange bearing ass'y. (Do not fully tighten the bearing flange until the alignment of the countershaft is completed).
- Reinstall the chaincase, oil seal, sprockets, drive chain, tab locks. Torque sprocket retaining bolts to 9 N•m (7 ft-lbs). Bend tab locks.
- To align the countershaft use a 6" (approx) plastic square. (Cut out a 1" x 2" section as illustrated.




Apply the square on the countershaft and on the side of the frame. The square must be horizontal.



Adjust the countershaft so that it is perpendicular to the frame. (Use a plastic hammer to adjust, do not tap on the keyway).

When the shaft is well adjusted, tighten all nuts.

Tighten bearing collar against bearing seat until well seated, then lock in place by tightening the Allen set screw. (Loctite 242 blue medium strength).



Lubricate the countershaft with antiseize lubricant...

Install the pulley ass'y and shims, chaincase cover, chaincase oil.

Reinstall the countershaft protector plate.

Install the air intake silencer and the brake caliper ass'y. Check the pulley alignment.


Install the drive belt.

CAUTION: When adjusting the pulley alignment, never tamper or modify the countershaft adjustment. Use the engine support bolts to obtain correct pulley distance.

Install the belt guard.

Install the suspension.

Check the track tension and alignment.



CHAINCASE

Models covered in this section:


1979 BLIZZARD 5500 1979 GRAND PRIX SPECIAL 1979 BLIZZARD 9500

For all other models, refer to the 1978 Bombardier Shop Manual.

1979	ELAN	refer to 1978 ELAN
1979	SPIRIT	refer to 1978 SPIRIT
1979	OLYMPIQUE	refer to 1978 OLYMPIQUE
1979	NUVIK	refer to 1978 NUVIK
1979	CITATION	refer to 1978 CITATION
1979	MIRAGE	refer to 1978 CITATION
1979	EVEREST	refer to 1978 EVEREST
1979	FUTURA	refer to 1978 FUTURA
1979	BLIZZARD 7500 Plus / CROSS COUNTRY	refer to 1978 BLIZZARD 6500 Plus
1979	SUPER SONIC / CROSS COUNTRY	refer to 1978 BLIZZARD 6500 Plus
1979	ALPINE 640 ER	refer to 1978 ALPINE 640 ER
1979	ELITE 450 LC	refer to 1978 ELITE

(1979 SUPPLEMENT) (CHAINCASE) PAGE 1

CHAINCASE



(CHAINCASE) PAGE 2 (1979 SUPPLEMENT)

REMOVAL

Remove the suspension.

NOTE: On the Blizzard 9500, disconnect the muffler and push it aside underneath the exhaust pipes.

Remove the chaincase cover and drain the oil.

Slacken the end bearing housing.

Pry out the drive axle oil seal from the chaincase.

Release chain tension then open the tab locks locking the sprockets. Remove the screws, washers, sprockets and chain.

Remove bolts and/or nuts securing the chaincase to the frame.

INSPECTION

Visually inspect the chain for cracked, damaged or missing link rollers. Inspect for defective bearing, sprockets.

DISASSEMBLY & ASSEMBLY

Remove the oil seal, snap ring and bearing from the chaincase.


Using an appropriate pusher, press the oil seal into chaincase hub. Oil seal must fit flush with the case hub edge.

INSTALLATION

Install the chaincase to the frame (do not tighten). Position the drive axle into location. Tighten the end bearing housing. Prior to lower sprocket installation ensure that the spacer is on the drive axle.

Reinstall the sprockets, chain, flat washers.

Position the sprockets with the longer flanges facing inside the chaincase. (For proper sprocket and chain use, see Technical Data).




Install the tab locks as illustrated.

Install the screws and torque to 9.5 N•m (7 ft-lbs). Bend the tab locks.


V

CAUTION: Lock tabs should be replaced if bent more than twice. If in doubt, replace.



Reinstall the chaincase cover.


Refill with chaincase oil.



GEARBOX


Refer to the 1978 Bombardier Shop Manual

1979 ALPINE 640 ER ______ 1978 ALPINE 640 ER 1979 ELITE 450 LC _____ 1978 ELITE



DRIVE CHAIN

Refer to the 1978 Bombardier Shop Manual




STEERING SYSTEM

Models covered in this section:

1979 BLIZZARD 5500 1979 GRAND PRIX SPECIAL 1979 BLIZZARD 9500

For all other models, refer to the 1978 Bombardier Shop Manual.

1979	ELAN	refer to	1978	ELAN
1979	SPIRIT	refer to	1978	SPIRIT
1979	OLYMPIQUE	refer to	1978	OLYMPIQUE
1979	NUVIK	refer to	1978	NUVIK
1979	CITATION	refer to	1978	CITATION
1979	MIRAGE	refer to	1978	CITATION
1979	EVEREST	refer to	1978	EVEREST
1979	FUTURA	refer to	1978	FUTURA
1979	BLIZZARD 7500 Plus CROSS COUNTRY	refer to	1978	BLIZZARD 6500 Plus
1979	SUPER SONIC / CROSS COUNTRY	refer to	1978	BLIZZARD 6500 Plus
1979	ALPINE 640 ER	refer to	1978	ALPINE 640 ER
1979	ELITE 450 LC	refer to	1978	ELITE



- 1. Handle Bar
- 2. Throttle Handle Housing
- 3. Kill Switch
- 4. Throttle Handle
- 5. Pin
- 6. Retainer (Cable Barrel)
- 7. Brake Handle Housing
- 8. Dimmer Switch
- 9. Brake Handle
- 10. Pin
- 11. Push Nut
- 12. Grip (2)
- 13. Steering Padding
- 14. Clip (2)
- 15. Rivet (2)
- 16. Cable Protector
- 17. Tie Rap (2)
- 18. Lower Bushing (2)
- 19. Upper Bushing (2)
- 20. Retainer Bracket with Screw
- 21. Washer (2)
- 22. Tab Lock
- 23. Nut (2)

- 24. Retainer Bracket
- 25. Washer (2)
- 26. Nut (2)
- 27. Ball Joint L.H. (2)
- 28. Jam Nut L.H. (2)
- 29. Tab Lock (4)
- 30. Nut (4)
- 31. Tie Rod
- 32. Jam Nut R.H. (2)
- 33. Ball Joint R.H. (2)
- 34. Steering Arm
- 35. Tie Rod
- 36. Steering Arm
- 37. Ski Leg (2)
- 38. Ski Leg (Blizzard 9500) (2)
- 39. Washer (2)
- 40. Bushing (2)
- 41. Bushing (2)
- 42. Shim (2)
- 43. Screw (2)
- 44. Washer (4)
- 45. Nut (2)
- 46. Grease Fitting (2)

INSPECTION

Check skis and runner shoes for excessive wear, replace if necessary. (See section 03-02).

Make sure steering arm and ski leg splines interlock.

Check general condition of steering system.

Check general condition of steering system components for wear and replace if necessary.

DISASSEMBLY & ASSEMBLY


@Grips can be removed and installed without any damage by injecting compressed air into the handlebar.

Another way to install grips consists in soaking them in soapy water (detergent for dishes) and in pushing them onto the handlebar with a soft hammer.

(2) Inspect ball joint ends for wear or looseness, if excessive, replace.


NOTE: Screw the longest threaded end of ball joint into the tie rod, ensure that half of the total number of threads are inserted into the tie rod.

The cut-off section of the tie rod end must run parallel with the horizontal line of the steering arm when assembled on vehicle. The tie rod end should be restrained when tightening tie rod end lock nut. For torque specifications see Technical Data.



- (a) When assembling components, always position new tab locks.
- (2) 36 The steering arm angles should be equal on both sides when skis are parallel with vehicle.
- 2930 Tighten to 27 N•m (20 ft-lbs) and bend locking tabs over nuts.
- 38 Grease ski leg at grease fitting 46.
- 45 Torque to 42 Nom (31 ft-lbs).

STEERING ADJUSTMENT (SKIS) Type 5



Skis should have a toe out of 3 mm (1/8"). To check, measure distance between each ski at front and rear of spring leaves. The front distance should be 3 mm (1/8") more than the rear when the handlebar is horizontal. If adjustment is required:

Loosen the jam nuts locking the longer tie rod in place. Turn tie rod manually until alignment is correct. Tighten jam nuts firmly.

IMPORTANT: Close front of skis manually to take all slack from steering mechanism.

Check that handlebar is horizontal. To correct, loosen shorter tie rod jam nuts.

Turn tie rod manually until handlebar is horizontal.

Tighten jam nuts firmly.

(1979 SUPPLEMENT)


SKI SYSTEM

Models covered in this section:

1979 BLIZZARD 9500

For all other models, refer to the 1978 Bombardier Shop Manual.

1979	ELAN	refer to	1978	ELAN
1979	SPIRIT	refer to	1978	SPIRIT
1979	OLYMPIQUE	refer to	1978	OLYMPIQUE
1979	NUVIK	refer to	1978	NUVIK
1979	CITATION	refer to	1978	CITATION
1979	MIRAGE	refer to	1978	CITATION
1979	EVEREST	refer to	1978	EVEREST
1979	FUTURA	refer to	1978	FUTURA
1979	BLIZZARD 5500 /	refer to	1978	BLIZZARD 6500 Plus
	GRAND PRIX Special			
1979	BLIZZARD 7500 Plus CROSS COUNTRY	refer to	1978	BLIZZARD 6500 Plus
1979	SUPER SONIC / CROSS COUNTRY		1978	BLIZZARD 6500 Plus
1979	ALPINE 640 ER	refer to	1978	ALPINE 640 ER
1979	ELITE 450 LC	refer to	1978	ELITE



INSPECTION

Check the skis and runner shoes for excessive wear, replace if necessary.

Make sure the steering arm and the ski leg splines interlock.

Check the general condition of the steering components for wear and replace if necessary.

DISASSEMBLY AND ASSEMBLY

WARNING: Be careful when removing the steel runner shoes from the ski slots, as the shoes are under tension. Check that the ski runner shoes are not worn more then half their original thicknesss.

INSTALLATION


6 6 18 Install the rubber bushings 6 on the bushing weldment and on the leaf spring (use liquid soap).

Install the ski ass'y on the ski leg.

CAUTION: Make sure the bushing weldment ⁽¹⁸⁾ is properly installed as illustrated. The longest portion of the bushing must be facing the ski leg.

22 29 23 Install the two flat washers and coupler bolt, making sure the nut is secured from inside the ski leg. Torque to 68 N•m (50 ft-lbs).

(9) Bend lock tabs.



Secure shock absorber to ski leg bracket using retainer and cotter pins.

Set ski adjustment to obtain a toe-out of 3 mm (1/8").

(1979 SUPPLEMENT)




ENGINE TOLERANCES MEASUREMENT

CYLINDER TAPER

Maximum: 0.08 mm (.003")

Compare cylinder diameter 16 mm (5/8") from top of cylinder with down to just below the intake port.


On rotary valve engines, measure just below auxiliary transfer port, facing exhaust port. If the difference exceeds 0.08 mm (.003") the cylinder should be rebored and honed or should be replaced



CYLINDER OUT OF ROUND

Maximum: 0.05 mm (.002")

Measuring 16 mm (5/8") from top of cylinder with a cylinder gauge, check if the cylinder out of round is more than 0.05 mm (.002"). If larger, cylinder should be rebored and honed or should be replaced.




PISTON TO WALL CLEARANCE

ENGINE TYPE	PISTON TO WALL CLEARANCE MINIMUM — MAXIMUM
247	0.065 — 0.170 mm (.0026 — .0067'')
248	0.050 — 0.140 mm (.0020 — .0055'')
294	0.050 - 0.140 mm (.00200055'')
343	0.080 — 0.200 mm (.0031 — .0079'')
354	0.080 — 0.200 mm (.0031 — .0079")
402	0.070 - 0.180 mm (.00280071'')
440	0.070 - 0.180 mm (.00280071)
444	0.070 = 0.180 mm (.0028 = .0071")
454	0.090 — 0.220 mm (.0035 — .0087'')
503	0.060 = 0.160 mm (.0024 = .0063")
640	0.070 — 0.180 mm (.0028 — .0071′′)

SECTION 04 SUB-SECTION 01 (ENGINE TOLERANCES MEASUREMENT)

Accurate measurement


To determine piston to wall clearance, the piston should be measured 8 mm (5/16") above its bottom edge and the cylinder should be measured 16 mm (5/8") below its top edge.



The difference between these two measurements should be within specified tolerance.

Quick measurement

Place cylinder upside down on a work-bench and press a feeler gauge against the cylinder wall (intake side) while trying to insert the piston without any ring in its usual position.



The thickest possible to use feeler gauge will determine the piston to wall clearance...


RING END GAP

ENGINE TYPE	RING END GAP
248, 294, 343	0.15 — 0.35 mm
354	(.006 — .014")
247, 402, 440	0.20 - 0.40 mm
444, 454, 503	(.008"016")
640	0.25 - 0.45 mm (.010018")

Position ring half way between transfer ports and intake port. On rotary valve engines, position ring just below transfer ports.

NOTE: In order to correctly position the ring in the cylinder, use piston as a pusher.


Using a feeler gauge, check ring end gap. If gap exceeds specified tolerance the ring should be replaced.



PISTON RING/GROOVE CLEARANCE

Maximum: 0.20 mm (.008")


Using a feeler gauge check clearance between rectangular ring and groove. If clearance exceeds 0.20 mm (.008"), replace piston.




CRANKSHAFT DEFLECTION

Maximum: 0.06 mm (.0024")

With the crankshaft positioned between a center lathe, install a dial indicator as close as possible to crankshaft blade then measure deflection on each side. If deflection exceeds 0.06 mm (.0024") the crankshaft should be repaired by a specialized shop or it should be replaced.






CONNECTING ROD BIG END AXIAL PLAY

Maximum: 0.5 mm (.020")


Using a feeler gauge measure distance between connecting rod and thrust washer. If axial play exceeds 0.5 mm (.020"), the crankshaft should be replaced.




CONNECTING ROD ALIGNMENT

Check if connecting rod is bent as follows:

- Once engine crankcase is assembled with the piston mounted on connecting rod without its piston rings, position cylinder on piston.
- NOTE: The cylinder/crankcase gasket must not be installed.
- Rotate crankshaft slowly and at the same time observe piston movement within the cylinder. If piston bears against one side (PTO or mag. side), the connecting rod is bent.



 To correct, position needle bearing and gudgeon pin on connecting rod then pry connecting rod as illustrated.



SECTION 04 SUB-SECTION 01 (ENGINE TOLERANCES MEASUREMENT)

CRANKSHAFT END-PLAY


Maximum: 0.10 mm (.004")

NOTE: Crankshaft end-play is adjusted only when crankshaft and/or crankcase is replace.


One cylinder engine (247)


Maximum crankshaft end-play should be 0.10 mm (.004"). To determine necessary correction:

a) Measure crankcase. To do this first measure each half from mating surface to bottom of bearing seat. Add measurements of both halves then add 0.15 mm (.006") for gasket displacement. Equals A.



b) Measure thickness of each ball bearing. Measure distance between crankshaft blades. Add measurements. Total equals B.





c) Subtract measurement B from measurement A minus tolerance of 0.10 mm (.004") maximum. Total balance is distance to be shimmed. Shim(s) must be located between magneto side bearing and crankshaft blade.

Two cylinder engines (248, 294, 343, 402, 440, 640)

ENGINE TYPE	BEARING SIMULATOR NO.	AVAILABLE SHIMS
248, 294	420 876 380	0.1 mm (.004"), 0.2 mm (.008"), 0.3 mm (.012"), 0.5 mm (.020"), 1 mm (.040")
343, 402, 440	420 876 155	0.15 mm (.006"), 0.2 mm (.008"), 0.3 mm (.012")
640	420 876 160	0.15 mm (.006''), 0.2 mm (.008''), 0.3 mm (.012'')


Crankshaft end-play (0.1 mm (.004") maximum) is adjusted with shim(s) located between crankshaft and magneto side bearing. To determine correct amount of shims, proceed as follows.

Remove magneto side bearing(s) and existing shim(s). Slide the appropriate bearing simulator and retaining washers onto the crankshaft.


SECTION 04 SUB-SECTION 01 (ENGINE TOLERANCES MEASUREMENT)

Position crankshaft assembly into crankcase lower half, making sure that retaining washers are correctly seated into the grooves.

Gently tap crankshaft mag. side blade until P.T.O. side bearing bears against retaining washer



Any free-play between the bearing simulator and magneto side retaining washer, minus 0.1 mm (.004") maximum end-play is the distance to be covered by shim(s). Shims are available in variable thickness according to engine type.





ENGINES

These sub-section apply to the following engine types:

294 Citation et Mirage

354-454 Blizzard 7500 Plus et Super Sonic (354)


Blizzard 9500 Plus (454)

444 Everest et Futura 444 L/C


Elite 450 L/C

503 Blizzard 5500 et Grand Prix Special

For all other engine types, refer to 1978 Bombardier Shop Manual.




294 ENGINE TYPE




From serial no 2 746 622 and up, crankshaft is different and there is a distance ring (P/N 420 827 720) on P.T.O. side between inner bearing and crankshaft blade.

For any other information on 294 engine type, refer to 1978 Bombardier Shop Manual.




354, 454 ENGINE TYPES



ENGINE SUPPORT & MUFFLER

Blizzard & Super Sonic Cross Country



- 1. Carriage bolt
- 2. Flat washer
- 3. Cup washer
- 4. Threaded spacer bushing
- 5. Vibration absorber
- 6. Engine support
- 7. Nut
- 8. Distance sleeve
- 9. Washer
- 10. Lockwasher
- 11. Nut
- 12. Gasket
- 13. Exhaust socket or manifold
- 14. Lockwasher
- 15. Allen bolt
- 18. Spring
- 19. Rubber shear mount
- 20. Washer
- 21. Nut
- 22. Insulating washer
- 23. Tuned pipe support (magneto side)
- 30. Support
- 31. Spring
- 32. Reinforcement plate
- 33. Bolt
- 34. Washer
- 35. Nut
- 36. Muffler spacer
- 37. Muffler

ENGINE SUPPORT & MUFFLER Blizzard 9500 Plus 1. Carriage bolt 2. Flat washer 5. Vibration absorber 6. Engine support 7. Nut 17 8. Distance sleeve 9. Washer 10. Lockwasher 24 30 17. Nut 16 12. Gasket 13. Exhaust socket or manifold 14. Lockwasher 15. Allen bolt 16. Tuned pipe (P.T.O, side) 17. Tuned pipe (magneto side) 46 18. Spring 19. Rubber shear mount 47 20. Washer 21. Nut 24. Spring 25. Coupler 26. Tail pipe (P.T.O. side) 27. Tail pipe (magneto side) 28. Spring 29. Swirl chamber 30. Support 10-0 _49 31. Spring 33. Bolt D-20 34. Washer ⊕-21 38. Lockwasher 39. Spring 40. Spring seat 41. Seal ring 42. Spacer 43. Reinforcing cross support 44. Retainer plate 45. Internal tooth dished washer 46. Bushing 47. Rubber bushing 48. Threaded bushing 49. Spacer

ENGINE SUPPORT & MUFFLER

REMOVAL FROM VEHICLE

Disconnect or remove the followings from vehicle:

- Pulley guard and drive belt
- Air silencer and throttle cable
- Fuel lines, primer and pulsation lines
- Muffler and rewind starter
- Electric wires
- Drain the cooling system and disconnect hoses at engine
- Rotary valve oil reservoir
- Disconnect rewind starter at engine

DISASSEMBLY & ASSEMBLY

- n Torque to 35 Nem (26 ft-lbs).
- (15) Torque to 22 Nom (16 ft-lbs).

INSTALLATION ON VEHICLE


To install engine on vehicle, reverse removal procedure. However, pay attention to the followings:

- · Check tightness of engine mount nuts.
- After throttle cable installation, check carburetor maximum throttle slide opening.
- · Check pulley alignment.



COOLING SYSTEM

Blizzard 7500. Super Sonic & Cross Country



- T. Fitting
- 2. By-pass hose (560 mm)
- 3. Hose clamp
- 4. Tank
- 5. Bolt
- 6. Nut
- 7. Plug
- 8. Wire
- 9. Terminal

- 10. Pop rivet 11. Hair pin
- 12. Overflow tube (380 mm)
- 13. Radiator
- 14. Radiator protector
- 15. Screw
- 16. Pop rivet
- 17. Hose (130 mm)
- 18. Hose (660 mm)

- 19. "U" hose
- 20. Hose (660 mm)
- 21. Hose clamp 22. Coolant outlet collar
- 23. Thermostat 24. Sealing ring
- 25. Temperature gauge sender

COOLING SYSTEM Blizzard 9500 Plus 28 6-0 19 18 14 1-15 4. Tank 20. Hose (560 mm) 6. Nut 21. Hose clamp 7. Plug 22. Coolant outlet collar 12. Overflow tube (343 mm) 23. Thermostat 13. Radiator 24. Sealing ring 14. Radiator protector 25. Temperature gauge sender 15. Screw 26. Plug 27. Tank support 28. Washer 16. Pop rivet 17. Elbow hose 29. Clip 18. Outlet hose 19. "U" hose

COOLING SYSTEM


INSPECTION

Check general condition of hoses and clamp tightness.

DRAINING THE SYSTEM


Blizzard 7500 & Super Sonic

To drain the cooling system, remove the coolant tank cap and disconnect the by-pass hose from fitting on cylinder head.



Block fitting and keep hose as low as possible to drain the system.

However, to completely drain the system, it is necessary to blow into the tank through the vent tube, while maintaining the hand over the filler neck to prevent air leakage.




Blizzard 9500 Plus

To drain the cooling system, remove the coolant tank cap.



WARNING: Never drain or refill the cooling system when engine is hot.

Connect a drain hose to a drain valve at pump housing. Open valve and drain system.



NOTE: Open end of drain hose should be lower than engine base.

However, to completely drain the system, blow into the tank through the vent tube while blocking the tank filler neck with one hand to prevent air leakage.



DISASSEMBLY & ASSEMBLY

1) (25)(26) Apply pipe thread sealant to avoid leaks.

See if the cap pressurizes the system. If not, install a new 13 lbs cap, do not exceed 13 lbs of pressure.

3 To check thermostat, put it in water and heat water, Thermostat should open when water temperature reaches 43°C (110°F).



REFILLING THE SYSTEM


Blizzard 7500 & Super Sonic

Capacity:

Approximately 4 liters (0.9 lmp. gal.) (1 U.S. gal.) 55% concentrated antifreeze + 45% water

To refill the cooling system, disconnect by-pass hose and keep it near fitting on cylinder head; refill tank and blow into it through the vent tube, while maintaining the hand over the filler neck until the liquid comes out at the by-pass hose and the fitting on cylinder head.

NOTE: It is necessary to refill tank as soon as it becomes empty.



Reconnect by-pass hose and continue to pour the liquid in the coolant tank until the coolant level reaches 25 mm (1") below filler neck.

Reinstall tank cap and start engine; let engine run until it reaches its operating temperature and thermostat opens. Allow it to run a few minutes more. Stop engine and check coolant level; refill as necessary,




WARNING: Always unscrew cap to the first step with a cloth to release pressure, before removing it.

Blizzard 9500 Plus

Capacity:

Approximately 5 liters (1.1 lmp. gal.) (1.3 U.S. gal.) 55% antifreeze + 45% water

To refill the cooling system, unscrews plug on top of cylinder head.



Refill tank and blow into it through the vent tube, while maintaining the hand over the filler neck, until the liquid comes out at the plug hole on the cylinder head.


NOTE: It is necessary to refill tank as soon as it becomes empty.

Screw plug on cylinder head and continue to pour the liquid in the coolant tank until the coolant level reaches 25 mm (1") below filler neck.

Reinstall tank cap and start engine; let engine run until it reaches its operating temperature and thermostat opens. Allow it to run a few minutes more. Stop engine and check coolant level; refill as necessary.



WARNING: Always unscrew cap to the first step with a cloth to release pressure, before removing it.



BOTTOM END

CLEANING

Discard all oil seals, gaskets, "O" rings and sealing rings. Clean all metal components in a non-ferrous metal cleaner. Remove old "Loctite" from crankcase mating surfaces with Bombardier sealant stripper.



CAUTION: Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.


DISASSEMBLY & ASSEMBLY

①②③ Crankcase halves are factory matched and therefore, are not interchangeable or available as single halves. Prior to joining of crankcase halves, apply a light coat of "Loctite 515" (413 7027 00) on mating surfaces.



CAUTION: Before joining of crankcase halves be sure that crankshaft rotary valve gear is well engaged with rotary valve shaft gear.


Position the crankcase halves together and torque bolts by hand, then install armature plate (tighten) on magneto side to correctly align crankcase halves. Torque bolts to 22 N•m (16 ft-lbs) following illustrated sequence.



NOTE: Torque the two smaller bolts (15 and 16) on magneto side to 13 N•m (10 ft-lbs)

4 1 12 Apply "Loctite 242" on threads prior to assembly.

® 9 Because of cap nuts, cylinder studs have to be screwed into the crankcase so that they do not exceed further than 82.5 mm (3.250") on exhaust side and 57.5 mm (2.260") on intake side.



Apply "Loctite 242" on the threads of the two studs screwed above the intake ports.


19 Torque to 22 Nem (16 ft-lbs).

(6) Torque to 14 Nem (10 ft-lbs).

①At assembly on crankcase, apply "Loctite 242" on threads...


@ Torque to 35 Nem (26 ft-lbs).

2939 To remove bearings from crankshaft, use a protective cap and special puller as illustrated.




SECTION 04 SUB-SECTION 02 (ENGINES)

Prior to installation, place bearings into an oil container and heat the oil to 100°C (212°F). This will expand bearing and ease installation. Install bearings with groove as per the following illustration.




When positioning P.T.O. outer bearing on crankshaft, a gap of 0.5 mm (.020") must be left between bearing and labyrinth sleeve to avoid axial forces to the bearing.





On P.T.O. side, install oil seal flush with crankcase; do not push furthermore, there will be a gap of 0.5 mm (.020").

② Apply "Loctite 242" on threads then torque to 80 N•m (60 ft-lbs).



At assembly, apply a light coat of lithium grease on seal lips.





ROTARY VALVE & COOLANT PUMP

CLEANING

Discard all oil seals and "O" rings.


Clean all metal components in a non-ferrous metal cleaner.

DISASSEMBLY & ASSEMBLY

②Torque to 20 Nom (15 ft-lbs).

⑤Rotary valve adjustment when replacing crankcase having no timing marks.


REQUIRED TOOLS




ENGINE TYPE	TIMING MARKS opening, closing	
354, Blizzard 7500 and Super Sonic	132°, 50°	
454, Blizzard 9500 Plus	137°, 65°	

For example: 132° opening 50° closing

Using angle finder, mark crankcase at 132° from bottom edge of magneto side inlet port.




From top edge of magneto side inlet port, mark crankcase at 50°.




SECTION 04 SUB-SECTION 02 (ENGINES)

To correctly install the rotary valve disc proceed as follows:

- Turning crankshaft counter-clockwise, (drive pulley side) bring magneto side piston to Top Dead Center using a T.D.C. gauge.
- Position the rotary valve disc on gear to have edges as close as possible to the marks.
- NOTE: The rotary valve disc is asymmetrical, therefore, at assembly try positioning each side of disc on gear to determine best installation position.




② (9) At assembly, apply crankcase sealant "Loctite 515" on bearing and rotary valve shaft mating surfaces.




1 through 18 Rotary valve shaft assembly


To remove rotary valve shaft assembly from crankcase, first remove coolant pump impeller (a) and circlip (b). Using the suitable pusher (P/N 420 876 610) and a fiber hammer, push shaft assembly.



If it is necessary to disassemble components of rotary valve shaft assembly, compress spring retaining cup (7) in order to remove circlip (8).




To install shaft assembly and oil seal, use pusher no. 420 876 600.




- ²⁰Clean rotary valve shaft and inside of distance sleeve. At assembly apply "Loctite 271" inside of distance sleeve.
- (9) Using a suitable pusher, push coolant pump bearing with shield opposite to rotary valve disc.




To remove bearing




To install bearing




@ 10 Using no. 420 876 510 pusher, install oil seals (with lithium grease on seal lips).




Distance ring opening must be in line with crankcase half draining hole.





@Apply "Loctite 242" on threads.



TOP END

CLEANING

Discard all gaskets.

Clean all metal components in a non-ferrous metal cleaner.

Scrape off carbon formation from cylinder exhaust port, cylinder head and piston dome using a wooden spatula.


NOTE: The letters "AUS" (over an arrow on the piston dome) must be visible after cleaning.

Clean the piston ring grooves with a groove cleaner tool, or with a piece of broken ring.


DISASSEMBLY & ASSEMBLY

① ② 3 Prior to washer installation, apply silicone sealant around studs.


Torque cylinder head nuts to 16 N•m (12 ft-lbs) following illustrated sequence.




(a) Because of cap nuts, cylinder head studs have to be screwed into the cylinder so that they do not protrude by more than 43 mm (1.700"). If it is not possible to obtain this length, add a washer between cylinder head and cap nut. Shorter threaded part of stud should be screwed into cylinder.




When reassembling the cylinders to the crankcase, it is important to have them properly aligned so that the cylinder head holes will match up with the studs. A special tool (as per illustration) (or cylinder head itself) can be used to align the cylinders. Cross torque cylinder nuts to 16 N•m (12 ft-lbs).





(4) (5) Because of cap nuts, cylinder studs have to be screwed into the crankcase so that they do not protrude by more than 82.5 mm (3.250") on exhaust side and 57.5 mm (2.260") on intake side.

SECTION 04 SUB-SECTION 02 (ENGINES)



Apply "Loctite 242" on the threads of the two studs screwed above the intake ports.


(18) (19) Place a clean cloth over crankcase to prevent circlips from falling into crankcase then use a pointed tool to remove circlips from piston.

Drive the gudgeon pins in or out using a suitable drive punch and hammer.



CAUTION: When tapping gudgeon pin in or out of piston, hold piston firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.


At assembly, place the pistons over the connecting rods with the letters AUS (over an arrow on the piston dome) facing the direction of the exhaust port.




Piston to wall clearance should be:

TYPE	MINIMUM	MAXIMUM
354	0.080 mm (.0031'')	0.200 mm (.0079'')
454	0.090 mm (.0079'')	0.220 mm (.0087")

Once the circlips are installed, turn each circlip so that the circlip break is not directly in line with piston notch. Using very fine emery cloth, remove any burrs on piston caused through circlip installation.





23. Bolt M5 x 10

24. "Loctite 242"

12. Washer

11. Plug

36. Rubber spacer

35. Screw

MAGNETO

CLEANING


Clean all metal components in a non-ferrous metal cleaner.




CAUTION: Clean armature and magneto using only a clean cloth.

DISASSEMBLY & ASSEMBLY


To obtain best generator coil performance, position the armature plate on the crankcase with the retaining cap screws in the middle of the plate slots.



(2) Check air gap between magneto ring and trigger coil. The gap should be 0.8 - 1.2 mm (.031 - .047").



3 (3) To remove magneto, use special puller as illustrated. Tighten puller bolt and at same time, tap on bolt head using a hammer to release magneto from its taper.



At assembly, clean crankshaft extension (taper) then apply "Loctite 242".

(4) (a) At the re-installation or verification of the ignition system electric connections, all the connections must be coated with lithium grease or dielectric grease to prevent corrosion.




CAUTION: To prevent moisture, ensure no air is trapped within the connections. Do not use silicone sealant as contacts will corrode.

@Prior to assembly, clean threads then apply "Loctite 242".

Torque to 80 Nom (60 ft-lbs).

444 TYPE ENGINE



ENGINE SUPPORT & MUFFLER

REMOVAL FROM VEHICLE

Disconnect or remove the followings from vehicle:

- Pulley guard and drive belt.
- Air silencer, throttle cable.
- Fuel lines, primer and pulsation lines.
- Muffler and rewind starter.
- Electrical wires (junction block, main ground wire, starter wires)
- WARNING: Before disconnecting any electrical wire in starter system always first disconnect the battery cable.
- Drain the cooling system and disconnect hoses at engine.
- NOTE: It is not necessary to remove rotary valve oil hoses to remove engine from vehicle, it is easier to drain the system on the workshop bench.
- Remove engine mount nuts then lift engine from vehicle.

DISASSEMBLY & ASSEMBLY


- 8 Torque to 35 N•m (26 ft-lbs).
- 12 Torque to 14 Nom (10 ft-lbs)).

INSTALLATION ON VEHICLE

To install engine on vehicle, inverse removal procedure. However, pay attention to the followings:

- · Check tightness of engine mount nuts.
- After throttle cable installation, check carburetor maximum throttle slide opening.
- · Check pulley alignment.

(444 ENGINE TYPE), PAGE 2 1979 (SUPPLEMENT)



ENGINE SUPPORT AND MUFFLER

REMOVAL FROM VEHICLE

Disconnect or remove the followings from vehicle:

- Pulley guard and drive belt.
- Intake silencer and throttle cable.
- Fuel lines, primer and pulsation lines, fuel tank.
- Electrical wires (at engine, alternator, starter).
- WARNING: Before disconnecting any electrical wire in starter system, always first disconnect the battery cable.
- Drain the cooling system and disconnect hoses at engine.
- Remove engine mount nuts then lift engine from vehicle.


DISASSEMBLY AND ASSEMBLY

- (iii) At assembly on crankcase, apply "Loctite 242" on threads.
- 14 Torque to 36 Nom (26 ft-lbs),
- 17) Torque to 32 Nom (23 ft-lbs).
- 3 Torque to 14 Nom (10 ft-lbs).

INSTALLATION ON VEHICLE

To install engine on vehicle, inverse removal procedure. However, pay attention to the followings:

- Check tightness of engine mount nuts.
- After throttle cable installation, check carburetor maximum throttle slide opening.
- Check pulley alignment and alternator belt tension.




COOLING SYSTEM (Everest & Futura)

INSPECTION

Check general condition of hoses and clamps tightness.


DRAINING THE SYSTEM

To drain the cooling system, remove the coolant tank cap and disconnect the by-pass hose from fitting on cylinder head.



Block fitting and keep hose as low as possible to drain the system.

However, to completely drain the system, it is necessary to blow into the tank through the vent tube, while maintaining the hand over the filler neck to prevent air leak.



DISASSEMBLY & ASSEMBLY

- 1 24 Apply pipe thread sealant to avoid leaks.
- (8) See if the cap pressurizes the system. If not, install a new 13 lbs cap, (do not exceed 13 lbs of pressure).
- ② To check thermostat, put it in water and heat water. Thermostat should open when water temperature reaches 43°C (110°F).

REFILLING THE SYSTEM


Capacity:

4.5 liters approximately (0.9 lmp. gal.) (1.1 U.S. gal.)

55% concentrated antifreeze + 45% water

To refill the cooling system, disconnect by-pass hose and keep it near fitting on cylinder head; refill tank and blow into it through the vent tube, while maintaining the hand over the filler neck until the liquid comes out at the by-pass hose and the fitting on cylinder head.

NOTE: It is necessary to refill tank as soon as it becomes empty.




Reconnect by-pass hose and continue to pour the liquid in the coolant tank until the coolant level reaches 25 mm (1") below filler neck.

Reinstall tank cap and start engine; let engine run until it reaches its operating temperature and thermostat opens. Allow it to run a few minutes more. Stop engine and check coolant level; refill as necessary.



WARNING: Always unscrew cap to the first step with a cloth to release pressure, before removing it.

(444 ENGINE TYPE), PAGE 6



0

COOLING SYSTEM (Elite 450)

INSPECTION


Check general condition of hoses and clamps tightness.

DRAINING THE SYSTEM

To drain the cooling system, remove the coolant tank

Remove the R.H. access grill, and connect a length of plastic hose to the radiator drain valve in order to drain the cooling system outside of the body.

Open the drain valve.



DISASSEMBLY & ASSEMBLY

②To check thermostat, put it in water and heat water. Thermostat should open when water temperature reaches 43°C (110°F).

29 39 Apply pipe thread sealant to avoid leaks.

REFILLING THE SYSTEM


Capacity:

6.25 liters

(1.4 lmp. gal.) (1.7 U.S. gal.)


60% concentrated antifreeze + 40% water

To refill the cooling system, unscrew the plug on top of the cylinder head, then slowly pour the liquid into the coolant tank until it reaches the plug hole in the cylinder head. Reinstall the plug. Continue to pour the liquid in the coolant tank until the coolant level reaches 25 mm (1") below filler neck of reservoir.



With the pressure cap removed, start engine to allow the coolant to circulate and let it run until normal temperature is reached. Stop engine.

Then recheck coolant level, ensuring that it is 25 mm (1") below filler neck of reservoir.



D

BOTTOM END

CLEANING

Discard all oil seals, gaskets, "O" rings and sealing rings.

Clean all metal components in a non-ferrous metal cleaner.

Remove old sealant from crankcase mating surfaces with Bombardier sealant stripper.



CAUTION: Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.

DISASSEMBLY & ASSEMBLY


① ② ③ Crankcase halves are factory matched and therefore, are not interchangeable or available as single halves. Prior to joining of crankcase halves, apply "Loctite 515" (no. 413 7027 00) on mating surfaces.



CAUTION: Before joining of crankcase halves be sure that crankshaft rotary valve gear is well engaged with rotary valve shaft gear.


Position the crankcase halves together and tighten nuts by hand then install armature plate (tighten) on magneto side to correctly align the crankcase halves.

Torque bolts to 22 N•m (16 ft-lbs) following illustrated sequence.



- 4 It is recommended to wrap "Teflon" pipe tape around threads.
- (5) (1) Apply "Loctite 242" on threads prior to assembly.
- ® Because of cap nuts, cylinder studs have to be screwed into crankcase so that they do not protrude further than 15.6 cm (6.140"). If it is not possible to obtain this length, a washer must be added between cylinder head cap and cap nut.

Apply "Loctite 242" on the threads of the two studs screwed above the intake ports.




Longer threaded part of stud should be screwed into crankcase

- At assembly on crankcase, apply "Loctite 242" on threads.
- (3) Crankshaft center oil seals may be replaced at a crankshaft rebuild shop.
- (5) Torque to 35 N•m (26 ft-lbs).
- (6) (18) Torque to 22 N·m (16 ft-lbs).

1979 (SUPPLEMENT)

SECTION 04 SUB-SECTION 02 (ENGINES)


To remove bearings from crankshaft, use a protective cap and special puller as illustrated.




Prior to installation, place bearings into an oil container and heat the oil to 100°C (210°F). This will expand bearing and ease installation.

Install bearings with groove outward.

(a) At assembly, apply a light coat of lithium grease on seal lips.




To insure adequate oil supply to the bearing on the magneto side, install oil seal with a gap of at least 0.8 mm (.030") with bearing. On P.T.O. side install oil seal flush with crankcase, no more in.



To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support, as illustrated





ROTARY VALVE & COOLANT PUMP

CLEANING

Discard all oil seals and "O" rings.

Remove old crankcase sealant from rotary valve gear, adjacent bearing and cap mating surface.

Clean all metal components in a non-ferrous metal cleaner.

DISASSEMBLY & ASSEMBLY


- 2 Torque to 20 Nem (15 ft-lbs).
- 6 Apply "Loctite 242" on threads.
- (9) (1) There are two interchangeable types of rotary valve shaft. The first one is made of a shaft with a pinion attached to it by means of a key an Allen screw. On the second type, the pinion and the shaft are machined together as a single part.

First type




To remove rotary valve shaft assembly from crankcase, first remove pump impeller (29) and circlip (1).

Position special puller over shaft bore (with pinion removed) and screw puller bolt into rotary valve shaft. While holding puller bolt, turn puller nut clockwise until shaft comes out.



At assembly, apply "Loctite 515" on bearing and rotary valve gear mating surfaces.




To install shaft assembly, use a fiber hammer. Use a no. 420 876 505 pusher to insert oil seal with lithium grease on seal lip.


Second type



To remove rotary valve shaft assembly from crankcase, first remove pump impeller (29) and circlip (1). Using an appropriate pusher (P/N 420 876 610) and a fiber hammer, drive out shaft assembly.




At assembly, apply "Loctite 515" on bearing and rotary valve shaft mating surfaces.




SECTION 04 SUB-SECTION 02 (ENGINES)



To install shaft assembly and oil seal, use no. 420 876 600 pusher.




Rotary valve adjustment with replaced crankcase having to timing marks.




1979 444 type: 140° BTDC opening 50° ATDC closing

Using angle finder, mark crankcase at 140° from bottom edge of magneto side inlet port.




From top edge of magneto side inlet port, mark crankcase at 50°.




To correctly install the rotary valve proceed as follows:

- Turning crankshaft counter-clockwise, (drive pulley side) bring magneto side piston to Top Dead Center using a T.D.C. gauge.
- Position the rotary valve on gear to have edges as close as possible to the marks.
- NOTE: The rotary valve is asymmetrical, therefore, at assembly try positioning each side of disc on gear to determine best installation position.



@Through @ Rotary valve shaft assembly.


If it is necessary to disassemble components of rotary valve shaft assembly, compress spring cup (2) in order to remove circlip (2).




(8) Clean rotary valve shaft and inside of distance sleeve. At assembly, apply "Loctite 271" inside of distance sleeve.

(3) Using a suitable pusher, push pump bearing with shield facing rotary valve.

To remove bearing




② From pump side, using no. 420 876 510 pusher, install oil seals (with lithium grease on lips) as per illustrations.




Keep in mind that:


 distance ring opening must be in line with crankcase draining hole.



35% of the area between first and second oil seal (first oil seal being flush with crankcase) must be filled with lithium grease or equivalent.


To install bearing





Apply "Loctite 242" on threads.





TOP END


CLEANING

Discard all gaskets.

Clean all metal components in a non-ferrous metal cleaner.


DISASSEMBLY & ASSEMBLY

⑥ Decause of cap nuts, cylinder studs have to be screwed into crankcase so they do not protrude further than 15.6 cm (6.140"). If it is not possible to obtain this length, a washer must be added between cylinder head and cap nut.



Prior to washers (6) installation, apply silicone sealant on washer seat of cylinder head, around stud.

Torque cylinder head nuts to 38 N•m (28 ft-lbs) following illustrated sequence.



13 14 15 Place a clean cloth over crankcase to prevent circlips from falling into crankcase then use a pointed tool to remove circlips from piston.

Drive the gudgeon pins in or out using a suitable drive punch and hammer.

Scrape off carbon formation from cylinder exhaust port, cylinder head and piston dome using a wooden spatula.


NOTE: The letters "AUS" (over an arrow on the piston dome) must be visible after cleaning.

Clean the piston ring with a groove cleaner tool, or with a piece of broken ring.




CAUTION: When tapping gudgeon pin in or out of piston, hold piston firmly in place to eliminate the possibilities of transmetting shock and pressure to the connecting rod.

At assembly, place the pistons over the connecting rods with the letters AUS (over an arrow on the piston dome) facing direction of the exhaust port.



Once the circlips are installed, turn each circlip so that the circlip break is not directly in line with piston notch. Using very fine emery cloth, remove any burrs on piston caused through circlip installation.






Piston notch

(6) To check thermostat put it in water and heat water, thermostat should open when water temperature reaches 43°C (110°F).





- 1. Armature plate
- 2. Magneto ring
- 3. Magneto housing
- 4. Screw
- 5. Lockwasher
- *6. Starting pulley
- *7. Bolt
- 8. Magneto retaining nut 9. "Loctite 242"
- 10. Screw

- 11. Lockwasher
- 12. Flat washer
- 13. Capacitor
- 14. Lighting coil 110 W 15. Generator coil
- *16. Lighting coil 30 W *17. Screw
- *18. Distance sleeve (11 mm)
- 19. Contact breaker
- 20. Lubricating wick

- 21. Wire grommet
- 22. Ignition coil
- 23. Coil support
- 24. Nut
- 25. Screw
- 26. Protection cap
- 27. H.T. cable
- 28. Spark plug protector

* Everest & Futura only

MAGNETO

CLEANING

Clean all metal components in a non-ferrous metal cleaner.


V

CAUTION: Clean armature and magneto using only a clean cloth.

DISASSEMBLY & ASSEMBLY

③ ® With magneto retaining nut removed and hold-on support in place, install special puller onto hub.

Tighten puller bolt and at same time, tap on bolt head using a hammer to release magneto.



At assembly, clean crankshaft extension (taper) then apply "Loctite 242".


Install magneto retaining nut (with "Loctite 242" on threads) and torque to 80 N•m (60 ft-lbs).

- 4 29 Apply "Loctite 242" on threads.
- To replace a capacitor, it is first necessary to unsolder the black lead using soldering iron. The capacitor can then be driven out of the armature plate using a suitable pusher and hammer. To reinstall, inverse procedure.
- (4) (5) (6) Whenever a coil is replaced, the air gap (distance between coil end and magnet) must be adjusted.


To check air gap, insert a feeler gauge of 0.30-0.45 mm (.012-.018") between magnet and coil ends. If necessary to adjust, slacken coil retaining screws and relocate coil.



(20) When replacing contact breakers, apply a light coat of grease on lubricating wick.



503 ENGINE TYPE



ENGINE SUPPORT AND MUFFLER

REMOVAL FROM VEHICLE

Remove or disconnect the followings (if applicable) then lift engine out of vehicle.

- · Pulley guard, drive belt.
- · Muffler.
- · Air intake silencer.
- Throttle cable at carburetor.
- · Fuel lines and pulsation line.
- NOTE: Secure fuel lines so that the opened ends are higher than the fuel level in the tank.
- · Cab retaining cable.
- · Rewind starter cable.
- · Wiring harness.
- · Engine support and reinforcing cross support nuts

DISASSEMBLY AND ASSEMBLY


(5) Torque to 36 Nom (26 ft-lbs).

INSTALLATION IN VEHICLE

To install engine on vehicle, inverse removal procedure. However, pay attention to the followings:

- Check tightness of engine mount and cross support nuts
- After throttle cable installation, check maximum throttle slide opening.
- · Check pulley alignment.

(SUPPLEMENT) 1979



D

BOTTOM END

CLEANING

Discard all oil seals, gaskets and "O" rings.

Clean all metal components in a non-ferrous metal cleaner.

Remove old sealant from crankcase mating surfaces with Bombardier sealant stripper.



CAUTION: Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.


DISASSEMBLY AND ASSEMBLY

① ② ⑨ Crankcase halves are factory matched and therefore, are not interchangeable as single halves.


Prior to joining of crankcase halves, apply Loctite 515 (no. 413 7027) on mating surfaces.

Position the crankcase halves together and tighten nuts (or bolts) by hand then install armature plate (tighten) on magneto side to correctly align the crankcase halves.

Torque nuts (or bolts) to 21 N•m (15 ft-lbs) following illustrated sequence.




- (4) (5) Torque to 21 N•m (15 ft-lbs).
- (6) At assembly on crankcase, apply "Loctite 242" or equivalent on threads.
- (8) Torque to 36 Nem (26 ft-lbs).
- To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support as illustrated. (See Tools Section).



At assembly, apply "Loctite 242" or equivalent on threads, then torque to 80 N·m (60 ft-lbs).

®At assembly, apply a light coat of lithium grease on seal lip. Seal outer surface should be flush with crankcase.

20 To remove bearing from crankshaft use a protective cap and special puller, as illustrated. (See Tools Section).




Prior to installation, place bearings into an oil container and heat the oil to 100°C (210°F) for 5 to 10 minutes. This will expand bearings and ease installation, Install bearings with groove as per exploded view.



P.T.O. side

At inner bearing installation, provide a free play of 2 mm (.080") for lubrication between bearing and crankshaft blade, using P/N 420 876 620 tool.




MAG side

At bearing installation, provide a free play of 1 mm (.040") for lubrication between bearing and crankshaft blade, using P/N 420 876 625 tool.



Transport to provide a free play of 1 mm (.040") between oil seal and bearing.



ON 02 (ENGINE)

TOP END 1. Cylinder flange gasket 2. Cylinder 3. Cylinder head gasket 4. Cylinder head 5. Washer 8.4 mm 6. Nut 7. Distance sleeve 8. Distance nut M8 x 35 9. Intake manifold gasket 10. Intake manifold 11. Lockwasher M8 12. Allen screw M8 x 40 13. Noise damper 14. Noise damper (short) 15. Noise damper (long) 16. Piston 17. Gudgeon pin 18. Circlip 19. Needle bearing 20. Rectangular ring 21. Semi-trapez ring

TOP END

CLEANING

Discard all gaskets.

Clean all metal components in a non-ferrous metal cleaner.


Scrape off carbon formation from cylinder exhaust port, cylinder head and piston dome using a wooden spatula.

NOTE: The letters "AUS" (over an arrow on the piston dome) must be visible after cleaning.

Clean the piston ring grooves with a groove cleaner tool, or with a piece of broken ring.


DISASSEMBLY AND ASSEMBLY

② (At cylinder and/or cylinder head installation, use P/N'420 876 171 aligning toold (or exhaust manifold) to ensure sealing of intake manifold and exhaust (See Tools Section), before tightening cylinder head nuts.



Cross torque cylinder head nuts to 20 N•m (15 ft-lbs); torque each cylinder head individually.


(6) (7) (8) Position nuts, distance nuts and distance sleeves as illustrated.



Torque nuts to 20 Nem (15 ft-lbs)

(9) Install a gasket on each side of the air deflector.


@Install intake manifold as per the following illustration.




12 Torque to 20 N•m (15 ft-lbs).

SECTION 04 SUB-SECTION 02 (ENGINE)

(3) (4) (5) For proper position of noise dampers, refer to the following illustrations.






(19 17) (19 Place a clean cloth over crankcase to prevent circlips from falling into crankcase. Use a pointed tool to remove circlips from piston.



CAUTION: When tapping out gudgeon pins, hold piston firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.

At assembly, place the pistons over the connecting rods with the letters "AUS" (over an arrow on the piston dome) facing in the direction of the exhaust port.




Piston to wall clearance should be:

MINIMUM: 0.060 mm (.0024") MAXIMUM: 0.160 mm (.0063")

NOTE: Once circlips are installed, turn each circlip so the circlip break is not directly on piston notch. Remove any burrs from piston caused through circlip installation using very fine emery clotch.






MAGNETO

CLEANING

Clean all metal components in a non-ferrous metal cleaner.




DISASSEMBLY AND ASSEMBLY

(2) (4) (6) Whenever a coil is replaced, the air gap (distance between coil end and magnet) must be adjusted.

To check air gap, insert a feeler gauge of 0.30-0.45 mm (.012"-.018") between magnet and coil ends. If necessary to adjust, slacken coil retaining screws and relocate coil.




- (9) To replace a capacitor, it is first necessary to unsolder the two (2) black leads. The capacitor can then be driven out of the armature plate using a suitable pusher and hammer. To reinstall, inverse procedure.
- (3) When replacing contact breakers, apply a light coat of grease on lubricating wick.
- (5) ②To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support as illustrated. (See Tools section).



With magneto retaining nut removed, install special puller onto hold-on support.

Tighten puller bolt and at same time, tap on bolt head using a hammer to release magneto from its taper.



At assembly, clean crankshaft extension (taper) then apply "Loctite 242" or equivalent.

Install magneto retaining nut (with "Loctite 242" on threads) and torque to 80 N•m (60 ft-lbs).

20 28 At assembly, apply "Loctite 242" on retaining screw threads.

COOLING SYSTEM 22 24 19 1. Fan housing 2. Circlip 3. Shim 1 mm 4. Ball bearing 5. Fan shaft 6. Woodruff key 7. Distance sleeve 8. Pulley half 9. Shim 0.5 mm 10. Fan 11, Lockwasher 20. Upper air deflector 12. Nut M16 x 1.5 21. Deflector gasket 13. Belt 22. Lockwasher M8 14. Protector 23. Screw M8 x 16 15. Cable grommet 24. Washer 16. Lower air deflector 25. Screw 17. Lockwasher M6 26. Lockwasher M6 18. Screw M6 x 12 27. Allen screw M6 x 30 19. Speed nut 28. Spark plug grommet

1


COOLING SYSTEM

CLEANING

Clean all metal components in a non -ferrous metal cleaner.

DISASSEMBLY AND ASSEMBLY

- ① 4 It is first necessary to heat bearing housing to 65°C (150°F) to remove or install bearing.
- ② To remove or install fan pulley retaining nut, lock fan pulley with special holder wrench. (See Tools section). At assembly, torque nut to 62 N•m (46 ft-lbs).



- (B) A gasket must be placed on both sides (inner and outer) of intake and exhaust holes.
- (8) (29) At assembly, apply a light coat of "Loctite 242" on threads. It should be noted that to correctly remove a Loctite locked screw, it is first necessary to slightly tap on head screw to break Loctite bond. The screw can then be removed. This will eliminate the possibility of screw breakage.

0

(503 ENGINE TYPE), PAGE 12

IGNITION TIMING

These sub-section apply to the following 1979 engine types:

For 247 engine type, refer to 1978 Bombardier Shop Manual.



IGNITION TIMING — TWO CYLINDER ENGINES) (248, 294, 343, 402, 440, 444, 503, 640 TYPES)

FOREWORD

For timing purposes, it is necessary to separate the twin cylinder engines into two groups.

GROUP 1: 248, 294, 343 (no. 3021123 and above) engine types

These engines do not incorporate an automatic advance mechanism. The ignition timing marks on the magnetoring are stamped at the full advance position.

GROUP 2: 343 (up to no. 3021122), 402, 440 444, 503, 640 engine types


These engines incorporate an automatic advance mechanism. The ignition timing marks on the magneto ring are stamped at the full advance position. Therefore, when setting the ignition timing always hold the centrifugal lever at the full advance position.

Two methods are detailed in this section; the first using the timing marks stamped on the engine, the second using a Top Dead Center gauge.


TIMING MARKS PROCEDURE

- Disconnect spark plug wires and remove spark plugs.
- Remove rewind starter assembly from engine then remove the fan protector, starting pulley and "V" belt.
- NOTE: The upper breaker point set controls the timing of the magneto side piston and the lower breaker point set controls the P.T.O. side piston.
- 3. Rotate crankshaft until breaker points, visible through magneto ring opening, are fully opened. Adjust point setting to 0.40 mm ± 0.05 (.016" ± .002) using a feeler gauge and screwdriver, as illustrated. Repeat procedure for other set of points. Adjust both side equally.

- NOTE: Breaker point gap can change upon tightening. Always recheck after tightening.
- Disconnect junction block at engine then connect one lead of a timing light (flashlight type) or of a tone timer, to the blue wire (mag. side) leading from engine. Connect other wire to fan cowl (ground).
- Slacken the two (2) armature plate retaining screws and turn timing instrument ON. Rotate crankshaft until mag, side piston approaches top dead center and timing marks align (while holding centrifugal lever in the open position, toward magneto rim).




Rotate armature plate until timing light fluctuates or tone signal level varies. Retighten retaining screws.




SECTION 04 SUB-SECTION 04 (IGNITION TIMING)

 Ignition timing can change upon tightening therefore, rotate the magneto counter-clockwise 1/4 of a turn and slowly turn the magneto back in a clockwise direction. As soon as the timing marks align the timing light should fluctuate, or the tone signal level should vary. Readjust if necessary.





Too early: Turn armature plate clockwise



Too late: Turn armature plate counter-clockwise

- 7. Disconnect timing instrument wire from blue wire then reconnect it to the blue/red wire (P.T.O. side) leading from engine. Rotate crankshaft until P.T.O. side piston approaches top dead center. As soon as timing marks align, timing light should fluctuate, or tone signal sound level should vary. If necessary to adjust, proceed as follows:
 - If timing is too early decrease breaker point gap toward lower limit, i.e. 0.35 mm (.014"), then recheck timing.
 - If timing is too late increase breaker point gap toward upper limit, i.e. 0.45 mm (.018"), then recheck timing.






Too late: Increase point gap


TDC GAUGE PROCEDURE

- 1. Disconnect spark plug wires and remove spark plugs.
- Remove rewind starter assembly from engine then remove the fan protector, starting pulley and "V" belt.
- NOTE: The upper breaker point set controls the timing of the magneto side piston and the lower breaker point set controls the P.T.O. side piston.
- Rotate crankshaft until breaker points, visible through magneto ring opening, are fully open. Adjust point setting to 0.40 mm ± 0.05 (.016" ± .002) using a feeler gauge and screwdriver, as illustrated. Repeat procedure for other set of points. Adjust both side equally.



- NOTE: Breaker point gap can change upon tightening. Always recheck after tightening.
- 4. Disconnect junction block at engine then connect one lead of a timing light (flashlight type) or a tone timer, to the blue wire (mag. side) leading from engine. Connect other wire to fan cowl (ground).
- 5. Install and adjust T.D.C. gauge on engine as follows.
 - Rotate magneto until mag. side piston is just before top dead center.

 With gauge in adaptor, adjust roller so that it is parallel with dial face. Tighten roller lock nut.



- Loosen adaptor lock nut then holding gauge with dial face toward magneto, screw adaptor in mag. side spark plug hole.
- Slide gauge far enough into adaptor to obtain a reading then finger tighten adaptor lock nut.
- Rotate magneto until mag. side piston is at top dead center.
- Unlock outer ring of dial and turn it until "0" on dial aligns with pointer.
- · Lock outer ring in position.

SECTION 04 SUB-SECTION 04 (IGNITION TIMING)

Slacken the two (2) armature plate retaining screws and turn timing instrument ON.

Rotate magneto counter-clockwise until specified piston position before top dead center is reached.

Engine type	Direct measurement B.T.D.C.	Indirect measurement B.T.D.C.
		amhu
248	Not applicable	2.29 mm ± 0.25 (.090" ± .010)
294	Not applicable	2.49 mm ± 0.25 (.098" ± .010)
343, 402	Not applicable	2.46 mm ± 0.25 (.097" ± .010)
440	Not applicable	3.30 mm ± 0.25 (.130" ± .010)
444	2.35 mm ± 0.25 (.092" ± .010)	Not applicable
503	2.07 mm ± 0.25 (.081" ± .010)	Not applicable
640	Not applicable	4.11 mm ± 0.25 (.162" ± .010)

Hold advance mechanism centrifugal lever in full advance position (toward magneto rim) then slowly rotate armature plate until timing light fluctuates or until tone signal sound level varies. Retighten retaining screws.

NOTE: Ignition timing can change upon tightening. Always recheck after tightening.

 Disconnect timing instrument wire from blue wire then reconnect it to the blue/red wire leading from engine. Remove T.D.C. gauge from mag. side and reinstall it on P.T.O. side, as previously detailed. 8. Hold centrifugal lever in full advance position (toward magneto rim) and rotate crankshaft until P.T.O. piston approaches T.D.C. As soon as same specified piston position before top dead center as on mag. side is reached the timing light should fluctuate or tone signal level vary. If necessary to adjust proceed as follows:

With centrifugal lever in full advance position and piston at specified position, slacken lower breaker point set retaining screw then readjust breaker point gap until timing light fluctuates or tone signal level varies.

- If timing is too early decrease breaker point gap toward lower limit, i.e. 0.35 mm (.014"), then recheck timing.
- If timing is too late increase breaker point gap toward upper limit, i.e. 0.45 mm (.018"), the recheck timing.
- NOTE: Breaker point gap can change upon tightening. Always recheck after tightening.


EDGE GAP VERIFICATION

By following either of the procedures mentioned herein the edge gap will automatically be adjusted. However, if the edge gap is to be verified, proceed as follows:

 From timing marks, rotate magneto clockwise 1/4 of a turn. Hold advance mechanism centrifugal weight in the open position (toward magneto rim) then slowly turn magneto back counter-clockwise until timing light fluctuates or until tone signal sound level varies.

At this point check the distance between pole shoe trailing edge and magnet (edge gap), with a strip of cardboard of appropriate width. (Refer to the following table.)

	v
Engine type	Edge gap
248, 294	7-11 mm (.275 430'')
440, 640	5-8 mm (_200 – .315'')
343, 402, 444, 503	6-10 mm (.235400'')



If edge gap is more or less than specified the problem lies within engine internal components (crankshaft out of alignment, broken Woodruff key, loose breaker cam, etc.). Corrective measures should be applied.



FOREWORD


On models equipped with a C.D. ignition system, plug firing is initiated by an electrical pulse. This pulse is released when a metal projection on the flywheel hub rotates near the pick-up coil. Therefore, timing must be performed while the engine is running.

A stroboscopic timing light such as Sun PTL 45, Snap-On MT215B, Bosch EFAW 169A, or a suitable equivalent, plus a 12 volt battery are needed.

IGNITION TIMING

Timing procedure for this engine type is composed of four main phases, all being equally important:

- 1. Position of the armature plate.
- 2. Position of the timing marks on magneto ring.
- 3. Air gap between trigger coil and magneto ring.
- 4. Timing verification using a stroboscopic timing light.
- To obtain best generator coil performance, position the armature plate on the crankcase with the retaining cap screws in the middle of the plate slots.







CAUTION: When assembling magneto ring on crankshaft, clean crankshaft extension (cone) and threads. Apply Loctite 242 (no. 413 7025) on cone and threads. Torque bolt to 80 N•m (60 ft-lbs).

Check the position of the timing marks (for each cylinder) on magneto ring: repunch if necessary.


C.D. IGNITION — 354-454 ENGINE TYPES

With the piston positioned at 1.40 mm (.055") B.T.D.C., magneto ring mark should align with central mark on crankcase (around timing hole).





3. Check air gap between magneto ring and trigger coil. The gap should be 0.8 to 1.2 mm (.031 to .047").




SECTION 04 SUB-SECTION 04 (IGNITION TIMING)


Check timing using a stroboscopic timing light (on each cylinder).


WARNING: Place ski tips against the wall, raise rear of vehicle so the track is not in contact with the ground and place it on a stand equipped with a protector. Make sure nobody passes behind the vehicle during timing procedure.


Magneto ring mark and crankcase central mark should align at 6500 RPM.



If necessary to adjust: unscrew slightly the two (2) screws holding trigger coil bracket, then move bracket up or down.







NOTE: Carburetor side trigger coil controls magneto side ignition and exhaust side trigger coil controls P.T.O. side ignition.


(C.D. IGNITION), PAGE 2 1979 (SUPPLEMENT)

CARBURETOR

Refer to the 1978 Bombardier Shop Manual

NOTE: Supplementary information applicable to all Mikuni carburetors.

All new Mikuni carburetors are equipped with a new throttle slide. The new design has a deeper "E" clip seat, to permit the installation of a nylon bushing between the "E" clip and its seat.



Make sure the bushing is installed on all applicable throttle slides.

CAUTION: Serious engine damage can occur if this notice is disregarded.




SECTION 04 SUB-SECTION 06 (AIR INTAKE SILENCER AND FUEL TANK)

Models covered in this section:

BLIZZARD 5500 1979 GRAND PRIX SPÉCIAL 1979 BLIZZARD 9500 1979

For all other models, refer to the 1978

1979	ELAN	refer to	1978	ELAN
1979	SPIRIT	refer to	1978	SPIRIT
1979	OLYMPIQUE	refer to	1978	OLYMPIQUE
1979	NUVIK	refer to	1978	NUVIK
1979	CITATION	refer to	1978	CITATION
1979	MIRAGE	refer to	1978	CITATION
1979	EVEREST	refer to	1978	EVEREST
1979	FUTURA	refer to	1978	FUTURA
1979	BLIZZARD 7500 / CROSS COUNTRY	refer to	1978	BLIZZARD 6500
1979	SUPER SONIC / CROSS COUNTRY	refer to	1978	BLIZZARD 6500
1979	ALPINE 640 ER	refer to	1978	ALPINE 640 ER
1979	ELITE 450 LC	refer to	1978	ELITE



SECTION 04 SUB-SECTION 06 (AIR INTAKE SILENCER AND FUEL TANK)

- 1. Rubber Flange (2)
- 2. Clamp (4)
- 3. Carburetor VM 34-203 (2)
- 4. Adaptor (2)
- 5. Gear Clamp (2)
- 6. Air Intake
- 7. Elbow
- 8. Clamp
- 9. Throttle Cable & Housing
- 10. Circlip
- 11. Impulse hose 12" (305 mm) (AR)
- 12. Fuel Pump
- 13. Washer Head Screw (2)
- 14. Internal Tooth Lockwasher (2)
- 15. Fuel Line 23" (584 mm) (AR)
- 16. Fuel Line 16" (406 mm) (AR)
- 17. Fuel Line 12" (305 mm) (AR)
- 18. Fuel Line 4" (102 mm) (AR)
- 19. Fuel Line 6" (153 mm) (AR) 20. Fuel Line 20" (508 mm) (AR)
- 21. Fuel Gauge 6.6" (133 mm) (AR)
- 22. Spring Clip (AR)
- 23. Tee
- 24. Fuel Filter
- 25. Fuel Tank
- 26. Tube
- 27. Grommet (3)
- 28. Male Connector (3)

- 29. Fuel Tank Cap
- 30. Spring
- 31. Pin
- 32. Release spring
- 33. Pressure Pad
- 34. Gasket
- 35. O'Ring
- 36. Roll Pin
- 37. Pin (2)
- 38. Lock
- 39. Spring
- 40. Push Nut (6)
- 41. Air Vent Fitting
- 42. Nut
- 43. Air Vent Tube 49" (1235 mm) (AR).
- 44. Primer Tube 12.5" (318 mm) (AR)
- 45. Primer Tube 23" (584 mm) (AR)
- 46. Primer Tube 4.5" (115 mm) (AR)
- 47. Primer Valve
- 48. Tee
- 49. Cable Clip
- 50, Clip
- 51. Clip
- 52. Screw (2)
- 53. Washer (4)
- 54. Nut (4)
- 55. Retainer
- 56. Tie Rap (AR)


BLIZZARD 5500 GRAND PRIX SPÉCIAL BLIZZARD 9500

Air silencer

CAUTION: Never operate your snowmobile with the air intake silencer disconnected. Serious engine damage will occur if this notice is disregarded.

The air intake silencer elbow must always be turned to the front of the vehicle when operated in cold, warm temperature.

If the vehicle is to be operated in deep powdered snow it is recommended to turn the elbow towards the rear of the vehicle.




Throttle slide adjustment



WARNING: Ensure the engine is turned **OFF**, prior to the throttle slide adjustment.

With the throttle cable adjuster jam nut unlocked, press the throttle lever against the handle grip. Unscrew the cable adjuster manually to obtain maximum carburetor slide opening. (With the air silencer removed, check with your finger if the carburetor slide is well seated against the carburetor top portion). Then, screw the cable adjuster in two turns in order to nullify any possible tension on the throttle cable then tighten the cable adjuster jam nut.





WARNING: It is important that the throttle side adjustment be performed to ensure proper functioning of throttle mechanism.

MODEL	HEADLAMP watts	TAILLIGHT watts	CHART NO
ELAN 250 / SPIRIT	60/60	5/21	1
ELAN 250 DELUXE	45/45	5/21	2
CITATION / MIRAGE	45/45	5/21	3
OLYMPIQUE / NUVIK 340	60/60	5/21	4
OLYMPIQUE / NUVIK 340E	60/60	5/21	5
EVEREST 340-440 / FUTURA 400-440	60/60	5/21	6
EVEREST 340E-440E / FUTURA 400E-440E	60/60	5/21	7
EVEREST 444 LC / FUTURA 444 LC	45/45	5/21	8
BLIZZARD 5500 / GRAND PRIX SPECIAL	60/60	5/21	9
BLIZZARD 7500 PLUS / SUPER SONIC / CROSS COUNTRY	60/60	5/21	10
BLIZZARD 9500 PLUS	60/60	5/21	11
ALPINE 640 ER	60/60	5/21	12
ELITE 450 LC	60/60	5/21	13

~		~		-	-	$\overline{}$	_
 	 		R		1	1.1	_

BK - BLACK	GN - GREEN
WH - WHITE	GY - GREY
RD - RED	VI - VIOLET
BL - BLUE	OR - ORANGE
YL - YELLOW	BR - BROWN













CHART NO 3 1979 CITATION 294cc TWIN 1979 MIRAGE


























SPARK PLUGS

SPARK PLUG NUMBERING SYSTEM

Bosch has introduced a new numbering code for its complete line of spark plugs. The new code is shorter, therefore easier to use. The following charts will assist you in making the change-over easily and effectively.

IMPORTANT: The new code has a different heat range identification system.

High number	→ hot plug
Low number	cold plug


CROSS REFERENCE CHART

List of Bosch* spark plugs used on Bombardier snowmobiles:

NEW NUMBER	OLD NUMBER
M4A1	M260T1
M4A2	M240T1
M5A	M225T1
M7A	M175T1
W08CS	W340S2S
W3A0	W280MZ1
W3C0	W280MZ2
W4A2	W240T1
W4A5	W260MZ1
W4A6	W240MZ1
W4C3	W260MZ2

^{*} The bosch M280T1 spark plug is replaced by the NGKA8 plug.

(SUPPLEMENT) 1979 (SPARK PLUGS) PAGE 1



(SPARK PLUGS) PAGE2 (SUPPLEMENT) 1979

SPARK PLUG

HEAT RANGE


The proper operating temperature or heat range of the spark plug is determined by the spark plug's ability to dissipate the heat generated by combustion.

The longer the heat path between the electrode tip to the plug shell, the hotter the spark plug operating temperature will be — and inversely, the shorter the heat path, the colder the operating temperature will be.

A "cold" type plug has a relatively short insulator nose and transfers heat very rapidly into the cylinder head.

Such a plug is used in heavy duty or continuous high speed operation to avoid overheating.

The "hot" type plug has a longer insulator nose and transfers heat more slowly away from its firing end. It runs hotter and burns off combustion deposits which might tend to foul the plug during prolonged idle or low speed operation.





CAUTION: Severe engine damage can occur if a wrong heat range plug is used:


A too "hot" plug will result in overheating and pre-ignition, etc.

A too "cold" plug will result in fouling (shorting the spark plug) or may create carbon build up which can heat up red-hot and cause pre-ignition or detonation.

FOULING

Fouling of the spark plug is indicated by irregular running of the engine, decreasing engine speed due to misfiring, reduced performance, and increased fuel consumption. This is due to a loss of compression. Other possible causes are: prolonged idling, running the engine with the choke on, or running on a too rich a mixture due to a faulty carburetor adjustment or incorrect fuel and/or fuel mixing. The plug face of a fouled spark plug has either a dry coating of soot or an oily, glossy coating given by an excess either of oil or of oil with soot. Such coatings form a conductive connection between the center electrode and ground.

SPARK PLUG ANALYSIS



The plug face (and piston dome) reveals the condition of the engine, operating condition, method of driving and fuel mixture. For this reason it is advisable to inspect the spark plug at regular intervals, examining the plug face (i.e. the part of the plug projecting into the combustion chamber) and the piston dome.

SPARK PLUG INSTALLATION

Prior to installation make sure that contact surfaces of the cylinder head and spark plug are free of grime.

- 1. Using a wire feeler gauge, set electrode gap.
- 2. Apply A light coat of graphite grease over the spark plug threads to prevent possible seizure.
- 3. Hand screw spark plug into cylinder head and tighten with a torque wrench:

M (18 mm) 40 N•m (30 ft-lbs) W (14 mm) 27 N•m (20 ft-lbs)

(SUPPLEMENT) 1979 (SPARK PLUGS) PAGE 3

SECTION 05 SUB-SECTION 02 (SPARK PLUGS)

1979 SPARK PLUG CHART

Bombardier Limited prescribes two spark plug types for specific uses on many of its snowmobile models.

Full load: frequent use of maximum engine RPM,

Partial load: use of medium engine RPM.

		ENGINE TYPE	FULL LOAD	PART LOAD
ELAN & SPIRIT	250	247	M175 T1	M175 T1
ELAN	250 Deluxe	248	W240 MZ1	W240 MZ1
CITATION & MIRAGE	300	294	W260 MZ1	W260 MZ1
OLYMPIQUE & NUVIK	340	343	W280 MZ1	W280 MZ1
EVEREST	340	343	W280 MZ1	W280 MZ1
FUTURA	400	402	W280 MZ1	W280 MZ1
EVEREST & FUTURA	440	440	M280 T1 (NGK A-8)	M260 T1
EVEREST & FUTURA	444 LC	444	W280 MZ2	W260 MZ2
BLIZZARD 5500/ GP Special	503	503	W275 T2	W275 T2
BLIZZARD 7500/SUPER SONIC	354	354	W340 S2S	W340 S2S
CROSS COUNTRY	354	354	W275 T2	W275 T2
BLIZZARD	9500	454	W340 S2S	W340 S2S
ALPINE	640 ER	640	M240 T1	M240 T1
ELITE	450 LC	444	W280 MZ2	W260 MZ2


TESTS PERFORMED WITH MERC-O-TRONIC ANALYSER

This sub-section applies to 1979 models as for no. 3 test (Ignition coil resistance «secondary»).

For all other tests, refer to 1978 Bombardier Shop Manual.


TEST NO. 3 IGNITION COIL RESISTANCE (SECONDARY)

- Turn selector switch to position no. 3 COIL CON-TINUITY.
- 2. Connect the back test lead to terminal no. 15 of the external coil.
- 3. Connect the red test lead to the spark plug terminal of the coil.
- Read the RED figures of Scale no. 3. Meter reading must be between specification limits. The values on red scale no. 3 are in OHM and must be multiplied by 1,000. If coil is not within specifications, replace the defective coil.



CODE NUMBER	RESISTANCE MINIMUM — MAXIMUM
Up to 724	6300 — 8500 ohms
From 725 and up	4850 — 5850 ohms

TEST NO. 3 IGNITION COIL RESISTANCE (SECONDARY)





BOMBARDIER IGNITION TESTER



GENERAL

The Bombardier ignition tester is an electrical energy measuring device capable of measuring the peak energy output of a coil.

The tester is of solid state construction and performs as a comparator. The correct value of energy output is indicated in each test and is then compared with the value taken from the engine being tested.

The energy output is verified by means of a 0-100 scale on the tester. The greater the energy output, the greater value indication on the scale. The indication is in the form of an incandescent lamp that lights when the scale knob is set at the position corresponding to the energy output.

The tester has two input ranges selected by a toggle switch. The LOW range is sensitive to AC or DC voltages from 0.5 to 27 volts. The HIGH range is sensitive to AC or DC voltages of from approximately 75 to 500 volts.

TEST CONDITION

All tests are performed on the vehicle at cranking speed.

Vigorous cranking against compression causes the flywheel to snap over, raising the output higher than by cranking without compression, therefore, do not remove spark plug.

Test values listed are taken against compression.

Always crank vigorously as in actual starting.

Read all instructions thoroughly and as you become familiar with this test instrument it will be possible to test a complete ignition system in a matter of minutes. Always proceed in the following order:

- 1. Connect tester P and N clip leads as illustrated.
- 2. Follow test procedure sequence.
- After every test that lights the indicator lamp, reset the indicator circuit by depressing the reset button.

ANALYSIS OF TEST RESULTS

Indicator lamp lights at specific setting

Output is as specified. Test results should repeat three times. If readings do not repeat, output is erratic and cause should be investigated (loose connections or components, etc.).

Indicator lamp lights at lower setting

This indicates that the output is less than that designed to operate in a satisfactory manner. However, before coming to the conclusion of a faulty condition be certain that correct engine cranking conditions were met before condemning the ignition.

Indicator lamp does not light.

One component is defective. Proceed as instructed to find defective component.

Intermittent ignition problems

In dealing with intermittent problems there is no easy diagnosis. For example, problems that occur only at normal engine operating temperature have to be tested under similar conditions.

In most cases of temperature and/or vibration failure, only parts replacement can solve the problem as most of these failures return to normal when engine is not running.

Double trouble

There is always the possibility of more than one faulty parts. If after a component has been replaced, the problem still persists, carefully repeat the complete test procedure to find the other faulty part.

ANALYSER TEST AND MAINTENANCE

A test simulator is provided with each tester as a means to test the lamp, detector circuit, and batteries.

High scale test

- a) Place switch in HIGH position. Plug the simulator into an electric outlet (117 VAC) for ten seconds.
- CAUTION: After charging, do not touch plug terminals while pressing test button. A mild shock will result.
- b) Remove the simulator from the outlet, and connect the "P" and "N" leads from the tester to the simulator as indicated on the button of the simulator.
- c) Set the tester dial to 50, or below. Depress the button of the simulator. The indicator lamp on the tester should light.
- NOTE: For each test performed by the simulator, it must be recharged.


Low scale test

- a) Place switch in LOW position.
- b) Set tester dial to 50, or below.
- c) Connect N lead to negative terminal of 12 volt battery. Connect P lead to positive terminal of 12 volt battery: indicator lamp should light.

If lamp does not light, check tester batteries. If they are installed correctly and are good, check the clip leads for faulty connections. If no fault can be found, refer to the warranty statement for instructions for sending the tester back to Electro-Specialties, Inc.

Battery replacement

- 1. Remove the four (4) screws securing cover to case.
- 2. Carefully lift cover.
- Replace batteries with size "C" Alkaline batteries. Be sure to observe polarity markings on battery holder or lamp will not light.



- Carefully install cover on case being certain that no wires are pinched between cover and case. Secure cover.
- NOTE: Weak batteries will not impair tester operation or calibration. The light will glow dim.

The ignition tester may give false readings if the rivets on the back cover come in contact with metal.

Indicator knob alignment

Check indicator knob alignment by turning knob fully clockwise. The white mark on the knob must align with no. 100 on the scale. If the marks does not line up with the no. 100, loosen the knob set screw, line the mark on the knob with no. 100, and tighten the set screw. Recheck alignment.

NOTE: If after adjustment, the knob is turned fully counter-clockwise and it does not exactly align with the 0, it is of no consequence.

SECTION 05 SUB-SECTION 03 (ELECTRICAL TESTS)

TESTS INDEX

ROTAX ONE CYLINDER BREAKER POINTS ENGINE

- 1. Generator coil output.
- 2. Lighting coil output.
- 3. Brake light coil output.

ROTAX TWO CYLINDER BREAKER POINTS ENGINE

- 4. Generator coil output.
- 5. Lighting coil output.
- 6. Brake light coil output.


ROTAX TWO CYLINDER ELECTRONIC IGNITION ENGINE

- 7. Generator coil output.
- 8. Trigger coil output.
- 9. Lighting coil output.

ONE CYLINDER ENGINE

1. GENERATOR COIL OUTPUT

- Disconnect blue and black wires from terminal (15) of ignition coil.
- Attach tester P lead to blue and black wires prviously disconnected. Connect tester N lead to a good engine ground.




3. Set tester dial and switch as follows:

Engine type	Switch position	Dial
247	HIGH	75

- Turn ignition key to ON position, disable emergency cut-out button circuit then crank engine.
- A. Indicator lamp lights: Coil output is up to specifcations. Repeat test at least three (3) times to verify reading and check for consistency.
- B. Indicator lamp does not light: Coil output is below specifications. This could be caused by a faulty coil or breaker points. Check breaker points condition and adjustment, and correct as necessary. Repeat test. If lamp still does not light the coil is defective and should be replaced.

2. LIGHTING COIL OUTPUT

- 1. Disconnect wiring harness junction block at engine .
- 2. Connect tester leads as illustrated using two (2) harness adaptors.




Engine type	Switch position	Dial
247	LOW	85

- 4. Crank engine.
- A. Indicator lamp lights: Brake light coil output is up to specifications. Repeat test at least three (3) times to verify reading and consistency.
- B. Indicator lamp does not light: Lighting coil is faulty.

3. BRAKE LIGHT COIL OUTPUT

- 1. Disconnect wiring harness junction block at engine .
- 2. Connect tester leads as illustrated using two (2) harness adaptors.




Engine type	Switch position	Dial
247	LOW	85

- 4. Crank engine.
- A. Indicator lamp lights: Brake light coil output is up to specifications. Repeat test at least three (3) times to verify reading and check for consistency.
- B. Indicator lamp does not light: Brake light coil output is faulty.

TWO CYLINDER BREAKER POINTS ENGINE

4. GENERATOR COIL OUTPUT

- Disconnect blue/red and black wires from terminal (15) of P.T.O. side ignition coil. Disconnect the two (2) blue wires from terminal (1) of magneto side ignition coil. Make sure that neither connector touches the engine (ground).
- Connect tester P lead to blue/red and black wires previously disconnected. Connect N lead to a good engine ground.




3. Set tester switch and dial as follows:

Engine type	Switch position	Dial
248, 294	HIGH	75
343, 402, 440, 444, 503, 640	HIGH	80

- 4. Turn ignition key to ON position, disable cut-out button circuit then crank engine.
- A. Indicator lamp lights: Generator coil output is up to specifications. Repeat test at least three (3) times to verify reading and consistency.
- B. Indicator lamp does not light: Generator coil output is below specifications. This could be caused either by a faulty coil or breaker points.
- Repeat test with other side (blue wires). If test indicates good on magneto side wire, but not on the other, suspect faulty breaker points. If test indicates no output on either side, suspect either faulty generator coil or breaker points.

LIGHTING COIL OUTPUT

- NOTE: On some engine types covered by this test an additional lighting coil is connected in parallel with the main lighting coil; in this case, the test will determine if the whole assembly is working right or not. If test appears to be negative, each component must be checked separately.
- Disconnect wiring harness junction block at engine .
- Connect tester leads as illustrated using two (2) harness adaptors.




Engine type	Switch position	Dial
248, 294	LOW	80
343, 402, 440,	LOW	85
444, 503, 640	2011	

- 4. Crank engine.
- A. Indicator lamp lights: Lighting coil output is up to specifications. Repeat test at least three (3) times to verify reading and consistency.
- B. Indicator lamp does not light: Lighting coil is faulty.

6. BRAKE LIGHT COIL OUTPUT

- 1. Disconnect wiring harness junction block at engine .
- 2. Connect tester leads as illustrated using two (2) harness adaptors.




Engine type	Switch position	Dial
248, 294	LOW	80

- 4. Crank engine.
- A. Indicator lamp lights: Brake light coil output is up to specifications. Repeat test at least three (3) times to verify reading and consistency.
- B. Indicator lamp does not light: Brake light coil output is defective.

TWO CYLINDER ELECTRONIC IGNITION ENGINE

7. GENERATOR COIL OUTPUT

- Disconnect wire connectors from C.D.I. electronic boxes
- Using one (1) harness adaptor, connect tester P test lead to red wire of one of the two connectors removed from C.D.I. electronic boxes. Connect N test lead to ground (engine); do not use brown wire as ground.



Set tester switch and dial as follows:

Engine type	Switch position	Dial
354, 454	HIGH	40

- 4. Turn ignition key to **ON** position, disable cut-out button circuit then crank engine.
- WARNING: To prevent powerful electric shocks with engine running, do not touch any component related to electronic ignition system (ignition coil, high tension wire, wire harness, etc...)
- A. Indicator lamp lights: Generator coil output is up to specifications. Repeat test at least three (3) times to verify reading and consistency.
- B. Indicator lamp does not light: If trigger coil (no. 8) is positive, the problem is a faulty generator coil.
- WARNING: Do not touch tester P lead clip while cranking the engine. Also make sure that tester P lead clip does not contact any metallic object.

8. TRIGGER COIL OUTPUT

1. Disconnect electronic box connectors.


Magneto side: Connect tester P lead to white wire.

P.T.O. side: Connect tester P lead to white/red

wire.

Connect tester N lead to a good engine ground.

2. Set tester switch and dial as follows:




Engine type	Switch position	Dial
354, 454	LOW	50

- Turn ignition key to ON position, disable cut-out buton circuit then crank engine.
- WARNING: To prevent powerful electric shocks with engine running, do not touch any component related to electronic ignition system (ignition coil, high tension wire, wire harness, etc...)
- A. Indicator lamp lights: Trigger coil output is up to specifications. Repeat test at least three (3) times to verify reading and check for consistency.
- B. Indicator lamp does not light: The problem is a faulty trigger coil.
- NOTE: If no output is indicated on trigger coil, carefully inspect the trigger ground connection wire connected to C.D.I. electronic box retaining screw. Clean and tighten connection then repeat test.

9. LIGHTING COIL OUTPUT

- 1. Disconnect wiring harness junction block at engine .
- 2. Connect tester leads as illustrated using two (2) harness adaptors.



Engine type	Switch position	Dial
354, 454	LOW	80

- 4. Crank engine.
- A. Indicator lamp lights: Lighting coil output is up to specifications. Repeat test at least three (3) times to verify reading and consistency.
- B. Indicator lamp does not light: Lighting coil is faulty.

ELECTRIC STARTER


Refer to the 1978 Bombardier Shop Manual.





BATTERY

Refer to the 1978 Bombardier Shop Manual.



ALTERNATOR

Refer to the 1978 Bombardier Shop Manual.

CAB

Models covered in this section:

1979: Elan

Spirit

Citation

Mirage

Olympique

Nuvik

Everest / Futura

Blizzard 7500 / Cross Country

Super Sonic / Cross Country


Blizzard 5500 / Grand Prix Special

Blizzard 9500


Alpine 640 ER

Elite 450 LC (winshield installation only, cab and


frame, refer to section 06-02 Frame).



(CAB), PAGE 2 (SUPPLEMENT) 1979




(SUPPLEMENT) 1979 (CAB), PAGE3





- 1. Cab
- 2. Cabin Latch Bracket (2)
- 3. Rivet (8)
- 4. Hand lever (2)
- 5. Washer (2)
- 6. Spring Washer (2) 7. Hook (2)
- 8. Washer (4)
- 9. Nut (2)
- 10. Air Intake Duct
- 11. Washer (4)
- 12. Rivet (4)
- 13. Side Decal Set
- 14. Stripe 206" (5233 mm) (AR)
- 15. Identification Label
- 16. Ski-Doo Label (2)

- 17. Felt Strip 5.5" (140 mm) (AR)
- 18. Retainer Cable
- 19. Washer (2)
- 20. Screw
- 21. Rivet
- 22. Hinge
- 23. Rivet (5)
- 24. Retainer Plate
- 25. Nut (2)
- 26. Windshield
- 27. Windshield Trim (AR)
- 28. O'Ring (7)
- 29. Acoustic Foam (AR)
- 30. Washer
- 31. Rubber Washer

SECTION 06 SUB-SECTION 01 (CAB)








- 2. Reinforcement
- 3. Rivet (6)
- 4. Cabin Latch Bracket (2)
- 5. Rivet (8)
- 6. Hand Lever (2)
- 7. Washer (2)
- 8. Spring Washer (2)
- 9. Hook (2)
- 10. Washer (4)
- 11. Nut (2)
- 12. Acoustic Foam (Heat Shield)
- 13. Plug (Dash Board) (2)
- 14. Decal (Meter Plug) (2)
- 15. Stripe 160" (4064 mm) (AR)
- 16. Stripe (2)


- 18. Moto-Ski Label
- 19. Acoustic Foam (AR)
- 20. Retainer Cable
- 21. Rivet
- 22. Washer
- 23. Lockwasher
- 24. Screw
- 25. Spring
- 26. Windshield
- 27. Windshield Trim (AR)
- 28. O'Ring (4)
- 29. Nut (Cabin Hinge) (2)
- 30. Machine Screw (2)
- 31. Speed Nut (2)




Everest / Futura


		340	400	440	444			340	400	440	444
1	. Cab	1	1	1	1	21	Tachometer with Fuse				
	Cabin Latch	2	2	2	2	04.	0.1 Ampere			7	1
	Machine Screw	2	2	2	2	35	Packing			2	2
	Washer	16	16	16	10		Plate			2	2
	Bushing	2	2	2	2		Case Holder			2	2
	R.H. Stopper	1	1	1	7		Lock Washer			4	4
D.	L.H. Stopper	1	7	1	7		Wing Nut			4	4
7	R.H. Spring	1	7	1	7		Flexible Shaft			7	7
/.	L.H. Spring	1	1	1	1		Angle Drive			1	1
Q	Nut	14	14	14	8		Cable Branch Key			7	1
	Machine Screw	2	2	2	2		Washer			1	1
	Hinge Assembly	7	1	1	1		Bulb			2	2
	Machine Screw	4	4	4	4		Fuse 0.1 Ampere			1	1
	Side Louvre	4	4	2	4		Fuse Holder Without			1	
12.	Plate			-	2	40.	Fuse			1	1
12	Square Washer	2	2	5	5	17	Tie Rap	AR	AR	AR	AR
	Rivet	8	8	14	14		Clip	4	4	7	7
	Grill	1	1	1	1		Retainer Cable	1	1	7	1
	Duct Assembly	1	1	1	1		Spring	1	1	1	7
	R.H. Side Duct	1	7	7	1		Washer	1	7	2	2
17.	L.H. Side Duct	1	1	7	1		Lock Washer	1	1	4	1
18	Intake Grill R.H.	1	1	7	1		Screw	1	1	1	1
10.	Intake Grill L.H.	1	1	1	1		Side Decal	1	1	1	,
10	Washer	2	2	2	2		Stripe 150" (3810 mm)	AR	AR	AR	
	R.H. Grill	1	1	1	1		Mirror	An	An	An	7
	L.H. Front Baffle	1	1	1	-1		Palnut				6
	L.H. Grill	1	1	1	+		Upper Dash Decal				1
	Rivet	2	2	2			Lower Dash Decal				7
	Acoustic Foam	AR	AR	AR	AR		Label				7
	Identification Label	1	1	1	1		Temperature gauge				7
	Side Decal Set	1	1	1	1		Bulb				7
	Label	2	0	7	2		Packing				4
	Dash Panel Decal	1	2	2	4		Holder				1
	Meter Plug	2	2	1			Washer				2
		2	2				Lock Washer				2
	Decal Windshield			,			Nut				2
	Windshield	1	1	1	10		Decal "Eagle"			7	1
	Windshield Trim	AR	AR	AR	AR	00.	Decai Eagle			7	1
33.	Speedometer			1	1		API as required				
							AR: as required				

(SUPPLEMENT) 1979




(CAB), PAGE 10 (SUPPLEMENT) 1979





- 1. Cab
- 2. Cabin Latch (2)
- 3. Rivet (12)
- 4. Cab Reinforcement R.H. Cab Reinforcement L.H.
- 5. Hinge
- 6. Nut (2)
- 7. Foam (AR)
- 8. Dash Decal
- 9. Bombardier Label
- 10. Stripe 365" (9271 mm) (AR)
- 11. Side Decal Set
- 12. Ski-Doo Label (2)
- 13. Identification Label
- 14. Compte-tours
- 15. Fuse Holder
- 16. Fuse 0.1 Ampere
- 17. Speedometer
- 18. Packing (2)
- 19. Plate (2)
- 20. Case Holder (2)
- 21. Lock Washer (4)
- 22. Wing Nut (4)

- 23. Flexible Shaft
- 24. Angle Drive
- 25. Cable Branch Key
- 26. Washer
- 27. Bulb (2)
- 28. Temperature Gauge
- 29. Packing
- 30. Holder
- 31. Washer (2)
- 32. Lock Washer (2)
- 33. Nut (2)
- 34. Bulb 12V/2W
- 35. Retainer Cable
- 36. Washer (2)
- 37. Lock Washer
- 38. Screw
- 39. Spring
- 40. Rivet
- 41. Windshield
- 42. Windshield Trim
- 43. O'Ring (8)
- 44. Screw (2)
- 45. Speed Nut (2)




- 1. Cab
- 2. Cabin Latch Bracket (2)
- 3. Rivet (16)
- 4. Hand Lever (2)
- 5. Washer (2)
- 6. Spring Washer (2)
- 7. Hook (2)
- 8. Washer (2)
- 9. Nut (2)
- 10. Aphonic Foam (AR)
- 11. Ski-Doo Label (2)
- 12. Identification Label
- 13. Filler Pipe Grommet
- 14. Windshield
- 15. O'Ring (11)
- 16. Windshield Trim (AR)
- 17. Console
- 18. Stud Plate (2)
- 19. Nut (6)
- 20. Machine Screw (4)
- 21. Washer (4)
- 22. Nut (4)
- 23. Machine Screw (2)


- 24. Washer (2)
- 25. Louvre
- 26. Rivet (5)
- 27. Air Deflector
- 28. Rivet (5)
- 29. Louvre R.H. Louvre L.H.
- 30. Door
- 31. Hinge
- 32. Threaded Screw
- 33. Latch
- 34. Pin
- 35. Rubber Spacer
- 36. Plastic Nut
- 37. Cab Trim (29" 736 mm) (AR)
- 38. Bombardier Label
- 39. Upper Column
- 40. Screw (2)
- 41. Nut
- 42. Shifting Label
- 43. Washer (5)
- 44. Washer (3)

HEADLAMP BEAM AIMING

Place the vehicle on a flat surface 7.6 m (25') from a wall or screen.



With the suspension correctly adjusted, the rider seated on the vehicle and the high beam ON (engine must be running on manual start models), check that the center of the high intensity zone of the high beam is 50 mm (2") below the horizontal line of the headlamp height.



To adjust, on vehicles so equipped, remove the headlamp chrome ring, turn the upper or lower adjusting screws to obtain the desired beam position.

BULB REPLACEMENT

If headlamp is burnt, tilt cab, unplug the connector from the headlamp. Remove the rubber boot and unfasten the bulb retainer clips. Detach the bulb and replace. If the taillight bulb is burnt, expose the bulb by removing red plastic lens. To remove, unscrew the two (2) Phillips head screws. Verify all lights after replacement.

CAB MAINTENANCE

Clean the vehicle thoroughly, removing all dirt and grease accumulation.



CAUTION: Plastic alloy components such as fuel tank, windshield, cab, etc., can be cleaned using mild detergents or isopropyl alcohol. Do not use strong soaps, degreasing solvents, abrasive cleaners, paint thinners, etc.

Inspect cab and repair damage. Repair kits are available at your authorized dealer.



NOTE: Apply wax on glossy finish of cab only. Protect the vehicle with a cover to prevent dust accumulation during storage.



CAUTION: If for some reason the snowmobile has to be stored outside it is necessary to cover it with an opaque tarpaulin. This caution will prevent the sun rays affecting the plastic components and the vehicle finish.

DECAL

To remove a decal, pull it off.

Clean the surface.

Apply liquid soap on the new decal. Position the decal and pass a sponge over it to remove air bubbles and water. Allow to air dry.

SHEET MOLDED COMPOUND


To repair cabs made of sheet molded compound, use appropriate resin compound.

(CAB), PAGE 14

WINDSHIELD INSTALLATION

Elan

- Peel off protective film from the new windshield and install windshield trim. Insert anchor tabs into holes of windshield. Install tabs in every retaining holes at the exception of the front center hole.
- Bend each tab in the middle until ends meet. Lubricate rubber strip with liquid soap. Install strip into cab channel. Position windshield in cab channel then from within the cab, pull and fully open anchor tabs. Work from center, outward.



Olympique, Everest, Futura

- Peel off protective film from the new windshield.
- Position windshield on cab then push down until tabs are locked in their holes.
- Install windshield trim on outer edge.

Elite

- Rebore the windshield retaining holes to 17/64".
- Align the windshield in position (in order to have the windshield deflector pleat on each side in line with the body side).
- Mark the body, and drill 17/64" holes. Secure the windshield in place.
- Install windshield trim on outer edge.
- Install the hood stopper in place by drilling a 1/8" hole in the center of the windshield at exactly 23 mm (9") from bottom edge of windshield and push the hood stopper in place.

Citation, Spirit, Blizzard 7500/Cross Country, Super Sonic/Cross Country


- Peel off protective film from the new windshield and install windshield trim.
- Position windshieldd on cab then push tabs in their slots. Lock in place using the "0" rings supplied in kit.

Nuvik, Blizzard 5500, Grand Prix Special, Blizzard 9500, Mirage


- Peel off protective film from the new windshield.
- Position windshield on cab then push until tabs are fully inserted into cab slots. Lock windshield tabs in position using the "O" rings supplied in kit.
- Using the windshield holes as a guide, drill 7/32" dia. holes through cab. Install the two (2) retaining bolts and the two (2) push nuts.
- Install windshield trim on outer edge,

Alpine


- Peel off protective film from the new windshield.
- Position windshield on cab then push until tabs are fully inserted into cab slots. Lock windshield tabs in position using the eleven (11) "O" rings supplied in kit (install two (2) "O" rings on outer tabs.)









1979 (SUPPLEMENT) (FRAME), PAGE 1









	340	400	440	444		340	400	440	444
1.2.3. Frame	1	1	1		49. Open Barrel				2
Frame (With Radiators)				1	50. Hair Pin				1
2. Bottom Plate	7	7	1	1	51. Cover				1
3. Footrest R.H.	1	1	1	7	52. Heat Shield				1
Footrest L.H.	1	1	1	1	53. Carriage Bolt				2
4. Steel Pop Rivet	55	55	55	55	54. Wing Nut	1.0.20		1.2	2
5. Steel Pop Rivet	8	8	8	8	55. Stripe 72" (1828 mm)	AR	AR	AR	1
6. Bumper R.H.	1	1	7	1	AD:				
Bumper L.H.	1	7	1	7	AR: as required				
7. Rubber Bumper	7	1	1	1					
8. Screw	1	7	1	1					
9. Nut	9	9	9	9					
10. Cab Protector R.H.	1	1	1	1					
Cab Protector L.H.	1	1	1	1					
11. Cab Sealer	2	2	2	2					
12. Clip (Cab Sealer)	12	12	12	12					
13. Trim 4" (102 mm) R.H.	AR	AR	AR	AR					
14. Washer	6	6	6	6					
15. Washer	12	12	12	10					
16. Nut	14	14	14	14					
17.19. Front Handle	1	1	1	1					
18.19. Rear Bumper	1	1	1	1					
19. Grip	2	2	2	2					
20. Screw	6	6	6	6					
21. Snow Guard	1	1	1	1					
22. Pop Rivet	4	4	4	4					
23. Tool Box	1	1	1						
24. Felt Strip 1.5" (38 mm)	AR	AR	AR						
25. Cup	2 2 2	2 2 2	2 2 2						
26. Lockwasher	2	2	2						
27. Screw	2								
28. Cover	1	1	1	6					
29. Latch Bracket R.H.	1	1	1	7					
Latch Bracket L.H.	1	1	1	1					
30. Carriage Bolt	4	4	4	4					
31. External Tooth									
Lockwasher	4	4	4	4					
32. Reflector	2	2	2	2					
33. Decal	2	2	2	2					
34. Decal	0		0	2					
35. Label	2	2	2						
36. Seat	1	1	1	1					
37. Leatherette	1	1	1	1					
38. Speed Nut	2	2	2	2					
39. Seat Belt	1	1	1	1					
40. Pin	2	2	2	2					
41. Cap	1	1	1						
42. Protector R.H.	1	1	7	1					
Protector L.H.	1	1	1	1					
43. Tool Box				1					
44. Bracket (Spark Plug)				1					
45. Rivet				2					
46. Washer				2					
47. Rivet				2 2 2 AR					
48. Wire 4" (102 mm)				AR					

1979 (SUPPLEMENT) (FRAME), PAGE 5


Blizzard 5500 **Grand Prix Spécial** Bazzard 27 GPs 1. Frame 2. Cabin Guide (2) 3. Rivet (4) 4. Cab Seat 3.8" (97 mm) (AR) 5. Cap (drive pulley) 6. Plug (2) 7. Cab Seal (2) 8. Screw (2) 9. Washer (6) 10. Nut (10) 11. Rear Bumper 12. Grip (AR) 21. Seat 13. Screw (4) 22. Seat Cover (Leatherette) 14. Clip (3) 23. Speed Nut (2) 15. Clip 24. Snow Guard 16. Tool Box 25. Rivet (4) 17. Rubber Spacer (3) 26. Reflector (2) 18. Washer (3) 27. Frame Decal (2) 19. Rivet (3) 20. Retainer AR: as required


(FRAME), PAGE 6 1979 (SUPPLEMENT)






		Blizzard 7500 Super Sonic	Cross Country
1.	Frame (With Radiators)	1	1
	Bottom Plate	1	1
	Rivet	44	44
	R.H. Footrest	1	
	L.H. Footrest	1	1
5	Trim 22" (559 mm)	AR	AR
	Snow Guard	1	1
	Rivet	4	4
	Reflector	2	2
	Frame Decal	2	2
	Seat Seat	2	1
	Leatherette	1	7
	Speed Nut	2	2
	Washer	2 2	2
	Nut	6	6
	Tool Box Bracket	1	1
	Tool Box Bracket	1	1
	Internal Tooth Lockwasher		2
	Screw	2	2
	Tool Box	1	1
	Carriage Bolt	2	2 1 2 2 2
	Washer	2 2	2
	Wing Nut	2	2
	Cover	1	1
	Hinge Pin	2	2
	Lock	7	1
	27. Rear Bumper	7	1
	Grip	7	1
	Screw	4	4
	Clip	3	3
	Clip	2	2
	Stripe 96" (2439 mm)	AR	AR
	Exhaust Grommet	7	1
	Exhaust Ring	1	1
	Rivet	3	3
	Heat Insulator	1	1
	Carriage Bolt	2	2
	Speed Nut	3	
38.	Rubber Spacer	3	<i>3</i>
39.	Heat Shield	7	1
	Wing Nut	3	3
41.	"L" Bracket	1	1
	Screw	1	1
	Screw	1	1
	Washer	2	1
	Nut	1	1
	Frame Decal	2	2
	Frame Decal Cross Country		2 2 1
	Protector Band		7








- 1. Bottom Plate
- 2. Plastic Sealer 7" (178 mm) (AR)
- 3. Body Moulding
- 4. Rivet (4)
- 5. Rivet (10)
- 6. Tubular Rivet (14)
- 7. Deflector
- 8. Acoustic Foam (AR)
- 9. Front Bumper
- 10. Machine Screw (4)
- 11. Nut (4)
- 12. Screw (2)
- 13. Nut (2)
- 14. Side Guard (20 1/2" Long) (521 mm) (2) Side Guard (27 3/16" Long) (691 mm) (4)
- 15. Rivet (16)
- 16. Rubber Rib 160" (4064 mm) (AR)
- 17. Foot Rib Stop (12)
- 18. Rivet (12)
- 19. Grille
- Grille (Close)
- 20. Attach Bracket
- 21. Retainer Pin
- 22. Cotter Pin (2)
- 23. Screw
- 24. Nut
- 25. Hitch Plate
- 26. Pin
- 27. Machine Screw (5)
- 28. Cushion (2)
- 29. Latch Bracket (2)
- 30. Washer (4)
- 31. Nut (5)
- 32. Reflector (2)
- 33. Clip
- 34. Washer Head Screw
- 35. Seat
- 36. Leatherette
- 37. Padded Backrest
- 38. Hinge (2)
- 39. Rivet (6)
- 40. Machine Screw (6)

AR: as required

1979 (SUPPLEMENT) (FRAME), PAGE 13



- 1. Upper Body
- 2. Trunk Door
- 3. Hood
- 4. Hinge (4)
- 5. Machine Screw (8)
- 6. Washer (8)
- 7. Nut (12)
- 8. Square Washer (8)
- 9. Rivet (8)
- 10. Front Latch Bracket
- 11. Rivet (2)
- 12. Plate (2)
- 13. Square Washer (4)
- 14. Rivet (21)
- 15. Knob (2)
- 16. Spring Washer (2)
- 17. Hook (2)
- 18. Washer (17)
- 19. Nut (13)
- 20. Rear Latch Bracket
- 21. Screw
- 22. Nut
- 23. Stand Rod
- 24. Cotter Pin
- 25. Stand Rod Retainer
- 26. Metal Screw
- 27. Grommet (6)
- 28. Seat Belt
- 29. Rivet (33)
- 30. Seat Backet (4)
- 31. Console Cover
- 32. Seat (2)
- 33. Leatherette Seat
- 34. Plate (4)
- 35. Access Plate (2)
- 36. Machine Screw (8)
- 37. Backrest (2)
- 38. Leatherette (Backrest)
- 39. Speed Nut (4)
- 40. Washer (10)
- 41. Wing Nut (4)
- 42. Louvre (2)
- 43. Push Nut (12)
- 44. Trim (AR)
- 45. Grommet (2)
- 46. Foam (AR)
- 47. Side Decal Set (Front)
- 48. Front Reflector (2)
- 49. Ski-Doo Label (2)
- 50. Decal Trunk Door (2)
- 51. Elite Label
- 52. Decal (2)
- 53. Elite Label (2)
- 54. Side Decal Set (Rear)
- 55. Rear Deflector (2)
- 56. Label 450 L/C
- 57. Dash Decal

- 58. Bombardier Label
- 59. Windshield
- 60. Trim (AR)
- 61. Machine Screw (14)
- 62. Nut (8)
- 63. Body Retainer (22)
- 64. Side Bumper (2)
- 65. Rear Bumper
- 66. Rivet (55)
- 67. Vinyl Trim
- 68. Rivet (2)
- 69. Roll Bar
- 70. Screw (2)
- 71. Mirror
- 72.73. Front Handle
- 73. Grip
- 74. Screw (2)
- 75. Lock Washer (2)
- 76. Washer (4)
- 77. Washer (2)
- 78. Cover (Drive Axle Access) (2)
- 79. Grill
- 80. Machine Screw (4)
- 81. Hitch Plate
- 82. Screw (8)
- 83. Fuel Pump Bracket
- 84. Screw
- 85. Washer (2)
- 86. Nut
- 87. Tool Box
- 88. Cover
- 89. Floor
- 90. Footrest
- 91. Footrest Guard (2)
- 92. Rivet (2)
- 93. Rubber Rib 31.5" (801 mm) (AR)
- 94. Foot Rib Stop (4)
- 95. Rivet (4)
- 96. Trunk Shield
- 97. Machine Screw (6)
- 98. Shifting Label
- 99. Rivet (8)

FRAME

FRAME WELDING

Steel frame:

- Electric Welding

- Amperage: 70-110 Amp.

Voltage: 20-24 voltsRod: E-7014 (3/32")

Aluminium frame: (refer to specialized welding shop)


Argon-oxygen/acetylen welding

- Rod: ER-4043 (3/32")

V

CAUTION: When electrical welding is to be performed anywhere on the vehicle, unplug the multiple connector at the electronic box prior to connecting the welding wire to the vehicle. This will protect the electronic box against damage caused by flowing current when welding.

NOTE: This procedure applies to all electronic ignition systems.



FRAME CLEANING

Clean frame. For aluminum frame use only "Aluminum cleaner" and follow instructions on container. (Dursol cleaner or equivalent).

Touch up all metal spots where paint has been scratched off. Spray all bare metal parts of vehicle will metal protector.

SEATS


Elite model

To remove the backrest, unscrew the two (2) wing nuts located in the engine compartment.


TOOLS


ITEM	USE	APPLICABLE TO		
Dial indicator (T.D.C. gauge). 414 1047 00	Engine timing, to determine T.D.C.	All engine types.		
Tone timer. 414 0990 00	Engine timing (static).	All engine types.		
Circuit tester (continuity light). 414 0122 00	Engine timing (static). Continuity tests.	All engine types.		
Magneto ignition analyser (Merc-O-Tronic). 414 0192 00	Engine electrical components tests.	All engine types.		

(SUPPLEMENT) 1979 (TOOLS), PAGE 1



(TOOLS), PAGE 2 (SUPPLEMENT) 1979





SECTION 07 (TOOLS)

Starter gear puller. 420 876 145 Twin cylinder electric start engines. Starter gear puller Connecting rod holder. 420 977 900 All single cylinder models. Connecting rod Cylinder aligning tool. 420 876 170 Twin cylinder engine types. Cylinder aligning tool 420 842 160

Magneto housing holder. 420 876 350		Twin cylinder engine types.
Magneto housing holder. All twin cylinders F.C. Except 248, 294 420 876 080	Puller	Twin cylinder engine types.
420 876 085 Bearing puller. 247 engine 420 976 350 All twin cylinders 420 876 065	To remove magneto ring from engine	All engines.
Bearing simulator. 305, 343, 402, 440 engine 420 876 155 640 engine 420 876 160 248, 294 420 876 380	When adjusting crankshaft play.	All engine types.

(TOOLS), PAGE 6 (SUPPLEMENT) 1979

Puller assembly. 420 876 296 With 145 mm screw.



Screw

420 940 755 M16 x 1.5 x 145

420 841 200 M8 x 70

420 840 680 M8 x 40





Ring for puller ball bearing. 420 977 480 All models since 1971 Except 292, 337, 640, 641, 775 420 977 490 Since 1971 292, 337, 640, 641, 775




Ring for roller bearing 420 276 020 Since 1971 All models except: 248, 249, 292, 294, 337, 640, 641, 775 420 977 470 Since 1971 292, 337, 640, 641, 775 420 876 330 Since 1971 248, 249, 294




Distance ring for puller

420 876 560




All engine types.



Armature plate contact set pivot pin remover (socket). 420 876 530	To remove contact set pivot pin from armature plate.	All engine types using breaker point type ignition.
Rotary valve shaft puller. 420 876 485 A B C C	To remove rotary valve shaft assembly from crankcase.	RV engines up to serial no. 3095 551
Rotary valve shaft pusher. 420 876 610		RV engines serial no. 3095 552 on up.
Insertion jig for oil seal. 420 876 505	To install oil seal.	RV engines up to serial no. 3095 551
Insertion jig for oil seal. 420 876 600	To install oil seal	RV engines serial no. 3095 552 and up.

SECTION 07 (TOOLS)



TECHNICAL DATA LIST

TRACK TENSION SPECIFICATIONS (SLIDE SUSPENSION)

TRACK TENSION SPECIFICATIONS (BOGIE WHEEL SUSPENSION)

TRACK SPECIFICATIONS

VEHICLE MODEL/DRIVE BELT NUMBER

DRIVE PULLEY SPECIFICATIONS

DRIVEN PULLEY SPRING TENSION

PULLEY ALIGNMENT SPECIFICATIONS

SPROCKET AND CHAIN SPECIFICATIONS

STEERING SYSTEM TORQUE SPECIFICATIONS

SKI SYSTEM TORQUE SPECIFICATIONS

TOLERANCE AND WEAR LIMIT — ENGINES

IGNITION TIMING SPECIFICATIONS


CARBURETOR SPECIFICATIONS

BOSCH SPARK PLUG CHART


IGNITION GENERATING COIL, TRIGGER COIL AND LIGHTING COIL RESISTANCE CHART

BOMBARDIER IGNITION TESTER DIAL POSITIONS

METRIC INFORMATION CHART




TRACK TENSION SPECIFICATIONS (SLIDE SUSPENSION)




		1979
CITATION	300	
MIRAGE	300	10
OLYMPIQUE	340	13 mm (1/2")
NUVIK	340	
EVEREST	340, 400	10 50 10 100
FUTURA	440, 444 LC	13 mm (1/2")
BLIZZARD 5500		3.50
GRAND PRIX SE	PECIAL	13 mm (1/2")
BLIZZARD 7500/0	CROSS COUNTRY	
SUPER SONIC/C	ROSS COUNTRY	13 mm (1/2")
BLIZZARD	9500	13 mm (1/2")
ELITE	450 LC	13 mm (1/2")


TRACK TENSION SPECIFICATIONS (BOGIE WHEEL SUSPEN-SION)



		1979
ELAN and SPIRIT	250	35 mm (1 3/8'')
ALPINE	640 ER	*57 mm (2 1/4")




*Between top inside edge of track and center of second bogie wheel set retaining bolt (from rear).




1979 TRACK SPECIFICATIONS


CLEAT AND GUIDE ARRANGEMENT




TYPE 1: Narrow insert.




TYPE 2: Narrow insert with shoulder TYPE 3: Narrow guide with shoulder.






TYPE 4: Wide guide (large track hole).



TYPE 5: Wide guide (large track hole).


	TYPE	TRACK PART NUMBER	WIDTH	LENGTH (interior)
ELAN	1	570 0006 00	38.1 cm (15")	289.6 cm (114")
SPIRIT	1	570 0085 00	38.1 cm (15")	289.6 cm (114")
CITATION	2	570 0069 00	38.1 cm (15")	289.6 cm (114")
MIRAGE	2	570 0068 00	38.1 cm (15")	289.6 cm (114")
NUVIK	4	570 0056 00	38.1 cm (15")	304.8 cm (120")
OLYMPIQUE	5	570 0071 00	38.1 cm (15")	304.8 cm (120")
EVEREST	4	570 0045 00	41.9 cm (16 1/2")	314.9 cm (124")
FUTURA	4	570 0060 00	41.9 cm (16 1/2")	314.9 cm (124")
BLIZZARD 5500	2	570 0086 00	38.1 cm (15")	289.6 cm (114")
GRAND PRIX SPECIAL	2	570 0068 00	38.1 cm (15")	289.6 cm (114")
BLIZZARD 7500/CROSS COUNTRY	2	570 0079 00	41.9 cm (16 1/2")	289.6 cm (114")
SUPER SONIC/CROSS COUNTRY	2	570 0080 00	38.1 cm (15")	289.6 cm (114")
BLIZZARD 9500	2	570 0088 00	38.1 cm (15")	289.6 cm (114")
ALPINE 640 ER	1	570 0014 00	38.1 cm (15")	353 cm (139")
ELITE 450 LC	4	570 0056 00	38.1 cm (15")	304.8 cm (120")



VEHICLE MODEL/DRIVE BELT NUMBER

		1979	WIDTH
ELAN and SPIRIT		570 0411	30 mm (1 3/16")
OLYMPIQUE NUVIK CITATION MIRAGE		414 2327	33 mm (1 5/16'')
EVEREST	340	414 2327	33 mm (1 5/16")
EVEREST FUTURA	400, 440	414 2417	33 mm (1 5/16'')
EVEREST FUTURA	444 LC	414 2277	33 mm (1 5/16'')
BLIZZARD GRAND PRIX SPE		414 2277	33 mm (1 5/16'')
BLIZZARD 7500/CF SUPER SONIC/CR		414 2277	33 mm (1 5/16'')
BLIZZARD	9500	414 3758	33 mm (1 5/16")
ALPINE	640 ER	414 2277	33 mm (1 5/16'')
ELITE	450 LC	414 2277	33 mm (1 5/16")

NOTE: For longer belt life, always reinstall the drive belt in the same direction of rotation.



TYPE CUP COUNTERWEIGHT ROLLER SPRING AND LENGTH CLUTCH RETAINING NUMBER IDENTIFICATION IDENTIFICATION COLOR PART **ENGAGEMENT** BOLT NUMBER TORQUE 11.5 mm (.060") R.P.M. N•m (ft-lbs) **ELAN and SPIRIT** 250 R.R.S. 504 2186 E4 Nylon 31.75 (1 1/4) 414 2580 Bronze 76.7 (3.020) 61 (45) 2000-2200 250 Deluxe **ELAN** R.R.S. 504 2186 D2 Nylon 31.75 |1 1/4| 414 2581 Blue 77.7 (3.060) 3300-3500 B1 (45) CITATION and MIRAGE R.S.S. 504 2289 A3S Fiber 34.04 (1.340) 414 1967 Light blue 119.1 (4.688) 3900-4300 B5 (63) **OLYMPIQUE** and **NUVIK** R.S.S. 504 2289 C3L Fiber 34.04 (1,340) 414 1967 Light blue 119.1 (4.688) 3800-4100 B5 (63) 340 400 **EVEREST** R.S.S. 504 2289 Fiber 34.04 (1.340) 414 1987 Light blue 119.1 (4.688) 3800-4100 C3L 85 (63) **FUTURA** 440 **EVEREST and FUTURA** R.S.S. 504 2289 C4L Fiber 34.04 (1.340) 414 1966 Pink 122.3 (4.813) 2900-3200 85 (63) 444 LC **EVEREST and FUTURA** R.S.S. 504 2289 C7L Fiber 34.04 (1.340) 414 1995 Yellow 100 (3.938) 3400-3700 85 (63) BLIZZARD 5500/GRAND PRIX SPECIAL H.S.S. 504 2289 Fiber 34.04 (1.340) 414 1967 Light blue 3200-3500 C8M-H 119.1 (4.688) 85 (63) **BLIZZARD 7500/SUPER SONIC** R.S.S.R. (1) 504 2398 A3S Steel 15.87 (.625) 414 3412 Brown 76.9 (3.030) 4200-4500 85 (83) BLIZZARD CROSS COUNTRY/ R.S.S.R. (2) 504 2419 A6S Aluminum 15.49 (.610) 414 1967 Light blue 119.1 (4.688) 3800-4000 85 (63) SUPER SONIC CROSS COUNTRY **BLIZZARD 9500** R.S.S.R. (2) 504 2419 A3S Aluminum 15,97 (.625) 414 2610 Violet 73.66 (2.90) 3800-4100 85 (63) ELITE 450 LC 504 2374 C8 414 1967 Light blue 85 (63) A.S.S. 119.1 (4.688) 3200-3500 ALPINE R.S.S.B. 504 2302 C8 Double Fiber 34.04 (1.340) 414 1966 Pink 122.2 (4.812) 2250-2400 118 (87)

R.S.S.: Roller square shaft R.R.S.: Roller round shaft


R.S.S.B.; Roller square shaft with bearing R.S.S.R.: Roller square shaft 3 ramps

1 Ramps no. 2406 (2) Ramps no. 2422

SECTION 08 SUB-SECTION 02-03

1979 DRIVE PULLEY

SPECIFICATIONS




DRIVEN PULLEY SPRING TENSION

1979	kg ± 1 (lbs ± 2)
ELAN/SPIRIT	3.6 (8)
CITATION/MIRAGE	3.6 (8)
OLYMPIQUE/NUVIK	3.6 (8)
EVEREST/FUTURA	3.6 (8)
BLIZZARD 5500/GRAND PRIX SPECIAL	5.9 (13)
BLIZZARD 7500/SUPER SONIC	5.9 (13)
CROSS COUNTRY	5.9 (13)
BLIZZARD 9500	5.9 (13)
ELITE 450 LC	5.9 (13)
ALPINE 640 ER	5.9 (13)




1979 PULLEY ALIGNMENT



- Dimension "X" must never exceed dimension "Y".
- Dimension "Y" can exceed dimension "X" by 1.6 mm (1/16").


	DIMENSIONS X and Y (offset)	NOMINAL DISTANCE (between pulleys)
ELAN and SPIRIT	33-35 mm (1 5/16" - 1 3/8")	44 mm (1 3/4")
OLYMPIQUE and NUVIK CITATION and MIRAGE EVEREST and FUTURA	33-35 mm (1 5/16'' - 1 3/8'')	36 mm (1 7/16'')
BLIZZARD 5500 and GRAND PRIX SPECI	AL (1) 33-35 mm (1 5/16" - 1 3/8")	35 mm (1 3/8")
BLIZZARD 7500 and SUPER SONIC	33-35 mm (1 5/16" - 1 3/8")	36 mm (1 7/16")
CROSS COUNTRY	33-35 mm (1 5/16" - 1 3/8")	36 mm (1 7/16")
BLIZZARD 9500	① 33-35 mm (1 5/16'' - 1 3/8'')	36 mm (1 7/16'')
ALPINE	33-35 mm (1 5/16" - 1 3/8")	44 mm (1 3/4")
ELITE 450 LC	33-35 mm (1 5/16" = 1 3/8")	41 mm (1 5/8")

① With a 1/16" shim between driven pulley and bearing flange. Refer to section 02.



1979 SPROCKET AND CHAIN SPECIFICATIONS


		SPROCKET UPPER/LOWER	CHAIN PITCH AND NUMBER OF LINKS
ELAN and SPIRIT	250	10/25	1/2" single, 62
ELAN	250 DELUXE	14/35	3/8" double, 84
CITATION/MIRAGE		17/33	3/8" double, 88
OLYMPIQUE/NUVIK	340	17/33	3/8" double, 88
EVEREST	340	16/34	3/8" double, 88
FUTURA	400	18/34	3/8" double, 90
EVEREST/FUTURA	440	21/38	3/8" triple, 94
EVEREST/FUTURA	444 LC	20/34	3/8" triple, 90
BLIZZARD 5500/GRAND F	RIX SPECIAL	21/38	3/8" triple, 68
BLIZZARD 7500/SUPER S	SONIC	19/38	3/8" triple, 92
CROSS COUNTRY		21/38	3/8" triple, 94
BLIZZARD	9500	19/40	3/8" triple, 68
ALPINE	640 ER	17/38	3/8" triple, 90
ELITE	450 LC	17/38	3/8" triple, 188



1979 STEERING SYSTEM TORQUE SPECIFICATIONS

	STEERING SYSTEM TYPE	HANDLEBAR RETAINING BOLT N•m (ft-lbs)	STEERING ARM TO SKI LEG N•m (ft-lbs)	TIE ROD END TO STEERING ARM N•m (ft-lbs)
ELAN and SPIRIT	1 (1978)		27 (20)	27 (20)
CITATION and MIRAGE	2 (1978)	===	42 (31)	27 (20)
OLYMPIQUE and NUVIK EVEREST and FUTURA	3 (1978)	-8-	42 (31)	27 (20)
BLIZZARD 5500 GRAND PRIX SPECIAL BLIZZARD 9500*	8 (1978)		42 (31)	27 (20)
BLIZZARD 7500 SUPER SONIC CROSS COUNTRY	5 (1978)		42 (31)	27 (20)
ALPINE	6 (1978)	42 (31)	42 (31)	*61 (45)
ELITE	7 (1978)	42 (31)	42 (31)	27 (20)

^{*}Ball bushing nut torque value.




1979 SKI SYSTEM TORQUE SPECIFICATIONS

	SKI SYSTEM TYPE	SPRING LEAF/ LEAF COUPLER RETAINING BOLT N•m (ft-lbs)	RUNNER SHOE NUT N•m (ft-lbs)	LEAF COUPLER TO SKI LEG
ELAN & SPIRIT ELAN DELUXE	1 2	.50 (37)	7 (5)	check tight-
CITATION & MIRAGE	3	50 (37)	14 (10)	hand to leg. Then (45 ft-lbs)
OLYMPIQUE & NUVIK EVERESt 340, FUTURA 400	4	50 (37)	14 (10)	move ski by hand to check easily on ski leg. Then tight- it to 61 N•m (45 ft-lbs),
EVEREST & FUTURA 440 & 444 LC	5		14 (10)	ve sk y on 61 N
BLIZZARD 7500/CROSS COUNTRY SUPER SONIC/CROSS COUNTRY	6		14 (10)	Tighten bolt, move s that it pivots easily o en locking nut to 61
ALPINE	7	50 (37)	14 (10)	ten b it pive
ELITE	8	50 (37)	14 (10)	Tighten bolt, I that it pivots e en locking nut
BLIZZARD 9500	9	small bolts main bolt 34 (25) 68 (50)	14 (10)	

*Assemble the ski to the ski leg, using water or liquid soap.

NOTE: Install the two machined bolts from inside the coupler; install and tighten the large bolt to 68 N•m (50 ft-lbs).




Install the new lock tabs and elastic stop nuts and torque to 34 N•m (25 ft-lbs).

Bend the lock tabs.

Secure the shock absorber to the ski leg using the retainer pin and cotter pin.


Repeat the procedure for the other ski.



TOLERANCES AND WEAR LIMIT — 1979 ENGINES

ENGINE TYPE	CYL. BORE (MIN STANDARD	I. NOMINAL) OVERSIZE	PISTON TO WALL CLEARANCE MINIMUM — MAXIMUM	MAXIMUM RING END GAP	MAXIMUM CRANKSHAFT END PLAY
247	69.5 mm (2.7362")		0.065 — 0.170 mm (.0025 — .0067")	0.20-0.40 mm (.008016'')	0.1 mm (.004'')
248	54.0 mm	54.5 mm	0.050 — 0.140 mm	0.15-0.35 mm	0.1 mm
	(2.159")	(2.1456")	(.0020 — .0055")	(.006014")	(.004")
294	57.0 mm	57,5 mm	0.050 — 0.140 mm	0.15-0.35 mm	0.1 mm
	(2.2441")	(2,2638'')	(.0020 — .0055'')	(.006014'')	(.004")
343	59.5 mm	60.0 mm	0.080 — 0.200 mm	0.15-0.35 mm	0.1 mm
	(2.3425")	(2.3622'')	(.0031 — .0079")	(.006014")	(.004")
354	59.5 mm (2.3425'')	59,75 mm (2.3524'')	0.080 — 0.200 mm (.0031 — .0079")	0.15-0.35 mm (.006014")	N.A.
402	64:5 mm	65.0 mm	0.070 - 0.180 mm	0.20-0:40 mm	0.1 mm
	(2.5394'')	(2.5590'')	(.00280071")	(.008016'')	(.004")
440	67.5 mm	68.0 mm	0.070 — 0.180 mm	0,20-0.40 mm	0.1 mm
	(2.6574")	(2.6771")	(.0028 — 0071")	(,008016")	(.004")
444	69.5 mm (2.7362")	69.75 mm (2.7461")	0.070 — 0.180 mm (.0028 = .0071)	0.20-0.40 mm (.008016'')	N.A.
454	67.5 mm (2.6575")	67.75 mm (2.6673'')	0,090 = 0.220 mm (,0035 = ,0087")	0.20-0.40 mm (,008-,016'')	N.A.
503	72.0 mm (2.8346'')	72.25 mm (2.8445'')	0.060 — 0.160 mm (.0024 — .0063")	0.20-0.40 mm (.008016'')	N.A.
640	76.0 mm	76.5 mm	0.070 — 0.180 mm	0.25-0.45 mm	0.1 mm
	(2.9921")	(3.0118")	(.0028 — .0071")	(.010018")	(.004")

N.A.: not applicable




1979 IGNITION TIMING SPECIFICATIONS

ENGINE TYPE	IGNITION TYPE	DIRECT MEASUREMENT B.T.D.C.	INDIRECT MEASUREMENT B.T.D.C.	EDGE CAP	
247	Breakers	3.98 mm ± 0.25 (.157" ± .010)	N.A.	6.6 mm ± 1.5 (.260" ± .060)	
248	Breakers	N.A.	2.29 mm ± 0.25 (.090" ± .010)	9.0 mm ± 2.0 (.354" ± .080)	
294	Breakers	N.A.	2.49 mm ± 0.25 (.098" ± .012)	9.0 mm ± 2.0 (,354" ± .080)	
343	Breakers	N.A.	2.46 mm ± 0.25 (.097" ± .010)	8.0 mm ± 2.0 (.315" ± .080)	
354	CD *	1,39 mm ± 0.25 (.055" ± .010)	N.A.	N.A.	
402	Breakers	N.A.	2.46 ± 0.25 (.097" ± .010)	8.0 mm ± 2.0 (.315" ± .080)	
440	Breakers	N.A.	3.30 mm ± 0.25 (.130" ± .010)	6.6 mm ± 1.5 (.260" ± .060)	
444	Breakers	2.35 mm ± 0.25 (,092" ± ,010)	N.A.	8.0 mm ± 2.0 (.315" ± .080)	
454	CD.	1.39 mm ± 0.25 (.055" ± .010)	N.A.	N.A.	
503	Breakers	2.07 mm ± 0.25 (.0081" ± 0.10)	N.A.	8.0 mm ± 2.0 (.315" ± .080)	
640	Breakers	N.A.	4.11 mm ± 0.25 (.162" ± .010)	6.6 mm ± 1.5 (.260" ± .060)	

N.A. not applicable

^{*} Stroboscopic timing at 6000 R.P.M.



CARBURETOR SPECIFICATIONS

MODEL		ENGINE TYPE	CARBURETOR TYPE	LOW SPEED ADJ, ± 1/8	SPEED R.P.M.
ELAN & SPIRIT ELAN	250 250 DL	247 248	Tillotson HR 173A Tillotson HR 172A	1 turn 1 turn +½ – 0	1800-2000 1800-2200
OLYMPIQUE & NUVIK CITATION & MIRAGE	340 300	343 294	Mikuni VM 30-91 Mikuni VM 30-104	1 1/2 turn 1 1/2 turn	1500-1800 1800-2000
EVEREST FUTURA	340 400	343 402	Mikuni VM 30-98 Mikuni VM 30-92	1 1/2 turn 1 1/2 turn	1500-1800 1500-1800
EVEREST FUTURA EVEREST	440 444 LC	440 444	Mikuni VM 34-165 Mikuni VM 34-150	2 turns	1500-1800 1500-1800
BLIZZARD 5500 GRAND PRIX SPECIAL		503	Mikuni VM 34-203	1 1/2 turn	1500-2000
BLIZZARD 7500/SUPER SONIC		354	Mikuni VM 34-184	1 1/2 turn	2800-3200
CROSS COUNTRY		354	Mikuni VM 34-199m	1 1/2 turn	1800-2000
BLIZZARD 9500		454	Mikuni VM 36-78	1 turn	1800-2000
ALPINE 640 ER		640	Tillotson HRM-7A	*1 1/8 + 1/4 -0	1500-1800
ELITE 450 LC		444	Mikuni VM 34-201	1 turn	1500-1800

^{*} High Speed = $1 \frac{1}{4} turn + \frac{1}{4} - 0$



MIKUNI CARBURETOR SPECIFICATIONS

YEAR	CARBURETOR	MAIN JET	MEEDLE.	NEEDLE JET	CUTAWAY Shine me	PILOT	
1979	VM 30-91	260	6DH2-3	159 Q-0	2.0	25	1 1/2 turn
1979	VM 30-92	220	6DH7-4	159 Q-0	3.5	45	1 1/2 turn
1979	VM 30-94	220	6DH4-3	159 P-2	2.0	30	1 1/2 turn
1979	VM 30-98	250	6F9-3	159 Q-2	3.5	35	1 1/2 turn
1979	VM 30-104	220	6DH4-3	159 P-2	2.0	30	1 1/2 turr
1979	VM 34-150	450	6EJ1-4	159 P-4	3.0	45	1 1/2 turn
1979	VM 34-165	320	6F9-3	159 P-6	3.0	35	2 turns
1979	VM 34-199	240	6F9-2	159 P-4	3.5	50	1 1/2 turn
1979	VM 34-199M	250	6F9-2	159 P-4	3.5	50	1 1/2 turr
1979	VM 34-201	370	6EJ1-3	159 P-2	2.5	30	1 turn
1979	VM 34-203	220	6DH2-3	159 P-4	3.0	35	1 1/2 turr
1979	VM 36-78	MAG PTO 300 280	6DH4-4	159 P-2	3.5	40	1 turn

Jet needle last digit indicates "E" clip position from top.
Ex.: 6HD2-3: 3rd

slot from top.

² Turning clockwise will enrich the mixture and counterclockwise will lean it.

1979 MAIN JET APPLICATION CHARTS

1979 CITATION — MIRAGE VM 30-104										
TEMPERATURE 0°C (0°F)	-45°C (-50)	-35°C (-30)	-25°C (-10)	-15°C (10)	0°C (30)	10°C (50)	20°C (70)	30°C (90)		
0 Sea level	250	240	230	220	220	210	200	190		
600 m (2,000)	240	230	220	210	210	195	185	180		
1,200 m (4,000)	230	220	210	200	190	185	175	165		
1,800 m (6,000)	210	210	195	190	180	170	165	155		
2,400 m (8,000)	200	195	185	175	170	160	150	145		
3,000 (10,000)	190	180	175	165	155	150	140	130		





	1979 OLYMPIQUE & NUVIK 340 VM 30-91										
TEMPERATURE 0°C (0°F) Altitude Meters (feet)	-45°C (-50)	-35°C (-30)	-25°C (-10)	-15°C (10)	0°C (30)	10°C (50)	20°C (70)	30°C (90)			
0 Sea level	290	280	270	260	260	250	240	230			
600 m (2,000)	280	270	260	250	240	230	220	210			
1,200 m (4,000)	270	260	250	240	230	220	210	195			
1,800 m (6,000)	250	240	230	220	210	200	195	185			
2,400 m (8,000)	240	230	220	210	200	190	180	170			
3,000 (10,000)	230	220	210	195	185	175	165	155			



1979 EVEREST 340 VM 30-98										
TEMPERATURE 0°C (0°F) Altitude Meters (feet)	-45°C (-50)	-35°C (-30)	-25°C (-10)	-15°C (10)	0°C (30)	10°C (50)	20°C (70)	30°C (90)	Needle & E clip position	
0 Sea level	280	270	260	250	240	230	220	210		
600 m (2,000)	270	260	250	240	230	220	210	200	6F9-3	
1,200 m (4,000)	250	240	230	230	220	210	200	190		
1,800 m (6,000)	240	230	220	210	200	195	185	175		
2,400 m (8,000)	230	220	210	200	190	180	170	160	6F9-2	
3,000 (10,000)	210	200	195	185	175	165	160	150		



	1979 FUTURA 400 VM 30-92											
TEMPERATURE 0°C (0°F) Altitude Meters (feet)	-45°C (-50)	-35°C (-30)	-25°C (-10)	-15°C (10)	0°C (30)	10°C (50)	20°C (70)	30°C (90)				
0 Sea level	250	240	230	220	220	210	200	190				
600 m (2,000)	240	230	220	210	210	195	185	180				
1,200 m (4,000)	230	220	210	200	190	185	175	165				
1,800 m (6,000)	210	210	195	190	180	170	165	155				
2,400 m (8,000)	200	200	185	175	170	160	150	145				
3,000 m (10,000)	190	180	175	165	155	150	140	130				



TEMPERATURE					119					
0°C (0°F)	-45°C (-50)	-35°C (-30)	-25°C (-10)	-15°C (10)	0°C (30)	10°C (50)	20°C (70)	30°C (90)	Needle & E clip position	Pilot Jet
Meters (feet)										
Sea level	360	350	330	320	310	300	290	280	- 6F9-3	35
000 m 2,000)	340	330	320	300	290	280	270	260		
,200 m 4,000)	320	310	300	290	280	270	250	240	6E0 2	20
,800 m 6,000)	310	300	280	270	260	250	240	230	6F9-2	30
,400 m 8,000)	290	280	270	260	240	230	220	210	650.1	25
(,000 10,000)	270	260	250	240	230	220	200	190	6F9-1	25



TEMPERATURE 0°C (0°F)	-45°C (-50)	-35°C (-30)	-25°C (-10)	-15°C (10)	0°C (30)	10°C (50)	20°C (70)	30°C (90)	Needle & E clip position
Meters (feet) O Sea level	460	440	430	410	400	380	370	350	
600 m (2,000)	440	420	410	390	380	360	350	330	6EJ1-3
1,200 m (4,000)	420	400	390	370	360	340	320	310	
1,800 m (6,000)	390	380	360	350	330	320	300	290	
2,400 m 8,000)	370	360	340	330	310	300	280	270	6EJ1-2
3,000 (10,000)	350	340	320	300	290	270	260	240	



1979				00 VM 34 SONIC 34		/M 34-199		
TEMPERATURE 0°C (0°F)	-45°C (-50)	-35°C (-30)	-25°C (-10)	-15°C (10)	0°C (30)	10°C (50)	20°C (70)	30°C (90)
0 Sea level	270	260	250	240	230	220	210	200
600 m (2,000)	260	250	240	230	220	210	200	195
1,200 m (4,000)	240	230	230	220	210	200	190	180
1,800 m (6,000)	230	220	210	200	195	185	180	170
2,400 m (8,000)	220	210	200	190	180	175	165	155
3,000 (10,000)	210	195	190	180	170	160	150	140



TEMPERATURE 0°C (0°F)	-45°C (-50)	-35°C (-30)	-25°C (-10)	-15°C (10)	0°C (30)	10°C (50)	20°C (70)	30°C
Altitude Meters (feet)								
0 Niveau de la mer	250	240	230	220	210	200	195	190
600 m (2,000)	240	230	220	210	200	195	185	175
1,200 m (4,000)	220	210	210	200	190	180	175	165
1,800 m (6,000)	210	200	195	185	180	170	160	155
2,400 m (8,000)	200	190	180	175	165	160	150	140
3,000 (10,000)	190	180	170	165	155	145	140	130




TEMPERATURE	1							
TEMPERATURE ° C (° F)	-45° C (-50)	-35° C (-30)	-25° C (-10)	-15° C (10)	0° C	10° C (50)	20° C (70)	30° C
ALTITUDE	PTO	PTO	PTO	PTO	PTO	PTO	PTO	PTO
Meters (feet)	MAG	MAG	MAG	MAG	MAG	MAG	MAG	MAG
0	310	300	290	280	270	260	250	240
Sea level	330	320	310	300	290	280	270	260
600 m	300	290	280	270	260	250	240	230
(2,000)	320	310	300	290	280	270	260	250
1,200 m	290	280	270	260	250	240	230	220
(4,000)	310	300	290	280	270	260	250	240
1,800 m	270	260	250	240	230	220	200	190
(6,000)	290	280	270	260	250	240	230	220
2,400 m	260	250	240	230	220	210	200	190
(8,000)	290	270	260	250	240	230	220	210
3,000 m	250	240	230	220	210	200	190	180
(10,000)	270	260	250	240	230	220	210	200





1979 BOSCH SPARK PLUG CHART

		ENGINE TYPE	FULL LOAD	PARTIAL LOAD
ELAN & SPIRIT	250	247	M175 T1	M175 T1
ELAN	250 DL	248	W240 MZ1	W240 MZ1
CITATION & MIRAGE	300	294	W260 MZ1	W260 MZ1
OLYMPIQUE & NUVIK	340	343	W280 MZ1	W280 MZ1
EVEREST	340	343	W280 MZ1	W280 MZ1
FUTURA	400	402	W280 MZ1	W280 MZ1
EVEREST & FUTURA	440	440	NGK A-8	M260 T1
EVEREST & FUTURA	444 LC	444	W280 MZ2	W260 MZ2
BLIZZARD 5500/ GP Special	503	503	W275 T2	W275 T2
BLIZZARD 7500/SUPER SONIC	354	354	W340 S2S	W340 S2S
CROSS COUNTRY	354	354	W275 T2	W275 T2
BLIZZARD	9500	454	W340 S2S	W340 S2S
ALPINE	640 ER	640	M240 T1	M240 T1
ELITE	450 LC	444	W280 MZ2	W260 MZ2



IGNITION GENERATING COIL, TRIGGER COIL AND LIGHTING COIL RESISTANCE CHART 1979

1979 MODELS		ENGINE	IGNITION GENERATING COIL	TRIGGER COIL	LIGHTING COIL	BRAKE LIGHT COIL
ELAN ET SPIRIT ELAN	250 250 Deluxe	247 248	3.4 1.15		0.45 0.45	1.85 1.90
CITATION & MIRAGE OLYMPIQUE & NUVIK	7.7.7	294 343	1.15 3.3	- 111	0.45 0.23	1.90
EVEREST FUTURA EVEREST & FUTURA EVEREST & FUTURA	340 400 440 444 LC	343 402 440 444	3.3 3.3 3.3 3.3		0.23 0.23 0.23 0.23	2.15 ①
BLIZZARD 5500 & GRAND PRIX SPECIAL		503	3.3		0.23	2.15 ①
BLIZZARD 7500 PLUS SUPER SONIC L/C CROSS COUNTRY		354	445-490	49-59	0.20	
BLIZZARD 9500 PLUS		454	445-490	49-59	0.20	
ALPINE	640 ER	640	3.3		0.23	2.15 ①
ELITE	450 LC	444	3.3			

All values are given in ohms, with a tolerance of ± 20%, except otherwise specified at a temperature of 20°C (70°F).

① Additional lighting coil 30 W.

BOMBARDIER IGNITION TESTER ADJUSTMENTS FOR 1979 COMPONENTS

1979 MODELS		ENGINE	GENERATING COIL	TRIGGER COIL	LIGHTING COIL	BRAKE LIGHT COIL
ELAN ET SPIRIT ELAN	250 250 Deluxe	247 248	HIGH 75 HIGH 75	111	LOW 85 LOW 80	LOW 85 LOW 80
CITATION & MIRAGE OLYMPIQUE & NUVIK	300 340	294 343	HIGH 75 HIGH 80	222	LOW 80 LOW 85	LOW 80
EVEREST FUTURA EVEREST & FUTURA EVEREST & FUTURA	340 400 440 444 LC	343 402 440 444	HIGH 80 HIGH 80 HIGH 80 HIGH 80		LOW 85 LOW 85 LOW 85 LOW 85	LOW 85 (
BLIZZARD 5500 & GRAND PRIX SPECIAL		503	HIGH 80		LOW 85	LOW 85 (
BLIZZARD 7500 PLUS SUPER SONIC L/C CROSS COUNTRY		354	HIGH 40	LOW 50	LOW 80	2-5
BLIZZARD 9500 PLUS		454	HIGH 40	LOW 50	LOW 80	
ALPINE	640 ER	640	HIGH 80		LOW 85	LOW 85 (
ELITE	450 LC	444	HIGH 80			

¹ Additional lighting coil 30 W.


S.I.* METRIC INFORMATION CHART

	BASE UNITS	
DESCRIPTION	UNIT	SYMBOL
length	meter	m
mass	kilogram	kg
liquid	liter	
temperature	celsius	°C
pressure	kilopascal	kPa
torque	Newton meter	N∙m
speed	kilometer per hour	km/h

PREFIXES								
PREFIX	SYMBOL	MEANING	VALUE					
kilo	k	one thousand	1,000					
centi	C	one hundredth of a	0.01					
milli	m	one thousandth of a	0.001					

*THE INTERNATIONAL SYSTEM OF UNITS (SYSTEME INTERNATIONAL) ABREVIATES "SI" IN ALL LANGUAGES.

1979 (SUPPLEMENT) (TOOLS), PAGE 11



WARRANTY

LIMITED WARRANTY SKI-DOO® SNOWMOBILES

BOMBARDIER Limited as manufacturer, warrants FROM THE DATE OF FIRST CONSUMER SALE, every 1979 Ski-Doo ® snowmobile, sold as NEW AND UNUSED, by an authorized SKI-DOO dealer, subject to the following limitations and conditions, for a period of:

- two (2) seasons maximum for models:
 Elan® , Olympique*, Citation*, Everest® , Elite®
- Warranty STARTS on the date of sale to the first consumer and ENDS the SECOND APRIL 30TH following the date warranty coverage started.
- Ninety (90) consecutive days for the following models: Blizzard[®] 5500-7500-9500 and Alpine[®] subject to the following:
- When a sale is made after MARCH 31ST of a given year but before THE 1ST DAY OF DECEMBER of the same year, the warranty will start on DECEMBER 1ST following the date of sale.
- When a sale is made on / or after JANUARY 2ND of a given year, the unused portion of the 90 days warranty as of MARCH 31ST, of that year will be carried over to the next season, beginning the 1ST DAY OF DECEMBER.

Any 1979 model not listed above is not warranted.

WHAT BOMBARDIER WILL DO

BOMBARDIER will repair and / or replace, at its option, components defective in material and / or workmanship (under normal use and service,) with a genuine BOMBARDIER component without charge for parts or labour at any authorized SKI-DOO dealer during said warranty period.

EXCLUSIONS

Items and components

Any of the following expendable items and / or components that are damaged or worn due to normal use: variable speed drive belt, windshield, filters, ignition breaker points, condensers, spark plugs, light bulbs, protective lenses, brake linings, ski runner shoes, slider shoes on suspension and variable speed pulleys, labels, soft trim, appearance items, lubricants and paints and all tune-ups and adjustments required, seized, melted or holed piston.

Also excluded are:

- Damage resulting from installation of parts other than genuine BOMBARDIER parts.
- Damage caused by failure to provide proper maintenance as detailed in the Operator Manual supplied with each SKI-DOO snowmobile. The labour, parts and lubricants cost of all maintenance services, including tune-ups and adjustments will be charged to the owner.
- Damage resulting from improper servicing or adjustment of the drive pulley assembly. The drive pulley assembly is factory sealed, and can only be serviced by an authorized SKI-DOO dealer.
- · Vehicles used for racing purposes.
- · Vehicles used for rental or other business purposes.
- All optional accessories installed on the vehicle.
 (The normal warranty policy for parts and accessories if any, applies).
- Damage resulting from operation of the snowmobile on surfaces other than snow.
- Damage resulting from accident, fire or other casualty, misuse, abuse or neglect.
- Damage resulting from modification to the snowmobile not approved in writing by BOMBARDIER.
- Losses incurred by the snowmobile owner other than parts and labour, such as, but not limited to, transportation, towing, telephone calls, taxis, or any other incidental or consequential damages.

Some states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply.

CONDITION TO HAVE WARRANTY WORK PERFORMED

Present, to the servicing dealer, the hard copy of the SKI-DOO Customer Registration card given by the selling dealer at time of purchase.

(SUPPLEMENT) 1979

EXPRESSED OR IMPLIED WARRANTIES

This warranty gives you specific rights, and you may also have other legal rights which may vary from **state to state, or province to province.**

Where applicable this warranty is expressly in lieu of all other expressed or implied warranties of BOMBAR-DIER, its distributors and the selling dealer, including any warranty of merchantability of fitness for any particular purpose; otherwise the implied warranty is limited to the duration of this warranty. However, some states or provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply.

Neither the distributor, the selling dealer, nor any other person has been authorized to make any affirmation, representation or warranty other than those contained in this warranty, and if made, such affirmation, representation or warranty shall not be enforceable against BOMBARDIER or any other person.

CONSUMER ASSISTANCE

If a servicing problem or other difficulty occurs, we suggest the following:

- Try to resolve the problem at the dealership with the Service Manager or Owner.
- If this fails, contact your area distributor listed in the operator manual.
- Then if your grievance still remains unsolved, you may write to us:

Bombardier Limited Customer Relations Dept. Recreational Product Group Valcourt, Quebec, Canada, J0E 2L0

Bombardier Limited reserves the right to modify its warranty policy at any time, being understood that such modification will not alter the warranty conditions applicable to vehicles sold while the above warranty is in effect.

JANUARY 1978
BOMBARDIER LIMITED
Valcourt, Quebec, Canada, J0E 2L0

^{*}Trademark of Bombardier Limited

Registered Trademark of Bombardier Limited

WARRANTY

LIMITED WARRANTY MOTO-SKI® SNOWMOBILES

BOMBARDIER Limited as manufacturer, warrants FROM THE DATE OF FIRST CONSUMER SALE, every 1979 Moto-Ski snowmobile, sold as NEW AND UNUSED, by an authorized MOTO-SKI dealer, subject to the following limitations and conditions, for a period of:

- two (2) seasons maximum for models: SPIRIT*, NUVIK*, MIRAGE*, FUTURA®
- Warranty STARTS on the date of sale to the first consumer and ENDS the SECOND APRIL 30TH following the date warranty coverage started.
- Ninety (90) consecutive days for the following models: SUPER SONIC*, GRAND PRIX® SPECIAL subject to the following:
- When a sale is made after MARCH 31ST of a given year but before THE 1ST DAY OF DECEMBER of the same year, the warranty will start on DECEMBER 1ST following the date of sale.
- When a sale is made on / or after JANUARY 2ND of a given year, the unused portion of the 90 days warranty as of MARCH 31ST, of that year will be carried over to the next season, beginning the 1ST DAY OF DECEMBER.

Any 1979 model not listed above is not warranted.

WHAT BOMBARDIER WILL DO

BOMBARDIER will repair and / or replace, at its option, components defective in material and / or workmanship (under normal use and service,) with a genuine BOMBARDIER component without charge for parts or labour at any authorized MOTO-SKI dealer during said warranty period.

EXCLUSIONS

Items and components

Any of the following expendable items and / or components that are damaged or worn due to normal use: variable speed drive belt, windshield, filters, ignition breaker points, condensers, spark plugs, light bulbs, protective lenses, brake linings, ski runner shoes, slider shoes on suspension and variable speed pulleys, labels, soft trim, appearance items, lubricants and paints and all tune-ups and adjustments required, seized, melted or holed piston.

Also excluded are:

- Damage resulting from installation of parts other than genuine BOMBARDIER parts.
- Damage caused by failure to provide proper maintenance as detailed in the Operator Manual supplied with each MOTO-SKI snowmobile. The labour, parts and lubricants cost of all maintenance services, including tune-ups and adjustments will be charged to the owner.
- Damage resulting from improper servicing or adjustment of the drive pulley assembly. The drive pulley assembly is factory sealed, and can only be serviced by an authorized MOTO-SKI dealer.
- · Vehicles used for racing purposes.
- Vehicles used for rental or other business purposes.
- All optional accessories installed on the vehicle.
 (The normal warranty policy for parts and accessories if any, applies).
- Damage resulting from operation of the snowmobile on surfaces other than snow.
- Damage resulting from accident, fire or other casualty, misuse, abuse or neglect.
- Damage resulting from modification to the snowmobile not approved in writing by BOMBARDIER.
- Losses incurred by the snowmobile owner other than parts and labour, such as, but not limited to, transportation, towing, telephone calls, taxis, or any other incidental or consequential damages.

Some states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply.

CONDITION TO HAVE WARRANTY WORK PERFORMED

Present, to the servicing dealer, the hard copy of the MOTO-SKI Customer Registration card given by the selling dealer at time of purchase.

(SUPPLEMENT) 1979

EXPRESSED OR IMPLIED WARRANTIES

This warranty gives you specific rights, and you may also have other legal rights which may vary from **state to state**, **or province to province**.

Where applicable this warranty is expressly in lieu of all other expressed or implied warranties of BOMBAR-DIER, its distributors and the selling dealer, including any warranty of merchantability of fitness for any particular purpose; otherwise the implied warranty is limited to the duration of this warranty. However, some states or provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply.

Neither the distributor, the selling dealer, nor any other person has been authorized to make any affirmation, representation or warranty other than those contained in this warranty, and if made, such affirmation, representation or warranty shall not be enforceable against BOMBARDIER or any other person.

CONSUMER ASSISTANCE

If a servicing problem or other difficulty occurs, we suggest the following:

- Try to resolve the problem at the dealership with the Service Manager or Owner.
- If this fails, contact your area distributor listed in the operator manual.
- 3. Then if your grievance still remains unsolved, you may write to us:

Bombardier Limited Customer Relations Dept. Recreational Product Group Valcourt, Quebec, Canada, J0E 2L0

Bombardier Limited reserves the right to modify its warranty policy at any time, being understood that such modification will not alter the warranty conditions applicable to vehicles sold while the above warranty is in effect.

JANUARY 1978 BOMBARDIER LIMITED Valcourt, Quebec, Canada, J0E 2L0

(WARRANTY), PAGE 4 (SUPPLEMENT) 1979

^{*}Trademark of Bombardier Limited

Registered Trademark of Bombardier Limited

