

NORDIK[®] 50
NORDIK[®] 60

OPERATOR'S MANUAL

1990

414 6833 00

model _____

V.I.N. _____

purchase date _____

warranty expiry date _____

To be completed by dealer at time of sale

DEALER IMPRINT AREA

AFTER SALES SERVICE
BOMBARDIER INC.
VALCOURT (QUEBEC)
CANADA JOE 2LO



The following are trademarks of Bombardier Inc.

ALPINE®
BOMBARDIER®
CHEYENNE*
ELAN®
NORDIK®

ROTAX®
SAFARI*
SCOUT*
SKI-DOO®

FOREWORD

The operator manual and the Snowmobile Safety Handbook have been prepared to acquaint the owner/operator or passenger of a new snowmobile with the various vehicle controls, maintenance and safe operating instructions. Each is indispensable for the proper use of the product, and should be kept with the vehicle at all times.

Should you have any questions pertaining to the warranty and its application, please consult the "Often Asked Question" section of this manual, or your authorized dealer.

This manual uses the following symbols.

◆ **WARNING** : Identifies an instruction which, if not followed, could cause serious personal injuries including possibility of death.

▼ **CAUTION** : Denotes an instruction which, if not followed, could severely damage vehicle components.

○ **NOTE** : Indicates supplementary information needed to fully complete an instruction.

Although the mere reading of such information does not eliminate the hazard, your understanding of the information will promote its correct use.

The information and components/system descriptions contained in this manual are correct at time of publication. Bombardier Inc. however, maintains a policy of continuous improvement of its products without imposing upon itself any obligation to install them on products previously manufactured.

Bombardier Inc. reserves the right at any time to discontinue or change specifications, designs, features, models or equipment without incurring obligation.

The illustrations show the typical construction of the different assemblies and, in all cases, may not reproduce the full detail or exact shape of the parts shown, however, they represent parts which have the same or a similar function.

Most specifications are given in both metric and customary units. Where precise accuracy is not required, some conversions are rounded to even numbers for easier use.

A shop manual can be obtained for complete service, maintenance and repair information.

◆ **WARNING** : The engines and the corresponding components identified in this manual should not be utilized on product(s) other than those mentioned on the cover page of this manual.

◆ **WARNING** : Maintenance procedures and tightening torques must be strictly adhered to, never attempt repairs unless the appropriate tools are available.

▼ **CAUTION** : Most components of this vehicle are built with parts dimensioned in the metric system. Most fasteners are metric and must not be replaced by customary fasteners or vice versa. Mismatched or incorrect fasteners could cause damage to the vehicle or possible personal injury.

INDEX

SAFETY MEASURES	4
THE 1990 "LIMITED WARRANTY"	5
OFTEN ASKED QUESTIONS	7
LISTING OF AREA DISTRIBUTORS	9
HOW TO IDENTIFY YOUR SNOWMOBILE	10
CONTROLS/INSTRUMENTS	11
Throttle lever	Speedometer
Brake lever	Tank cap
Ignition light switch	Hood opening
Headlamp dimmer switch	Hitch
Emergency cut-out switch	Accessories
Tether cut-out switch	
Rewind starter handle	
Primer	
Adjustable steering handle	
 BREAK-IN PERIOD	 16
Engine and belt break-in	Inspection check list
10-hour inspection	
 FUEL & OIL	 18
Recommended fuel	Oil injection system
Recommended oil	
 PRE-START CHECK	 21
Check points	
 STARTING PROCEDURE	 21
Manual starting	Emergency starting
Before riding	

LUBRICATION **23**

Frequency	Transmission oil level
Steering mechanism	Driven pulley
Slide suspension	

MAINTENANCE **26**

Maintenance chart	Drive pulley
Belt guard removal	Steering mechanism
Drive belt removal and installation	Steering adjustment
Drive belt condition	Muffler attachment
New drive belt	Engine head nuts
Brake condition	Engine mount nuts
Brake adjustment	Carburetor adjustment
Drive chain tension	High altitude kit
Spark plug	Fan belt
Suspension condition	Headlamp beam aiming
Suspension adjustment	Bulb replacement
Track condition	General inspection
Track tension and alignment	

STORAGE **37**

Track	Drive pulley
Suspension	Engine
Skis and runners	Fuel tank and carburetor
Controls	Chassis
Transmission	General inspection
Chaincase	

PRE-SEASON PREPARATION **40**

Pre-season preparation chart

TROUBLESHOOTING **41**

TOOLS **44**

SPECIFICATIONS **45**

SI METRIC INFORMATION GUIDE **47**

SAFETY MEASURES

Observe the following precautions :

- Throttle mechanism should be checked for free movement before starting engine.
- Do not operate vehicle near snow making equipment.
- Engine should be running only when belt guard and/or pulley guard is secured in place.
- Never run the engine without drive belt installed. Running an unloaded engine can prove to be dangerous.
- Never run the engine when the track is raised off the ground.
- It can be dangerous to run engine with the hood removed.
- Gasoline is flammable and explosive under certain conditions. Always manipulate in a well ventilated area. Do not smoke or allow open flames or sparks in the vicinity. If gasoline fumes are noticed while driving, the cause should be determined and corrected without delay.
- Maintain your vehicle in top mechanical condition at all times.
- Your snowmobile is not designed to be driven or operated on black top, bare earth, ice, hard pack or other abrasive surfaces. On such surfaces abnormal and excessive wear of critical parts is inevitable.
- Your snowmobile is not designed to be operated on public streets, road or highways. In most States and Provinces, it is considered an illegal operation.
- Installation of other than standard equipment, including ski-spreaders, bumpers, pack racks, etc., could severely affect the stability and safety of your vehicle. Avoid adding on accessories that alter the basic vehicle configuration.
- The snowmobile engine can be stopped by activating the emergency cut-out switch, tether switch or by turning off the key.
- Whenever the vehicle is parked outdoors, overnight or for a long period, it is suggested to protect it against the inclemency of the weather with a snowmobile cover.
- Do not lubricate throttle and/or brake cables and housings.
- Only perform procedures as detailed in this manual. Unless otherwise specified, engine should be turned OFF for all lubrication and maintenance procedures.
- Clean and check operation of the head light, taillight and brake light.
- Should removal of a locking device be required when undergoing repairs/ disassembly, always replace by new ones. Tighten fasteners as specified in the applicable Shop Manual.

PLEASE READ AND UNDERSTAND ALL WARNINGS AND CAUTIONS IN THE SNOWMOBILER'S SAFETY HANDBOOK, THIS OPERATOR'S MANUAL AND ON THE VEHICLE

BOTH MANUALS SHOULD REMAIN WITH THE VEHICLE AT THE TIME OF RESALE
--

THE 1990 SNOWMOBILE LIMITED WARRANTY

1 - PERIOD

BOMBARDIER INC. as manufacturer, warrants FROM THE DATE OF DELIVERY TO THE FIRST CONSUMER, every 1990 BOMBARDIER® snowmobile, sold as NEW AND UNUSED, and predelivered by an authorized BOMBARDIER® dealer for a period of:

- 12 consecutive months.
- Warranty coverage on all new snowmobiles delivered between August 1st and December 1st of a year will expire on December 1st of the following year.

2 - WHAT BOMBARDIER INC. WILL DO

BOMBARDIER INC. will repair and/or replace, at its option, components defective in material and/or workmanship (under normal use and service), with a genuine BOMBARDIER® component without charge for parts or labour, at any authorized BOMBARDIER® dealer during said warranty period.

3 - CONDITION TO HAVE WARRANTY WORK PERFORMED

Present to the servicing dealer, the hard copy of the BOMBARDIER® Warranty Registration card or proof of purchase received by the customer from the selling dealer at time of delivery.

4 - EXCLUSIONS - ARE NOT WARRANTED

- Normal wear on all items such as, but not limited to :
 - drive belts
 - bulbs
 - slider shoes
 - runners on skis
 - spark plugs
- Replacement parts and/or accessories which are not genuine BOMBARDIER® parts and/or accessories.
- Damage resulting from installation of parts other than genuine BOMBARDIER® parts.
- Damage caused by failure to provide proper maintenance as detailed in the Operator's Manual. The labour, parts and lubricants costs of all maintenance services, including tune-ups and adjustments will be charged to the owner.
- Cold seizure and piston scuffing caused by insufficient warm-up.
- Vehicles designed and/or used for racing purposes.
- All optional accessories installed on the vehicle. (The normal warranty policy for parts and accessories, if any, applies).
- Damage resulting from accident, fire or other casualty, misuse, abuse or neglect.
- Damage resulting from operation of the snowmobile on surfaces other than snow.
- Damage resulting from modification to the snowmobile not approved in writing by BOMBARDIER INC.
- Damage incurred by track studs.
- Losses incurred by the snowmobile owner other than parts and labour, such as, but not limited to, transportation, towing, telephone calls, taxis, or any other incidental or consequential damage.

5 - BATTERY WARRANTY:

- 12 consecutive months (Pro-rated).

100 % warranty coverage will start on the date the snowmobile was delivered and run to the following April 30th. The remainder of the 12 month-period will be pro-rated as follows:

- 50 % from April 30th to December 1st.
- 40 % from December 1st to December 31st.
- 30 % from January 1st to end of warranty.

6 - EXPRESSED OR IMPLIED WARRANTIES

This warranty gives you specific rights and you may also have other legal rights which may vary from state to state, or province to province. Where applicable this warranty is expressly in lieu of all other expressed or implied warranties of BOMBARDIER INC., its distributors and the selling dealer, including any warranty of merchantability or fitness for any particular purpose; otherwise the implied warranty is limited to the duration of this warranty. However, some states or provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply.

Neither the distributor, the selling dealer, nor any other person has been authorized to make any affirmation, representation or warranty other than those contained in this warranty, and if made, such affirmation, representation or warranty shall not be enforceable against BOMBARDIER INC. or any other person.

Some states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply.

BOMBARDIER INC. reserves the right to modify its warranty policy at any time, being understood that such modification will not alter the warranty conditions applicable to vehicles sold while the above warranty is in effect.

7 - CONSUMER ASSISTANCE

If a servicing problem or other difficulty occurs, we suggest the following:

1. Try to solve the problem at the dealership with the Service Manager or Owner.
2. If this fails, contact your area distributor listed in the Operator's Manual.
3. Then if your grievance still remains unsolved, you may write to us:

Bombardier Inc.
Service Department
Snowmobile Division
Valcourt, Quebec, Canada JOE 2L0

September 1988
Bombardier Inc.
Valcourt, Quebec, Canada JOE 2L0

®*Trademarks of Bombardier Inc.

OFTEN ASKED QUESTIONS

Q : Why must my snowmobile be registered at the factory ? After all I do have my original invoice as proof of when I purchased my snowmobile.

A : Your warranty is valid at any authorized dealer of the product. Your registration is the key element in providing the servicing dealer with the necessary data to complete warranty claim forms. This information is also used to notify owners in the event of a safety recall.

Q : Who should send the registration card to Bombardier Inc. ?

A : The dealer. However, it is important that the customer make sure that it has been sent. The company might contact you should your vehicle be recalled or in case of a particular warranty campaign.

Q : Why must my snowmobile be registered with the governing body having jurisdiction over snowmobile use ?

A : Snowmobile registration has two purposes : it allows the state or province to maintain records of existing snowmobiles and the owner/operator who registers a snowmobile has a reasonable chance for recovery after theft. Governmental agencies use the registration fees for establishing and maintaining trails.

Q : I bought my snowmobile in O'King County but I snowmobile in Washington County. Can the dealer in Washington County accept to perform warranty work on my snowmobile ?

A : Yes, any authorized dealer in North America can perform warranty repairs, providing the customer warranty registration card is presented.

Q : Where can I find information on the lubrication and maintenance of my snowmobile ?

A : In this Operator Manual provided with the vehicle at the time of delivery.

Q : Will the entire warranty be void or cancelled, if I do not operate or maintain my new snowmobile exactly as specified in the Operator's Manual ?

A : The warranty of the new snowmobile cannot be "Voided" or "Cancelled". However, if a particular failure is caused by operation or maintenance other than is shown in the Operator Manual, THAT failure may not be covered under warranty. This includes service work performed by the customer, especially the critical adjustments to ignition, timing, carburation and oil injection/or oil mixture.

Q : Would you give some examples of abnormal use or strain, neglect or abuse ?

A : These terms are general and overlap each other in areas. Some specific examples may include : running the machine out of oil, chain failure caused by a lack of lubrication, operating the machine with a broken or damaged part which causes another part to fail, and so on. If you have any specific question on operation or maintenance, please contact your dealer for advice.

Q : What costs are my responsibility during the warranty period ?

A : The customer's responsibility includes all costs of normal maintenance services, non-warranty repairs, accidents and collision damage, as well as oils, and spark plugs, and incidental or consequential damages costs as explained in the warranty.

Q : Are "Genuine" Bombardier replacement parts used in warranty repairs covered by warranty ?

A : Yes. When installed by an authorized dealer, any "Genuine" Bombardier part used in warranty repairs assumes the remaining warranty that exists on the machine.

Q : If I sell my snowmobile within the warranty period, will the new owner qualify for the balance of the warranty ?

A : Yes, provided the unit has already been registered with the manufacturer. Note that the change of ownership card in this manual should be completed and sent to Bombardier Inc.

Q : How can I receive the best owner assistance ?

A : The satisfaction and goodwill of the owners of Bombardier products are of primary concern to your dealer and Bombardier Inc. Normally, any problems that arise in connection with the sales transaction or the operation of your snowmobile will be handled by your Dealers Sales or Service Departments. It is recognized, however, that despite the best intentions of everyone concerned, misunderstandings will sometimes occur. If you have a problem that has not been handled to your satisfaction through normal channels, we suggest that you discuss your problem with a member of dealership management. Frequently, complaints are the result of a breakdown in communications and can quickly be resolved by a member of the dealership management. If the problem already has been reviewed with the Sales Manager or Service Manager, contact the Dealer himself or the General Manager.

LISTING OF AREA DISTRIBUTORS

CANADIAN DISTRIBUTORS

PROVINCE OF QUEBEC

SERVICE OFFICE

BOMBARDIER INC.

Valcourt, Quebec JOE 2L0

(514) 532-2211

SALES OFFICE

BOMBARDIER INC.

1350 Nobel Street

Boucherville, Quebec J4B 1A1

(514) 655-6121

PROVINCE OF ONTARIO

SERVICE AND SALES OFFICE

BOMBARDIER INC.

230 Bayview Drive

Barrie, Ontario L4N 5E9

(705) 728-8600

ATLANTIC REGION

SERVICE OFFICE

BOMBARDIER INC.

P.O. Box 7060

Riverview, New Brunswick E1B 1V0

(506) 386-6117

SALES OFFICE

BOMBARDIER INC.

1350 Nobel Street

Boucherville, Quebec J4B 1A1

(514) 655-6121

ALBERTA, BRITISH COLUMBIA, MANITOBA, SASKATCHEWAN, YUKON

SERVICE AND SALES OFFICE

BROOKS EQUIPMENT LIMITED

1616 King Edward Street

P.O. Box 985

Winnipeg, Manitoba R3C 2V8

(204) 633-7247

NEWFOUNDLAND, LABRADOR

SERVICE AND SALES OFFICE

CHARLES R. BELL LIMITED

Riverside Drive

P.O. Box 1050

Corner Brook, Newfoundland A2H 6J7

(709) 634-3533

NORTH-WEST TERRITORIES, FRANKLIN DISTRICT & KEEWATIN

SERVICE AND SALES OFFICE

HUDSON'S BAY CO. LIMITED

165 Hymus Blvd

Pointe-Claire, Quebec H9R 1G2

(514) 630-5279

AMERICAN DISTRIBUTORS

EAST-CENTRAL, CENTRAL, WESTERN REGION

SALES OFFICE

BOMBARDIER CORPORATION

7575 Packer Drive

P.O. Box 8035

Wausau, WI 54402-8035

(715) 842-8886

EAST-CENTRAL, CENTRAL REGION

SERVICE OFFICE

BOMBARDIER CORPORATION

4505 West Superior Street

P.O. Box 16106

Duluth, MN 55816-0106

(218) 628-2881

WESTERN REGION

SERVICE OFFICE

BOMBARDIER CORPORATION

P.O. Box 1572

Golden, CO 80402-1572

(303) 232-5284

EASTERN REGION

SERVICE AND SALES OFFICE

BOMBARDIER CORPORATION

East Main Street Road

Malone, NY 12953

(518) 483-4411

ALASKA

SERVICE AND SALES OFFICE

THE BRYANT CORPORATION

NE. 190th & Woodinville

Snohomish Road

P.O. Box 389


Woodinville, WA 98072

(206) 482-0110


HOW TO IDENTIFY YOUR SNOWMOBILE

The main components of your snowmobile (engine, track and frame) are identified by different serial numbers. It may sometimes become necessary to locate these numbers for warranty purposes or to trace your snowmobile in the event of loss.

Engine serial number




A007 002 001




Track
serial number

A009 005 002

NORDIK 50




NORDIK 60




○ **NOTE :** We strongly recommend that you take note of all the serial numbers on your vehicle and supply them to your insurance company. It will surely help in the event your snowmobile is stolen.

CONTROLS/ INSTRUMENTS

NORDIK 50



NORDIK 60



- A) Throttle Lever
- B) Brake Lever
- C) Ignition/Light switch
- D) Headlamp Dimmer Switch
- E) Emergency Cut-out Switch
- F) Tether Cut-out Switch
- G) Rewind Starter Handle
- H) Primer

- I) Adjustable Steering Handle
- J) Speedometer/Odometer
- K) Hot Grips
- L) Hood Opening
- M) Tank Cap
- N) Fuel Level Gauge
- P) Gear Shift Lever


A) Throttle Lever

Located on the right side of handlebar. When compressed, it controls the engine speed and the engagement of the transmission. When released, engine speed returns automatically to idle.

B) Brake Lever

Located on the left side of handlebar. When compressed, the brake is applied. When released, it automatically returns to its original position. Braking effect is proportionate to the pressure applied on the lever and to the type of terrain and its snow coverage.

C) Ignition/Light Switch




Key operated two position switch. To start the engine, first turn key to ON position. To stop engine, turn key to OFF position.

The lights are automatically ON whenever the engine is running.


D) Headlamp Dimmer Switch

The dimmer switch allows correct selection of headlamp beam. To obtain high or low beam simply flick switch.



E) Emergency Cut-Out Switch

To stop the engine in an emergency, push the button to the lower off position and simultaneously apply the brakes. To start engine, button must be at the upper on position.



The driver of this vehicle should familiarize himself with the function of this device by using it several times on first outing. Thereby being mentally prepared for emergency situations requiring its use.

◆ **WARNING :** For safety reasons, the emergency cut-off switch is easily accessible ; be careful not to operate it inadvertently. If the switch has been used in an emergency situation the source of malfunction should be determined and corrected before restarting engine.

F) Tether Cut-out Switch

Attach tether cord to wrist or other convenient location of the driver's clothing. Snap tether cut-out cap over receptacle before starting engine.

If emergency engine "shut off" is required, completely pull cap from safety switch and engine power will be automatically "shut off".

○ **NOTE :** The cap must be installed on the safety switch at all times in order to operate the vehicle.

◆ **WARNING :** If the switch is used in an emergency situation the source of malfunction should be determined and corrected before restarting engine.

G) Rewind Starter Handle

Auto rewind type located on right hand side of vehicle. To engage mechanism, pull handle slowly until a resistance is felt then pull vigorously.

H) Primer

Pull and push button (two three times) to start a cold engine. Not necessary to start a warm engine.

I) Adjustable Steering Handle


Steering handle height is adjustable. See your authorized dealer.

J) Speedometer/Odometer/Trip Meter

The speedometer indicates the speed of the vehicle in kilometers per hour. Odometer records the total number of kilometers travelled. A trip meter is also combined with speedometer.

Trip Meter Reset Button

The trip meter button is located in dashboard right to speedometer. To reset, turn button clockwise until all numbers read zero.



K) Heated Grip Switch

The two position toggle switch is located in dashboard underneath pilot lamps. Select the desired position to keep hands at a comfortable temperature.



L) Hood Opening

Pull down the latches to unlock the hood from the anchors.



NOTE: Always lift hood gently up until stopped by restraining device.




WARNING: It is dangerous to run an engine with the hood opened, unfastened or removed.

N) Fuel Gauge/Tank Cap

The fuel tank cap features a built-in needle fuel level gauge which indicates the amount of fuel remaining in tank.




WARNING: Remove fuel tank cap slowly. Fuel may be under pressure and spray may cause fire and injuries. Never use open flame to check fuel level.




P) Gear Shift Lever

The gear shift lever is located right side of the dashboard. It is a 3-position lever: 2 forward and 1 reverse. Pull lever upwards before selecting position.



WARNING: This snowmobile is capable of a fast reverse. Operator should become familiar with this operation by practicing on level ground. Always apply the brake before shifting and come to a complete stop then, while holding brake on, change gear. Ensure the path behind is clear of obstacles or bystanders. Fast reverse, while turning, could result in loss of stability.


Hitch



Fixed on the frame. A hair pin is supplied to lock the hook attachment.

◆ **WARNING:** When towing a sled or trailer, always ensure to lock the hook attachment with the hair pin.

Nordik 60



Fixed on the draw bar installed with rubber mounts on the frame.

The hitch is adjustable in accordance with the load. When pulling heavy loads the position of the rubber mount can be adjusted to holes A in order to improve maneuverability of the snowmobile. When pulling light loads the attachment can be changed to holes C to increase hitch travelling. The original attachment point is hole B.


◆ **WARNING:** When towing a sled or trailer, always ensure to lock the hook attachment with the hair pin.

Trailers or sleds towed behind a snowmobile should always be loaded in a way to obtain the lowest possible center of gravity. Use a rigid tow bar when pulling a tow sled behind snowmobile. When you are pulling passengers in a trailer or tow sled, use moderate speed and avoid rough terrain for their safety. Also, have all passengers get out of a towed vehicle and walk across all roads.

BREAK-IN PERIOD

Engine

With Bombardier-Rotax snowmobile engine, a break-in period is required before running the vehicle at full throttle. Engine's manufacturer recommendation is 10 to 15 operating hours. During this period, maximum throttle should not exceed $3/4$, however, brief full acceleration and speed variations contribute to a good break-in. Continued wide open throttle accelerations, prolonged cruising speeds, and engine over-heating are detrimental during the break-in period.

 **NOTE :** To assure additional protection during the initial engine break-in, 500 mL (18 imp. oz) of BLIZZARD OIL (P/N 496 0135 00) or the same quantity of Bombardier Injection oil should be added to fuel for the first full fuel tank filling.

 **CAUTION :** Remove and clean spark plugs after engine break-in.

Belt

A new drive belt requires a break-in period of 25 km (15 miles).

10-Hour Inspection

As with any precision piece of mechanical equipment, we suggest that after the first 10 hours of operation or 30 days after the purchase, whichever comes first, your vehicle be checked by your authorized dealer. This inspection will give you the opportunity to discuss the unanswered questions you may have encountered during the first hours of operation.

The 10-hour inspection is at the expense of the vehicle owner.

10-HOUR INSPECTION CHECKLIST	✓
Engine timing	
Fan belt tension	
Spark plugs condition : (Remove and clean)	
Carburetor adjustment	
Oil injection pump adjustment	
Engine head nuts	
Drive pulley screw (torque)	
Engine mount nuts	
Muffler attachment	
Transmission/Chaincase oil level	
Injection system oil level	
Brake operation and lining condition	
Ski alignment (runner condition)	
Handlebar bolts, retorque to 26 N•m (19 lbf•ft)	
Pulley alignment and drive belt condition	
Track condition, tension and alignment	
Lubrication (steering, suspension, etc.)	
Electrical wiring	
Tighten all loose bolts, nuts and linkage	
Operation of lighting system (HI / LO beam, brake light, etc.), test operation of emergency cut-out switch and tether switch	

We recommend that you have your dealer sign this inspection list.

Date of 10-hour inspection

Dealer signature

FUEL & OIL

Oil must be added to the fuel in premeasured amounts then both oil and fuel should be thoroughly mixed together before fueling the tank.

Recommended fuel

Use regular leaded or unleaded gasoline available from all service stations or gasohol with less than 10% of ethanol.

◆ **WARNING:** Remove fuel tank cap slowly. Fuel may be under pressure and spray may cause fire and injuries. Fuel is flammable and explosive under certain conditions. Always manipulate in a well ventilated area. Do not smoke or allow open flames or sparks in the vicinity.

▼ **CAUTION:** Never experiment with other fuels or fuel ratios. The use of fuel containing methanol, or similar products including naphta is not recommended. The use of unrecommended fuel can result in vehicle performance deterioration and damage to critical parts in the fuel system and engine components.

◆ **WARNING:** Never "top up" the fuel tank before placing the vehicle in a warm area. At certain temperatures, fuel will expand and overflow. Always wipe off any fuel spillage from the snowmobile.

Recommended oil

Use "BLIZZARD OIL" (P/N 496 0135 00 - 500 mL) available from your dealer. This type of oil will flow at temperatures as low as -40°C (-40°F).

If "BLIZZARD OIL" is unavailable, substitute with "Bombardier injection oil" (P/N 496 0133 00 - 1 liter or equivalent).

▼ **CAUTION:** Never use outboard or straight mineral oils.

Fuel mixture ratio

The importance of using the correct fuel mixture cannot be overstressed. An incorrect fuel/oil ratio results in serious engine damage. Recommended fuel/oil ratio is 50:1 (40:1 during break-in period, refer to "break-in period" section for mixing chart).

SI UNITS

500 mL oil to 25 liters = 50:1

IMPERIAL UNITS

16 oz oil to 5 imp. gal = 50:1
or

500 mL oil to 5-1/2 imp. gal = 50:1

U.S. UNITS

13 oz oil to 5 U.S. gal = 50:1
or

500 mL oil to 6.6 U.S. gal = 50:1


○ **NOTE:** To facilitate gas mixing, oil should be kept at room temperature.

Fuel mixing procedure


To mix the fuel and oil always use a separate clean container. Never mix directly in your snowmobile tank.

◆ **WARNING :** Fuel is flammable and explosive under certain conditions. Always manipulate in a well ventilated area. Do not smoke or allow open flames or sparks in the vicinity. If fuel fumes are noticed while driving, the cause should be determined and corrected without delay. Never add fuel while the engine is running. Avoid skin contact with fuel at below freezing temperatures.


1. Pour approximately 4 liters (one gallon) of fuel into a clean container.



2. Add the amount of oil required for the total mixture.



3. Replace the container cap and shake the container thoroughly.






4. Add the remainder of the fuel.
5. Once again thoroughly agitate the container. Then using a funnel with a fine mesh screen to prevent the entry of foreign particles, pour the mixture into the snowmobile tank.

◆ **WARNING :** To prevent fuel spillage in the engine compartment, a funnel must always be used when filling the gas tank.

○ **NOTE :** When using pre-mixed fuel, always shake the container thoroughly as the oil has a tendency to settle.

FUEL/OIL MIXING CHARTS
(50 to 1 ratio)



A000 000 006

PRE-START CHECK

Check Points

- ACTIVATE THE THROTTLE CONTROL LEVER SEVERAL TIMES to check that it operates easily and smoothly. The throttle control lever must return to idle position when released.
- Check that the skis and the track are not frozen to the ground or snow surface and that steering operates freely.
- Activate the brake control lever and make sure the brake fully applies before the brake control lever touches the handlebar grip. It must fully return when released.


- Check fuel level.
- Verify that the path ahead of the vehicle is clear of bystanders and obstacles.
- Clean and check operation of the headlight, taillight and brake light.

WARNING : Only start your snowmobile once all components are checked and functioning properly.

STARTING PROCEDURE

Test throttle control lever operation.

Check that the emergency cut-out switch is in the ON position.



Ensure the tether cut-out cap is in position and that the cord is attached to the clothing.

Activate the primer (two or three times).

NOTE : The use of the primer is not necessary when the engine is warm.

CAUTION : Use of ether and/or other types fluid as a starting aid can cause damage to engine components and is not recommended.

On models equipped with an electric starter, follow either manual or electric starting procedure.

Manual Starting

Insert the key in the ignition and turn to ON position.

Grasp manual starter handle firmly and pull slowly until a resistance is felt then pull vigorously. Slowly release the rewind starter handle.

WARNING : Do not apply throttle while starting.

Before Riding

Check operation of the emergency cut-out switch and tether switch. Restart engine.

◆ **WARNING :** If engine does not shutoff when applying the emergency cut-out switch and or when pulling the tether cut-out cap, stop the engine by turning off the ignition key. Do not operate the vehicle further, see your authorized dealer.


Allow the engine to warm before operating at full throttle.

○ **NOTE :** Engine is warm when operating temperature has been reached on temperature gauge. On vehicles without temperature gauge, let engine idling three to five minutes.

Emergency Starting

Should the rewind starter rope fray and break, the engine can be started with the emergency starter rope supplied with the tool kit.


◆ **WARNING :** Do not wind starting rope around your hand. Hold rope by the handle only.




◆ **WARNING :** Do not start the vehicle by the drive pulley unless it is a true emergency situation. Have the vehicle repaired as soon as possible.

Attach emergency rope to any available handle.


○ **NOTE :** The spark plug socket can be used as an emergency starter grip.



Attach other end of emergency rope to starter clip supplied in tool box. Wind rope tightly around drive pulley.



LUBRICATION



Frequency

Routine maintenance is necessary for all mechanized products, and the snowmobile is no exception. A weekly vehicle inspection contributes to the life span of the snowmobile.

It is recommended that the steering system and suspension be lubricated monthly or every 40 hours of operation. If the vehicle is operated in wet snow or in severe conditions these items should be lubricated more frequently.

○ **NOTE :** When lubricating grease fittings, grease until grease appears at joints. Always use low temperature grease (P/N 413 7061 00).



◆ **WARNING :** Only perform such procedures as detailed in this manual. It is recommended that dealer assistance be periodically obtained on other components/systems not covered in this manual. Unless otherwise specified, engine should be turned OFF for all lubrication and maintenance procedures.

Steering Mechanism

◆ **WARNING :** Do not lubricate throttle and/or brake cables and housings.

Lubricate the ski legs at grease fittings until new grease appears at joints. Coat spring slider cushion with grease. Oil spring coupler bolts.


Oil ball joints and steering column bushings.



Slide Suspension

Nordik 60


Lubricate front & rear arms at grease fittings until grease appears at joints. Use low temperature grease only.



Nordik 50

Lubricate the following parts at grease fitting until grease appears at joints. Use low temperature grease only.


— Front upper and lower cross shafts.




— Rear cross shaft and both shafts of shackle.

Drive axle

Lubricate ar grease fitting using low temperature grease.




CAUTION: When lubricating the drive axle bearing, do not apply excessive grease as the seal will be pushed out of its housing. Check seal position with finger.



Gearbox

Drain gearbox and refill with 500 mL (18 oz) of fresh Bombardier chaincase oil (P/N 413 8019 00-250 mL). The drain plug is located underneath the front part of the vehicle.




High altitude kit

Snowmobiles used in high altitude areas (1200 m (4000 ft) and up) are subjected to lose power as temperature, elevation and snow condition are different. The carburetor and power train have to be recalibrated to meet those particular requirements. Ask your authorized dealer for more information on high altitude kit availability.

CAUTION : Do not change original jetting if using vehicle below 1200 m (4000 ft).

Fan belt

Inspect belt for cracks, uneven wear, etc. Check fan belt tension, 9-10 mm (3/8 in) deflection should exist.




If belt seems damaged or if tension is incorrect, contact the dealer immediately.

WARNING : If fan protector is removed, always reinstall after servicing.

Drive chain tension

Run vehicle forward so that true free-play can be taken. Check tension then turn driven pulley 1/2 turn towards and recheck. Starting from maximum reading, adjust chain tension to obtain 3-6 mm (1/8-1/4 in) free-play.

Remove capscrew locking chain tensioner in place. (Tensioner is located at bottom left of gearbox.)





Rotate the tensioner as required to obtain correct chain tension.

Reinstall capscrew to lock chain tensioner in place.


MAINTENANCE

The following Maintenance Chart indicates regular servicing scheduled to be performed by the owner or the servicing dealer. If these services are performed as suggested, the snowmobile will provide many years of use.

 **NOTE :** Shaded areas in chart indicate recommended frequency.

 **WARNING :** Only perform such procedures as detailed in this manual. It is recommended that dealer assistance be periodically obtained on other components/systems not covered in this manual. Unless otherwise specified, engine should be turn OFF for all lubrication and maintenance procedures.


MAINTENANCE CHART	Weekly or every 240 km (150 mi)	Monthly or every 800 km (500 mi)	Once a year or every 3200 km (2000 mi)	Refer to page
Drive belt condition				28
Brake condition				28
Brake adjustment				29
Spark plugs				30
Suspension condition				30
Suspension stopper strap condition				30
Suspension adjustment	(as required)			30
Track condition				33
Track tension and alignment	(as required)			33
Drive pulley				35
Steering mechanism				35
Ski and runner wear and condition				35
Steering adjustment				34
Muffler attachment				35
Engine head nuts				35
Engine mount nuts				35
Carburetor adjustment				35
Fan belt				36
Headlamp beam aiming				37
General inspection				42

 **NOTE :** The 10-hour inspection is a very important part of proper service and maintenance.

Belt Guard Removal

◆ **WARNING :** Engine should be running only when belt guard is secured in place.

1. Tilt the hood.
2. Pull out both retaining pins.




3. Lift and remove the belt guard assembly.

Drive Belt Removal and Installation


◆ **WARNING :** Never start or run engine without the drive belt installed. Running an unloaded engine is dangerous.

1. Remove the belt guard.


2. Open the driven pulley by twisting and pushing the sliding half. Hold in fully open position.



3. Slip slackened belt over the top edge of the sliding half.




4. Slip the belt out from the drive pulley and remove completely from vehicle.



To install the drive belt, reverse the procedure, however pay attention to the following :

The maximum drive belt life span is obtained when the belt has the proper rotation direction. Install it so the printed information on the belt can be read when facing pulleys.



Drive Belt Condition

Inspect belt for cracks, fraying or abnormal wear (uneven wear, wear on one side, missing cogs, cracked fabric). If abnormal wear is noted, probable cause could be pulley misalignment, excessive RPM with frozen track, fast starts without warm-up period, burred sheave, oil on belt or distorted spare belt. Contact the dealer.

Check the drive belt width. If less than 31.7 mm (1-1/4 in), replace the drive belt.

New Drive Belt

When installing a new drive belt, break in period of 25 km (15 miles) is strongly recommended.


○ **NOTE :** Always store a spare belt in a manner to allow its natural shape to be maintained.

Brake Condition

The brake mechanism on your snowmobile is an essential safety device. Keep this mechanism in proper working condition. Above all, do not operate the snowmobile without an effective brake system.


◆ **WARNING :** Brake pads must be replaced when fixed pad projects only 1 mm (1/32 in) from caliper. Replacement must be performed by an authorized dealer.

▼ **CAUTION :** Do not force or use tools to pry the belt into place, as this could cut or break the cords in the belt.




Brake Adjustment

If a quicker brake response is desired, strongly squeeze the brake lever several times, this will actuate the self adjusting mechanism.



After the adjustment, brake should apply fully when lever is approximately 13 mm (1/2 in) from handlebar grip. If not, do not tamper with the brake, contact the dealer.




WARNING : If the specified free-play is not reached with the tensioner screw fully tightened, consult an authorized dealer.

Spark Plugs

Disconnect the spark plug wires and remove the spark plugs.

Check the condition of the plugs.

- A brownish tip reflects ideal conditions. (Carburetor adjustments, spark plug heat range, etc., are correct).
- A black insulator tip indicates fouling caused by : carburetor idle speed mixture and/or high speed mixture too rich, incorrect oil injection pump adjustment, wrong type of spark plug (heat range), or excessive idling.
- A light grey insulator tip indicates a lean mixture caused by : carburetor high speed mixture adjusted too lean, wrong spark plug heat range, oil injection pump adjustment, or a leaking seal or gasket.



CAUTION : If spark plug condition is not ideal, contact your authorized dealer.

Check spark plug gap using a wire feeler gauge. It should be 0.4 mm (.016 in).

Reinstall spark plugs and connect wires.

Suspension Condition



Visually inspect all suspension components including slider shoes, springs, wheels, etc.

○ **NOTE :** During normal driving, snow will act as a lubricant and coolant for the slider shoes. Extensive riding on ice or sanded snow, will create excessive heat build-up and cause premature slider shoe wear.

Suspension Adjustment

Adjuster blocks

The suspension is adjustable. The front adjustment for surface condition, the rear for driver's weight. Use the special key located in tool box.



When the front adjuster blocks are at the lowest elevation more weight is distributed on the skis.

At the highest position the weight is transferred from the skis to the track. The rear adjuster blocks should be adjusted to suit the driver's preference.

▼ **CAUTION :** Always turn the left side adjuster blocks in a clockwise direction, the right side blocks in a counter-clockwise direction. Left and right adjuster blocks of each adjustment must always be set at the same elevation.


The rear adjuster blocks should be adjusted to suit the driver's preference.

▼ **CAUTION :** Left and right adjuster blocks of each adjustment must always be equally set.

NOTE: For deep snow condition or hill climbing, it is recommended to place the front adjuster blocks at the lowest position.

Additional deep snow and for hill climbing adjustment is possible by relocating the front arm across shaft to the lower hole (B).


DISTANCE A	CONDITIONS
10 mm	Soft snow Low weight
30 mm	Packed snow Heavy load



CAUTION: Left and right cross shaft bolts must always be set at the same elevation.

WARNING: Always torque cross shaft bolts to 69 N•m (52 1 bf•ft).

More adjustment is possible when tightening or loosening the rear arm adjusting screw. Setting of distance A should be as follows:



Track condition


Lift rear of vehicle and support it off the ground. (Place gear shift lever in forward position). With the engine **OFF**, rotate the track manually and inspect condition. If worn or cut, or if track fibers are exposed, or if missing or defective inserts are noted; contact your authorized dealer.

◆ **WARNING:** Do not operate a snowmobile with a cut, torn or damaged track.


Track Tension and Alignment

TENSION:

Lift the rear of vehicle and support with a mechanical stand. Allow the slide to extend normally. Check the gap between the slider shoe and the bottom inside of the track. If the track tension is too loose, the track will have a tendency to thump.




▼ **CAUTION:** Too much tension will result in power loss and excess stresses on suspension components.




Alignment

Start the engine and accelerate slightly so that track barely turns. This must be done in a short period of time (one to two minutes). Check that the track is well centered; equal distance on both sides between edges of track guides and slider shoes.




◆ **WARNING:** Before checking track alignment, ensure that the tracks are free of all particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Ensure no one is standing in close proximity to the vehicle.

To correct, **stop the engine**, loosen the rear idler wheels retaining screws then loosen the lock nuts and tighten the adjuster bolt on side where the slider shoe is the farthest from the track insert guides.



Tighten lock nuts and the idler wheel retaining screws.

Inspect the Duralon bushing condition by checking the free-play of the sliding half pulley. This is achieved by restraining the inner half and checking if the sliding half moves in the direction of the arrows more than 3 mm (1/8 in). If so, contact the dealer.



WARNING: The drive pulley should be inspected by an authorized dealer at least annually.


Both models

Steering Mechanism

Inspect the steering mechanism for tightness of components (steering arms, tie rods, ball joints, spring coupler bolts, etc.). If necessary, replace or retighten.

WARNING: Check the condition of skis, ski runners and leaf springs, replace if weak. Replace ski runners if more than half worn.


Torque steering arm bolt as illustrated below making sure to keep a minimum gap of 4 mm (5/32 in) between lugs.



Steering Adjustment

Skis should have a toe out of 3 mm (1/8 in). To check, measure the distance between each ski at the front and rear of the leaf springs. The front distance should be 3 mm (1/8 in) more than the rear when the handlebar is horizontal.

IMPORTANT: Close the front of the skis manually to eliminate all slack from the steering mechanism using a rubber strap.




The handlebar should also be horizontal when the skis are pointed toward the front.

WARNING: The maximum ball joint external threaded length not engaged in the tie rod end must not exceed 17 mm (43/64 in). Torque lock nut to 20 N·m (15 lbf·ft).


NOTE: Steering adjustment can be carried out by adjusting both tie rods. Adjustment is carried out, with handlebars horizontal, by turning the turn buckle that is on the same side as the misaligned ski.

If adjustment is required:

Loosen the lock nut (s) of the tie rod(s).



WARNING: The ball joint socket must run parallel with the steering arm. The tie rod must be restrained when tightening the tie rod end lock nuts.



Turn the turn buckle(s) manually until ski(s) are properly aligned. Recheck the adjustment, if correct, tighten the lock nut(s).

WARNING: A minimum of 5 threads must be kept in the tie rod ends in the turn buckles.

Muffler Attachment


The engine/exhaust system parts are vital toward efficient muffler function. Check all attachments and muffler ball joint. Replace the springs and/or tighten if necessary.

CAUTION: Do not operate vehicle with muffler disconnected otherwise serious engine damage will occur.

Engine Head Nuts

With the engine cold, check that the engine head nuts are tight and equally torqued to 21 N•m (15 lbf•ft).

Respect tightening sequence as follows :




IMPORTANT: The engine head nut torque should be checked after the first five hours of operation.

Engine Mount Nuts

Check the engine mount nuts for tightness. Torque to 38 N•m (28 lbf•ft) if necessary.

Carburetor Adjustment

▼ **CAUTION:** Never operate your snowmobile with the air intake silencer disconnected. Serious engine damage will occur if this notice is disregarded.



A) Air Screw Adjustment

Completely close the air screw (until a slight seating resistance is felt) then back off screw 1-1/2 turn.

B) Idle Speed Adjustment

Turn the idle speed screw clockwise until it contacts the throttle slide then continue turning two (2) additional turns. This will provide a preliminary idle speed setting. Start engine and allow it to warm then adjust the idle speed to 1800-2000 R.P.M. by turning the idle speed screw clockwise or counter-clockwise.


High Altitude Kit

Snowmobiles used in high altitude areas (1200 m (4000 ft) and up) are subjected to lose power, as temperature, elevation and snow condition are different. The carburetor and power train have to be recalibrated to meet those particular requirements. Ask your authorized dealer for more information on high altitude kit availability.

▼ **CAUTION:** Do not change original jetting if using vehicle below 1200 m (4000 ft).

Fuel filter replacement


Remove fuel line grommet from top of fuel tank and pull out inlet fuel line from tank.



Replace fuel filter. To facilitate the fuel line installation, slide grommet on fuel line about 50 mm (2 in) away from elbow than install grommet on fuel tank and push down elbow through grommet.

Headlamp Beam Aiming


To adjust, remove the four caps, turn upper or lower adjusting screws to obtain desired beam position.



Bulb Replacement

If the headlamp bulb is burnt, tilt hood, unplug the connector from the headlamp. Remove the rubber boot and unfasten bulb retainer clips. Detach the bulb and replace.

▼ **CAUTION :** Never touch glass portion of an halogen bulb with bare fingers, it shortens it's operating life. If by mistake glass is touched clean it with a glass cleaner that will not leave a film on the bulb.



If taillight bulb is burnt, expose the bulb by removing the red plastic lens. To remove, unfasten the two (2) screws.

◆ **WARNING :** Always check light operation after bulb replacement.

General Inspection

Check the electrical wiring and components, retighten loose connections. Check for stripped wires or damaged insulation. Thoroughly inspect the vehicle and tighten loose bolts, nuts and linkage.

◆ **WARNING :** Check condition of skis, ski runners and leaf springs, replace if weak. Replace ski runners if more than half worn.

STORAGE

It is during summer, or when a vehicle is not in use for any length of time that proper storage is a necessity. Storage of the snowmobile during long periods of inactivity consists of checking and replacing missing, broken or worn parts, proper lubrication and treatment to insure that parts do not become rusted; cleaning items such as carburetor, to prevent gum and varnish formation within the carburetor, and in general, preparing the vehicle so that when the time comes to use the snowmobile again it will be in top condition.

◆ **WARNING :** Only perform such procedures as detailed in this manual. It is recommended that dealer assistance be periodically obtained on other components/systems not covered in this manual. Unless otherwise specified, engine should be turned OFF. For all lubrication and maintenance procedures.

Track

Inspect the track for wear, cuts, missing track guides and broken rods. Make any necessary replacement.

◆ **WARNING :** Do not operate a snowmobile with a cut, torn or damaged track.

Lift the rear of vehicle until track is clear of the ground then support with a brace or trestle. The snowmobile should be stored in such a way that the track does not stay in contact with the cement floor or bare ground.

○ **NOTE :** The track should be rotated periodically, (every 40 days). Do not release track tension.

▼ **CAUTION :** To prevent track damage, temperature in the storage area must not exceed 38°C (100°F).

Suspension

Remove any dirt or rust. Lubricate suspension. Wipe off surplus. (Replace worn slider shoes).

Skis and Runners

Wash or brush all dirt or rust accumulation from the skis and springs. Lubricate steering system.

◆ **WARNING :** Check condition of skis, ski runners and leaf springs. Replace if weak. Replace ski runners if more than half worn.

Controls

Inspect all components for tightness, steering arm locking bolts, tie rods, ball joints, etc.). Tighten if necessary. Oil moving joints of the brake mechanism.

◆ **WARNING :** Do not lubricate the throttle and/or brake cables and housings. Avoid getting oil on the brake pads.


Coat all electrical connections and switches with silicone dielectric grease (P/N 413 7017 00). If unavailable, use petroleum jelly.

Transmission

Gearbox

Drain gearbox and refill with 500 mL (18 oz) of fresh Bombardier chaincase oil.

NOTE: Drain plug is accessible a hole located underneath vehicle.



Drive Pulley

Inspection and cleaning must be performed by the dealer at the end of each season.

Engine


Engine internal parts must be lubricated to protect them from possible rust formation during the storage period.

To perform the storage procedures proceed as follows :

1. Lift the rear of the vehicle and support it off the ground.

◆ **WARNING : Ensure the track is free of all particles which could be thrown out while it is rotating. Keep hands, tools, feet and clothing clear of track. Ensure no one is standing in close proximity to the vehicle.**

2. Start the engine and allow it to run at idle speed until the engine reaches its operational temperature.
3. Stop the engine.
4. To prevent gasoline from draining, primer button should be pushed all the way.
5. Disconnect the outlet primer hose from the primer valve.



6. Insert storage oil (P/N 496 0141 00) can hose into primer outlet hose.
7. Restart engine and run at idle.
8. Inject storage oil until the engine dies or until a sufficient quantity of oil has entered the engine (approximately 30 seconds).
9. With the engine stopped, remove the spark plugs and pour approximately 85 mL (3 imp. oz) of Bombardier oil into each cylinder.
10. Crank slowly two or three revolutions to lubricate cylinders.
11. Reinstall the spark plugs and the outlet primer hose.

Do not run engine during storage period.


Fuel Tank and Carburetor

Remove the cap then using a syphon, remove the fuel from tank.

◆ **WARNING : Fuel is flammable and explosive under certain conditions. Always manipulate in a well ventilated area. Do not smoke or allow open flames or sparks in the vicinity.**

Carburetor must be dried out completely to prevent gum formation during the storage period.

Once the fuel tank is emptied, remove the float chamber drain plug from carburetor. Drain carburetor.



Reinstall plug.

Check all fuel lines, replace if necessary.

Chassis

Clean the vehicle thoroughly, removing all dirt and grease accumulation.

▼ **CAUTION :** Plastic alloy components such as fuel tank, windshield, controls, etc., can be cleaned using mild detergents or isopropyl alcohol and a soft clean cloth. Never clean plastic parts with strong detergent, degreasing agent, paint thinner, acetone, etc. Do not apply isopropyl alcohol directly on decals.

Inspect the hood and repair any damage. Clean the frame.

For the unpainted aluminum portion use only "Aluminum cleaner" and follow instructions on the container.

Touch up all metal spots where paint has been scratched off. Spray all metal parts with metal protector. Wax the hood and the painted portion of the frame.

○ **NOTE :** Apply wax on glossy finish only. Protect the vehicle with a cover to prevent dust accumulation during storage.

▼ **CAUTION :** If for some reason the snowmobile has to be stored outside it is necessary to cover it with an opaque tarpaulin. This caution will prevent the sun rays and the grime from affecting the plastic components and the vehicle finish.

General Inspection

Check the electrical wiring and components, retighten loose connections. Check for stripped wires or damaged insulation. Thoroughly inspect the vehicle and tighten loose bolts, nuts and linkage.

○ **NOTE :** Leave the drive belt off the pulleys for the entire storage period.

PRE-SEASON PREPARATION

To simplify the pre-season preparation we have drawn up a small chart. The chart indicates servicing points to be performed by you and your dealer.

IMPORTANT : Observe all Warnings and Cautions mentioned throughout this manual which are pertinent to the item being checked. When component conditions seem less than satisfactory, replace with genuine Bombardier parts or suitable equivalents.

PRE-SEASON PREPARATION CHART	TO BE PERFORMED BY DEALER	●
	TO BE PERFORMED BY THE OWNER	○
Change spark plugs*		○
Check chaincase oil level		○
Replace fuel filter (located inside fuel tank)		○
Check track tension and alignment		○
Lubricate suspension		○
Inspect drive belt and install		○
Check steering alignment and ski runner condition		○
Inspect condition of starting rope		○
Check tightness of all bolts, nuts and linkage		○
Refill fuel tank		○
Check throttle cable for free operation		●
Check electrical wiring		○
Inspect seals for possible cuts or leaks		○
Inspect brake condition and operation		○
Set engine timing		●
Check pulleys, verify components and clean, lubricate driven pulley		●
Adjust carburetor		●
Lubricate brake caliper ratchet wheel		●

○ ***NOTE :** Before installing new spark plugs, it is suggested to burn the excess storage oil by starting the engine, using the old spark plugs.

▼ **CAUTION :** Only perform this procedure in a well ventilated area.

TROUBLESHOOTING

SYMPTOMS	POSSIBLE CAUSES	WHAT TO DO
Engine turns over but fails to start	1. Ignition switch, emergency cut-out switch or tether switch is in the off position	Place all switches in the "run" or "on" position.
	2. Mixture not rich enough to start cold engine	Check fuel tank level and check starting procedure, particularly use of the primer.
	3. Flooded engine. (Spark plug wet when removed)	Do not over prime. Remove wet spark plug, turn ignition to OFF and crank engine several times. Install clean dry spark plug. Start engine following usual starting procedure. If engine continues to flood, see your authorized dealer.
	4. No fuel to the engine. (Spark plug dry when removed)	Check fuel tank level ; turn fuel on if applicable ; check fuel filter ; replace if clogged ; check condition of fuel and impulse lines and their connections. A failure of the fuel pump or carburetor has occurred. Contact your authorized dealer.
	5. Spark plug/ignition (no spark)	Check that emergency cut-out switch is at the upper position (ON) and the tether cut-out switch cap is snapped over the receptacle. Check for fouled or defective spark plug. Disconnect spark plug wire, unscrew plug and remove from cylinder head. Reconnect wire and ground exposed plug on engine cowl, being careful to hold away from spark plug hole . Follow engine starting procedure and check for spark. If no spark appears, replace spark plug. If trouble persists, contact your authorized dealer.


SYMPTOMS	POSSIBLE CAUSES	WHAT TO DO
	6. Engine compression	As the engine is pulled over with the recoil starter, "cycles" of resistance should be felt as each piston goes past top dead center. If no pulsating resistance is felt, it suggests a major loss of compression. Contact your authorized dealer.
Engine lacks acceleration or power	1. Fouled or defective spark plug	Check item 5 of "Engine turns over but fails to start."
	2. Lack of fuel to engine	Check item 4 of "Engine turns over but fails to start."
	3. Carburetor adjustments	Contact your authorized dealer.
	4. Drive belt worn too thin	If the drive belt has lost more than 3 mm (1/8 in) of its original width, it will affect vehicle performance.
	5. Drive and driven pulleys require servicing	Contact your authorized dealer.
	6. Engine is overheating	If applicable, check coolant level ; check pressure cap ; check thermostat. Check for air locks in cooling system. If applicable, check fan belt and its tension ; clean cooling fins of engine ; if heating persists, contact your authorized dealer.

SYMPTOMS	POSSIBLE CAUSES	WHAT TO DO
Engine backfire	1. Faulty spark plug	See item 5 of "Engine turns over but fails to start."
	2. Water in fuel	Drain fuel system and refill with clean fuel.
	3. Engine is running too hot	See item 6 of "Engine lacks acceleration or power."
	4. Ignition timing is incorrect or there is an ignition system failure	Contact your authorized dealer.
Snowmobile cannot reach full speed	1. Drive belt	Check item 4 of "Engine lacks acceleration or power."
	2. Incorrect track adjustment	See maintenance section for proper alignment and tension settings.
	3. Pulleys misaligned	Contact your authorized dealer.
	4. Engine	See items 1, 2, 3 & 6 of "Engine lacks acceleration or power."

TOOLS

As standard equipment each new snowmobile is supplied with basic tools such as screwdriver, wrenches, emergency starting rope, etc.

Standard Tools



SPECIFICATIONS

	NORDIK 50	NORDIK 60
ENGINE		
Type	447	503
No of cylinder	2	2
Bore	67.5 mm (2.657")	72 mm (2.834")
Stroke	61 mm (2.401")	61 mm (2.401")
Displacement	436.6 cm ³ (26.64 in. ³)	496.7 cm ³ (30.31 in. ³)
Compression ratio (corrected)	6.3:1	6.3:1
Maximum hp R.P.M.	7250 R.P.M.	5750 R.P.M.
Carburetor type	VM 32-310	VM 32-259
Carburetor adjustment:		
- air screw	1 ½ turn	1 ½ turn
- idle speed	1800-2000 R.P.M.	1800-2000 R.P.M.
Torque:		
- engine head nuts	23 N·m (17 lbf·ft)	M8: 22 N·m (16 lbf·ft)
- crankcase nuts	M6: 9 N·m (7 lbf·ft) M8: 21 N·m (15 lbf·ft)	M8: 21 N·m (15 lbf·ft)
- magneto ring nut	85 N·m (63 lbf·ft)	85 N·m (63 lbf·ft)
- fan nut	65 N·m (48 lbf·ft)	65 N·m (48 lbf·ft)
- crankcase engine support nuts	38 N·m (28 lbf·ft)	38 N·m (28 lbf·ft)
- exhaust manifold bolts	21 N·m (15 lbf·ft)	21 N·m (15 lbf·ft)
CHASSIS		
Overhall length	294 cm (115.7")	300 cm (118")
Overhall width	99 cm (39")	99 cm (39")
Overhall height	129 cm (50.8")	129 cm (50.8")
Ski stance (center to center)	82 cm (32.3")	82 cm (32.3")
Ski alignment (toe out)	3.0 mm (1/8")	3.0 mm (1/8")
Torque:		
- steering arm/ski leg bolt	60 N·m (45 lbf·ft)	60 N·m (45 lbf·ft)
- steering column/handlebar	26 N·m (19 lbf·ft)	26 N·m (19 lbf·ft)
Dry weight	224 kg (494 lbs)	260 kg (573 lbs)
Bearing area	10268 cm ² (1,592 in ²)	12054.8 cm ² (1,869 in ²)
Ground pressure	2,17 kPa (0.315 lb/in ²)	2,11 kPa (0.306 lb/in ²)
POWER TRAIN		
Track:		
- width	50 cm (19.7")	60 cm (23.6")
- length	370 cm (145.7")	370 cm (145.7")
- tension	30-35 mm (1 3/16"-1 3/8") gap between slider shoe and the bottom inside of track when exerting a downward pull of 5.0 kg (11 lb) to the track.	
- alignment	Equal distance between edges of track guides and slider shoes.	

SPECIFICATIONS

	NORDIK 50	NORDIK 60
Standard gear ratio (second gear)	17/34	17/40
Gearbox chain tension	3 to 6 mm (1/8" to 1/4")	3 to 6 mm (1/8" to 1/4")
Drive belt:		
- number	414 6175 00	414 6175 00
- max. width	34.5 mm (1 3/8")	34.5 mm (1 3/8")
- min. width	31.8 mm (1 1/4")	31.8 mm (1 1/4")
Chaincase/gearbox oil capacity	500 ml (18 oz.)	500 ml (18 oz.)
ELECTRICAL		
Lighting system (output)	160 watts	160 watts
Bulb:		
- headlamp	60/60 W	60/60 W
- tail/stop	5/21 W	5/21 W
- speedometer	5 W	5 W
Spark plug:		
- type	NGK BR9ES	NGK BR8ES
- gap	0.4 mm (.016")	0.4 mm (.016")
Ignition timing:		
- timing mark (B.T.D.C.)	1.88 mm (.074") (18°)	2.29 mm (.090") (20°)
- stroboscopic timing	6000 RPM	6000 RPM
FUEL		
Gas type		Regular leaded or unleaded
Fuel tank capacity		
-SI		30.0 liters
-Imp.		6.6 gallons
-U.S.		8.0 gallons
Premixed fuel/oil		
- type		Blizzard oil
- ratio		50:1
BRAKE		
Type		Disk self-adjusting
Lining minimum thickness		When only 1 mm (1/32") of fixed pad is projected out of caliper.
Control lever adjustment	13 mm (1/2") minimum distance from handlebar grip when fully applied.	

Bombardier Inc. reserves the right to make changes in design and specifications and/or to make additions to, or improvements in its product without imposing any obligation upon itself to install them on its products previously manufactured.

SI* METRIC INFORMATION GUIDE

BASE UNITS			
DESCRIPTION	UNIT	SYMBOL	
length	meter	m	
mass	kilogram	kg	
force	Newton	N	
liquid	liter	L	
temperature	Celsius	°C	
pressure	kilopascal	kPa	
torque	Newton meter	N•m	
speed	kilometer per hour	km/h	
PREFIXES			
PREFIX	SYMBOL	MEANING	VALUE
kilo	k	one thousand	1000
centi	c	one hundredth	0.01
milli	m	one thousandth	0.001
micro	μ	one millionth	0.000001
CONVERSION FACTORS			
TO CONVERT	TO †	MULTIPLY BY	
in	mm	25.4	
in	cm	2.54	
in ²	cm ²	6.45	
in ³	cm ³	16.39	
ft	m	0.3	
oz	g	28.35	
lb	kg	0.45	
lbf	N	4.4	
lbf•in	N•m	0.11	
lbf•ft	N•m	1.36	
lbf•ft	lbf•in	12	
PSI	kPa	6.89	
imp. oz	U.S. oz	0.96	
imp. oz	mL	28.41	
imp. gal	U.S. gal	1.2	
imp. gal	L	4.55	
U.S. oz	mL	29.57	
U.S. gal	L	3.79	
MPH	km/h	1.61	
Fahrenheit	Celsius	(°F - 32) ÷ 1.8	
Celsius	Fahrenheit	(°C × 1.8) + 32	

*The international system of units abbreviates "SI" in all languages.

†To obtain the inverse sequence, divide by the given factor. To convert "mm" to "in", divide by 25.4.

NOTES_____