


1985



OPERATOR'S MANUAL

formula plus
formula mx

414 5307 00

model _____

V.I.N. _____

purchase date _____

warranty expiry date _____

To be completed by dealer at time of sale.

DEALER IMPRINT AREA

AFTER SALES SERVICE
BOMBARDIER INC.
VALCOURT, QUEBEC
CANADA, J0E 2L0



The following are trademarks of Bombardier Inc.


| | | |
|--------------------|-----------|-------------|
| BOMBARDIER | EVEREST | MOTO-SKI |
| SKI-DOO | CITATION | FUTURA |
| ALPINE | OLYMPIQUE | SPIRIT |
| BLIZZARD | T'NT | NUVIK |
| CARRY-BOOSE | NORDIK | MIRAGE |
| ELAN | SKANDIC | SUPER SONIC |
| ELITE | SAFARI | ULTRA SONIC |
| GRAND PRIX SPECIAL | | SONIC |
| | | FORMULA |


FOREWORD


The Operator's Manual and the Snowmobile Safety Handbook have been prepared to acquaint the owner / operator of a new snowmobile with the various vehicle controls, maintenance and safe operating instructions. Each is indispensable for the proper use of the product, and should be kept with the vehicle at all times.

Should you have any questions pertaining to the warranty and its application, please consult the "Often Asked Question" section of this manual, or your selling dealer.


This manual uses the following symbols.

 **WARNING:** Identifies an instruction which, if not followed, could cause personal injury.

 **CAUTION:** Denotes an instruction which, if not followed, could severely damage vehicle components.

 **NOTE:** Indicates supplementary information needed to fully complete an instruction.

Although the mere reading of such information does not eliminate the hazard, your understanding of the information will promote its correct use.

 **WARNING:** The engines and the corresponding components identified in this manual should not be utilized on product(s) other than those mentioned on the cover page of this manual.

Most specifications are given in both metric and customary units. Where precise accuracy is not required, some conversions are rounded to even numbers for easier use.

A shop manual can be obtained for complete service, maintenance and repair information.

SAFETY IN MAINTENANCE

Observe the following precautions:

- Throttle mechanism should be checked for free movement before starting engine.
- The snowmobile engine can be stopped by activating the emergency cut-out or tether switches or turning off the key.
- Clean and check operation of the headlight, tail light and brake light.
- Engine should be running only when belt guard and/or pulley guard is secured in place.
- Never run the engine without drive belt installed. Running an unloaded engine can prove to be dangerous.
- Never run the engine when the track is raised off the ground.
- It can be dangerous to run engine with the hood removed.
- Gasoline is flammable and explosive under certain conditions. Always manipulate in a well ventilated area. Do not smoke or allow open flames or sparks in the vicinity. If gasoline fumes are noticed while driving, the cause should be determined and corrected without delay.
- Maintain your vehicle in top mechanical condition at all times.
- Your snowmobile is not designed to be driven or operated on black top, bare earth, or other abrasive surfaces. On such surfaces abnormal and excessive wear of critical parts is inevitable.
- Your snowmobile is not designed to be operated on public streets, road or highways. In most States and Provinces, it is considered an illegal operation.
- Installation of other than standard equipment, including ski-spreaders, bumpers, pack racks, etc., could severely affect the stability and safety of your vehicle. Avoid adding on accessories that alter the basic vehicle configuration.
- Whenever the vehicle is parked outdoors, overnight or for a long period, it is suggested to protect it against the inclemency of the weather with a snowmobile cover.
- Do not lubricate throttle and/or brake cables and housings.
- Only perform procedures as detailed in this manual. Unless otherwise specified, engine should be turned OFF for all lubrication and maintenance procedures.
- Since engine cooling is fully in effect only when the vehicle is in motion and driven on snow, it is not recommended that you allow the engine to idle for more than brief periods and/or you drive the vehicle on icy surface. Prolonged idling and/or continuous driving on ice may cause engine damage.
- When removing coolant tank cap, first place a cloth over cap then turn cap to its first step to release pressure. Never drain or refill the cooling system when engine is hot.
- These vehicles are designed for the driver only. No provisions have been made for a passenger.
- The performance of this snowmobile may significantly exceed that of other snowmobiles you have operated. Therefore, use of this vehicle by novice or inexperienced operators is not recommended.
- Should removal of a nylon lock nut be required when undergoing repairs/disassembly, always replace by new ones. Tighten as specified in the applicable Shop Manual.

**PLEASE READ AND UNDERSTAND ALL
WARNINGS AND CAUTIONS IN THIS MAN-
UAL AND ON THE VEHICLE.**

**THIS MANUAL SHOULD REMAIN WITH THE VEHICLE AT THE
TIME OF RESALE.**

INDEX

| | | |
|--|----|----|
| THE 1985 "LIMITED WARRANTY" | 4 | |
| OFTEN ASKED QUESTIONS | 6 | |
| LISTING OF AREA DISTRIBUTORS | 8 | |
| HOW TO IDENTIFY YOUR SNOWMOBILE | 9 | |
| CONTROLS/INSTRUMENTS | | |
| Throttle lever, brake lever, ignition/light switch, headlamp dimmer switch, emergency cut-out switch, tether cut-out switch, rewind starter handle, primer, adjustable steering handle, speedometer, tachometer, temperature gauge, injection oil level pilot lamp, high beam pilot lamp, electric fuel gauge, fuel gauge/tank cap, hood opening, tool bag, fuse holder, spare drive belt holder. | 10 | |
| BREAK-IN PERIOD | | |
| Engine and belt break-in, 10 hour-inspection, inspection check list | 13 | |
| FUEL | | |
| Recommended gasoline, recommended oil, oil injection system. | 15 | |
| PRE-START CHECK | | |
| Check points | 16 | |
| STARTING PROCEDURE | | |
| Manual starting, before riding, emergency starting | 16 | |
| LUBRICATION | | |
| Frequency, steering and front suspension, mechanism, drive axle, counter shaft (disk brake and driven pulley), slide suspension, chaincase oil level, rotary valve system, oil injection system | 17 | |
| MAINTENANCE | | |
| Chart, belt guard removal, drive belt removal, drive belt condition, new drive belt, brake condition, brake adjustment, spark plugs, suspension condition, suspension adjustment, track condition, track tension and alignment, drive pulley, drive chain tensioner, steering and front suspension mechanism, steering and ski legs camber adjustment, muffler attachment, engine head nuts, engine mount nuts, carburetors adjustment, oil injection system, fan belt, cooling system, headlamp beam aiming, bulb replacement, general inspection | 23 | |
| STORAGE | | |
| Track, suspension, skis, controls, chaincase, drive pulley, engine and primer lubrication, fuel tank & carburetors, cooling system, chassis, general inspection | 32 | |
| PRE-SEASON PREPARATION | | |
| Pre-season preparation chart | 36 | |
| TROUBLE SHOOTING | | 37 |
| TOOLS | | 39 |
| SPECIFICATIONS | | 40 |
| WIRING DIAGRAM | | 43 |
| SI METRIC INFORMATION GUIDE | | 44 |
| CHANGE OF ADDRESS OR OWNERSHIP | | 45 |

THE 1985 LIMITED WARRANTY _____

1 - PERIOD

BOMBARDIER® INC. as manufacturer, warrants FROM THE DATE OF FIRST CONSUMER SALES, every 1985 BOMBARDIER® snowmobile, sold as NEW AND UNUSED, by an authorized BOMBARDIER dealer for a period of:

- 12 consecutive months.

2 - WHAT BOMBARDIER WILL DO

BOMBARDIER will repair and/or replace, at its option, components defective in material and/or workmanship (under normal use and service,) with a genuine BOMBARDIER component without charge for parts or labour, at any authorized BOMBARDIER dealer during said warranty period.

3 - CONDITION TO HAVE WARRANTY WORK PERFORMED

Present to the servicing dealer, the hard copy of the BOMBARDIER Warranty Registration card received by the customer from the selling dealer at time of purchase.

4 - WARRANTY TRANSFER

This warranty is transferable to subsequent owner(s) for remainder of warranty period from original date of sale.

5 - EXCLUSIONS - ARE NOT WARRANTED

- Normal wear on all items such as, but not limited to:
 - drive belts
 - slider shoes
 - spark plugs
 - bulbs
 - runners on skis
- Replacement parts and/or accessories which are not genuine BOMBARDIER parts and/or accessories.
- Damage resulting from installation of parts other than genuine BOMBARDIER parts.
- Damage caused by failure to provide proper maintenance as detailed in the Operator Manual. The labour, parts and lubricants costs of all maintenance services, including tune-ups and adjustments will be charged to the owner.
- Wet cells battery.
- Vehicles designed and/or used for racing purposes.
- All optional accessories installed on the vehicle.
(The normal warranty policy for parts and accessories, if any, applies).
- Damage resulting from accident, fire or other casualty, misuse, abuse or neglect.
- Damage resulting from operation of the snowmobile on surfaces other than snow.

-
- Damage resulting from modification to the snowmobile not approved in writing by BOMBARDIER.
 - Losses incurred by the snowmobile owner other than parts and labour, such as, but not limited to, transportation, towing, telephone calls, taxis, or any other incidental or consequential damages.

6 - BATTERY WARRANTY:

- 12 consecutive months. (Pro-rated.)

100% warranty coverage will start on the date the snowmobile was purchased and run to the following April 30th. The remainder of the 12 months period will be pro-rated as follows:

 - 50% from April 30th to December 1st.
 - 40% from December 1st to December 31st.
 - 30% from January 1st to end of warranty.

7 - EXPRESSED OR IMPLIED WARRANTIES

This warranty gives you specific rights, and you may also have other legal rights which may vary from state to state, or province to province. Where applicable this warranty is expressly in lieu of all other expressed or implied warranties of BOMBARDIER, its distributors and the selling dealer, including any warranty of merchantability of fitness for any particular purpose; otherwise the implied warranty is limited to the duration of this warranty. However, some states or provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply.

Neither the distributor, the selling dealer, nor any other person has been authorized to make any affirmation, representation or warranty other than those contained in this warranty, and if made, such affirmation, representation or warranty shall not be enforceable against BOMBARDIER or any other person.

Some states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply.

BOMBARDIER INC. reserves the right to modify its warranty policy at any time, being understood that such modification will not alter the warranty conditions applicable to vehicles sold while the above warranty is in effect.

8 - CONSUMER ASSISTANCE

If a servicing problem or other difficulty occurs, we suggest the following:

1. Try to resolve the problem at the dealership with the Service Manager or Owner.
2. If this fails, contact your area distributor listed in the Operator Manual.
3. Then if your grievance still remains unsolved, you may write to us:

Bombardier Inc.
Service Department
Recreational Products Division
Valcourt, Quebec, Canada, JOE 2L0

February 1984
Bombardier Inc.
Valcourt, Quebec, Canada, JOE 2L0

® *Trademarks of Bombardier Inc.

OFTEN ASKED QUESTIONS

Q: Why must my snowmobile be registered? After all I do have my original invoice as proof of when I purchased my snowmobile.

A: Your warranty is valid at any authorized dealer of the product. Your registration is the key element in providing the servicing dealer with the necessary data to complete warranty claim forms. This information is also used to notify owners in the event of a safety recall.

Q: Who should send the registration card to Bombardier Inc..?

A: The dealer. However, the customer must make sure that it has been sent. The company might contact you should your vehicle be recalled or in case of a particular warranty campaign.

Q: I bought my snowmobile in O'King County but I snowmobile in Washington County. Can the dealer in Washington County accept to perform warranty work on my snowmobile?

A: Yes, any authorized dealer in North America can perform warranty repairs, providing the customer warranty registration card is presented.

Q: Where can I find information on the lubrication and maintenance of my snowmobile?

A: In this Operator Manual provided with the vehicle at the time of first sale.

Q: Will the entire warranty be void or cancelled, if I do not operate or maintain my new snowmobile exactly as specified in the Operator's Manual?

A: The warranty of the new snowmobile cannot be "Voided" or "Cancelled". However, if a particular failure is caused by operation or maintenance other than is shown in the Operator Manual, THAT failure may not be covered under warranty. This includes service work performed by the customer, especially the critical adjustments to ignition, timing, carburation and oil injection/or oil mixture.

Q: Would you give some examples of abnormal use or strain, neglect or abuse?

A: These terms are general and overlap each other in areas. Some specific examples may include: running the machine out of oil, chain failure caused by a lack of lubrication, operating the machine with a broken or damaged part which causes another part to fail, and so on. If you have any specific questions on operation or maintenance, please contact your dealer for advice.

Q: What costs are my responsibility during the warranty period?

A: The customer's responsibility includes all costs of normal maintenance services, non-warranty repairs, accidents and collision damage, as well as oils, and spark plugs, and incidental or consequential damages costs as explained in the warranty.

Q: Are "Genuine" Bombardier replacement parts used in warranty repairs covered by warranty?

A: Yes. When installed by an authorized dealer, any "genuine" Bombardier part used in warranty repairs assumes the remaining warranty that exists on the machine.

Q: If I sell my snowmobile within the warranty period, will the new owner qualify for the balance of the warranty?

A: Yes, provided the unit has already been registered with the manufacturer. Note that the change of ownership card in this manual should be completed and sent to Bombardier Inc.

Q: How can I receive the best owner assistance?

A: The satisfaction and goodwill of the owners of Bombardier products are of primary concern to your dealer and Bombardier Inc. Normally, any problems that arise in connection with the sales transaction or the operation of your snowmobile will be handled by your Dealers Sales or Service Departments. It is recognized, however, that despite the best intentions of everyone concerned, misunderstandings will sometimes occur. If you have a problem that has not been handled to your satisfaction through normal channels, we suggest that you discuss your problem with a member of dealership management. Frequently, complaints are the result of a breakdown in communications and can quickly be resolved by a member of the dealership management. If the problem already has been reviewed with the Sales Manager or Service Manager, contact the Dealer himself or the General Manager.

LISTING OF AREA DISTRIBUTORS

CANADIAN DISTRIBUTORS

BOMBARDIER INC. EASTERN CANADA DISTRIBUTION DIVISION

Atlantic Branch
P.O. Box 670
Shediac, New Brunswick, E0A 3G0
(506) 386-6117
Magdalen Island, Nova Scotia, New Brunswick, Prince Edward Island

Quebec Branch
1350 Nobel Boulevard
Boucherville, Quebec, J4B 1A1
(514) 655-6121
Province of Quebec

Ontario Branch
230 Bayview Drive
Barrie, Ontario, L4N 4Y8
(705) 728-8600
Province of Ontario

BROOKS EQUIPMENT LIMITED
1616 King, Edward Street
P.O. Box 985
Winnipeg, Manitoba, R3C 2V8
(204) 633-7247
British Columbia, Manitoba, Saskatchewan, Alberta, Yukon

CHARLES R. BELL LIMITED
Newfoundland, Labrador
Offices
- Riverside Drive
P.O. Box 1050
Corner Brook, Newfoundland, A2H 6J3
(709) 634-3533
- 81 Kenmount Road
P.O. Box 8127
St-John's, Newfoundland, A1B 3N1
(709) 722-6700

HUDSON'S BAY CO. LTD.
165 Hymus Blvd
Pointe-Claire, Quebec, H9R 1G2
(514) 697-8500
North-West Territories, Franklin District & Keewatin

AMERICAN DISTRIBUTORS

BOMBARDIER CORPORATION All States (excluding Alaska)

SERVICE OFFICES
- East Main Street Road
Malone, New York 12953
(518) 483-4411

- 4505 West Superior Street
P.O. Box 6106
Duluth, Minnesota 55806
(218) 628-2881




- P.O. Box 1569
Idaho Falls, Idaho, 83401
(208) 529-9510

NATIONAL SALES OFFICE
- O'Hare Lake Plaza
2350 Devon Avenue
Suite 150
Des Plaines, Illinois 60018
(312) 298-9540

MILLER EQUIPMENT AND RECREATIONAL CENTER
1049 Whitney Road
Anchorage, Alaska 99501
(907) 274-9513
Alaska


HOW TO IDENTIFY YOUR SNOWMOBILE

The main components of your snowmobile (engine, track and frame) are identified by different serial numbers. It may sometimes become necessary to locate these numbers for warranty purposes or to trace your snowmobile in the event of theft.



○ **NOTE:** We strongly recommend that you take note of all the serial numbers on your vehicle and supply them to your insurance company. It will surely help in the event a snowmobile is stolen.

CONTROLS/ INSTRUMENTS



- | | |
|-------------------------------|--|
| A) Throttle lever | J) Speedometer |
| B) Brake lever | K) Tachometer (Formula Plus only) |
| C) Ignition/light switch | L) Temperature gauge |
| D) Headlamp dimmer switch | M) Oil injection pilot lamp |
| E) Emergency cut-out switch | N) High beam pilot lamp |
| F) Tether cut-out switch | O) Fuel gauge/tank cap |
| G) Rewind starter handle | P) Electric fuel gauge (Formula Plus only) |
| H) Primer | Q) Hood opening |
| I) Adjustable steering handle | |


A) Throttle Lever

Located on right side of handlebar. When compressed, it controls the engine speed and the engagement of the transmission. When released, engine speed returns automatically to idle.

B) Brake Lever

Located on the left side of handlebar. When compressed, the brake is applied. When released, it automatically returns to its original position. Braking effect is proportionate to the pressure applied on the lever and to the type of terrain and its snow coverage.

C) Ignition/Light Switch



Key operated, 3 position switch. To start engine, first turn key clockwise to ON position. To stop engine, turn key counter-clockwise to OFF position.


To turn lights on while engine is running, turn key to LIGHT position.

D) Headlamp Dimmer Switch

The dimmer switch, located on left side of handlebar, allows correct selection of headlamp beam. To obtain high or low beam simply flick the switch.

E) Emergency Cut-Out Switch

A push pull type switch located on the right side of the handlebar. To stop the engine in an emergency, push the button to the lower off position and simultaneously apply the brakes. To start engine, button must be at the upper on position.



The driver of this vehicle should familiarize himself with the function of this device by using it several times on first outing. Thereby being mentally prepared for emergency situations requiring its use.

◆ **WARNING:** If the switch has been used in an emergency situation the source of malfunction should be determined and corrected before re-starting engine.

F) Tether Cut-Out Switch

A pull switch located below the handlebar. Attach tether cord to wrist or other convenient location then snap tether cut-out cap over receptacle before starting engine.

If emergency engine "shut off" is required completely pull cap from safety switch and engine power will be automatically shut "off".

○ **NOTE:** The cap must be installed on the safety switch at all times in order to operate the vehicle.

◆ **WARNING:** If the switch is used in an emergency situation the source of malfunction should be determined and corrected before restarting engine.

G) Rewind Starter Handle

Auto rewind type located on right hand side of vehicle. To engage mechanism, pull handle.

H) Primer

A push-pull button located below handlebar. Pull and push button (2-3 times) to activate primer. The primer should always be used for cold engine starts. After engine is warm however, it is not necessary to use primer when starting.

I) Adjustable steering handle

- Remove steering pad.
- Loosen the four (4) retaining screws.
- Adjust the handle to the desired position.

◆ **WARNING:** Do not adjust too high as the brake lever may contact the windshield when turning.

- Lock the steering handle in place by tightening the four (4) retaining screws.
- Reinstall steering pad.


J) Speedometer

The speedometer is linked directly to the drive axle. Direct-reading dial indicates the speed of the vehicle. Odometer records the total distance travelled in kilometers.

K) Tachometer


(Formula Plus only)

The tachometer registers the impulses of magneto. Direct-reading dial indicates the number of revolutions per minute (RPM) of the engine.

 **CAUTION:** The tachometer is protected by a fuse, if tachometer stops operating check fuse condition and if necessary replace. The fuse is 0.1 amp. Do not use a higher rated fuse as this can cause severe damage to the tachometer.


L) Temperature Gauge


The gauge indicates engine coolant temperature. Normal operating temperature is 60°C (140°F). However, coolant temperature can vary depending on driving condition. If coolant temperature exceeds 100°C (210°F) reduce speed and run vehicle in loose snow or stop engine immediately.

 **WARNING:** To remove coolant tank cap, place a cloth over the cap and unscrew it to the first step to release the pressure. If this notice is disregarded loss of fluid and possible severe burns could occur.

M) Oil Injection Level Pilot Lamp

Will light up when injection oil level is low. Check level and replenish as soon as possible.

 **CAUTION:** Do not run engine out of oil. Serious engine damage will occur.


 **NOTE:** Whenever brake lever is compressed, oil injection level pilot lamp should light up. If not replace lamp.

N) High Beam Pilot Lamp

Lights up when headlamp is on high beam.

O) Fuel Gauge/Tank cap

Unscrew fuel tank cap and withdraw dipstick to check fuel level.

 **WARNING:** Never use a lite match or open flame to check fuel level.

P) Electric fuel gauge

The electric fuel gauge is located in the dashboard and allows driver to observe the fuel level while riding the snowmobile.

Q) Hood Opening

Pull down the latch to unhook the hood from the anchor.

○ **NOTE:** Always lift hood gently up until stopped by restraining device.

◆ **WARNING:** It is dangerous to run an engine with the hood open or removed. Personal injury could result.

Tool Bag

To gain access, tilt hood. Ideal location for spare plugs, rope, first aid kit, flashlight, etc.


Fuse Holder

(Formula Plus only)

The tachometer is protected with a 0.1 ampere rated fuse. Fuse holder is located under the hood behind the tachometer. If it stops operating, check fuse condition and replace if necessary with the same rate.

Spare drive belt holder

A spare drive belt can be installed in clips on belt guard.



BREAK-IN PERIOD

Engine

With Bombardier-Rotax snowmobile engines, a break-in period is required before running the vehicle at full throttle. Engine's manufacturer recommendation is 10 to 15 operating hours. During this period, maximum throttle should not exceed $3/4$, however, brief full acceleration and speed variations contribute to a good break-in. Continued wide open throttle accelerations, prolonged cruising speeds, and lugging are detrimental during the break-in period.

▼ **CAUTION:** Remove and clean spark plugs after engine break-in.

Belt

A new drive belt requires a break-in period of 15-25 km (10-15 miles).

10-Hour Inspection

As with any precision piece of mechanical equipment, we suggest that after the first 10 hours of operation or 30 days after the purchase, whichever comes first, your vehicle be checked by your dealer. This inspection will give you the opportunity to discuss the unanswered questions you may have encountered during the first hours of operation. Remember that it is easier to remedy at this time than to allow the snowmobile to operate until a possible failure occurs.

The 10 hour inspection is at the expense of the vehicle owner.

| 10-HOUR INSPECTION CHECK LIST | ✓ |
|--|---|
| Engine head nuts | |
| Engine mount nuts | |
| Engine head nuts | |
| Engine mount nuts | |
| Muffler attachment | |
| Spark plugs condition | |
| Carburetors adjustment | |
| Engine timing | |
| Pulley alignment and drive belt condition | |
| Chaincase oil level | |
| Chain tension | |
| Rotary valve oil level | |
| Injection oil level | |
| Oil injection pump adjustment | |
| Engine coolant level | |
| Brake operation and lining condition | |
| Steering and ski legs camber adjustment (runners condition) | |
| Steering arm, retighten | |
| Handlebar bolts, retighten | |
| Suspension and steering condition and lubrication | |
| Track condition, tension and alignment | |
| Electrical wiring (loose connections, stripped wires, damaged insulation), tighten all loose bolts, nuts and linkage | |
| Operation of lighting system (HI / LO beam, brake light, etc.), test operation of emergency cut-out switch and tether cut-out switch | |


We recommend that you have your dealer sign this inspection .


Date of 10 hour inspection _____

Dealer signature _____

FUEL

Recommended Gasoline

 **CAUTION:** Never experiment with different fuel or fuel ratios. Never use naphtha, methanol or similar products.

 **WARNING:** Never "top up" the gas tank before placing the vehicle in a warm area. At certain temperatures, gasoline will expand and overflow. Always wipe off any gasoline spillage from the snowmobile.

Use **premium gasoline** available from all service stations.

Recommended Oil

Use "Bombardier Snowmobile Injection Oil" (P/N 496 0133 00 - 1 liter) available from your dealer. This type of oil will flow at temperatures as low as minus 40°C (-40°F).


It is a blend of specially selected base oils and additives which provides outstanding lubrication, engine cleanliness and minimum spark plug fouling.


If "Bombardier Snowmobile Injection Oil" is unavailable, substitute with BLIZZARD OIL P/N 496 0135 00.

 **CAUTION:** Never use outboard or straight mineral oils.

Oil Injection System

Always maintain a sufficient amount of Bombardier Snowmobile injection oil in the injection oil tank.

 **CAUTION:** Check level and refill every time you refuel.

 **NOTE:** For the break-in period only, 450 ml (16 oz.) of Bombardier Snowmobile Injection oil should be added to the **first full fuel tank filling**.

This will assure additional protection during the initial engine break-in.

PRE-START CHECK

Check Points

- **ACTIVATE THE THROTTLE CONTROL LEVER SEVERAL TIMES** to check that it operates easily and smoothly. The throttle control lever must return to idle position when released.
- Check that the skis and the track are not frozen to the ground or snow surface and that steering operates freely.
- Activate the brake control lever and make sure the brake fully applies before the brake control lever touches the handlebar grip.
- Check coolant level. Liquid should be 25 mm (1 in.) below filler neck. If additional coolant is necessary or if entire system has to be refilled, use a solution of 11 parts of anti-freeze for 9 parts of water (55% anti-freeze, 45% water). See cooling system in storage.

○ **NOTE:** Always use ethylene-glycol anti-freeze containing corrosion inhibitors specifically recommended for aluminium engines.

◆ **WARNING:** Before removing the radiator pressure cap place a cloth over the cap and unscrew it to the first step to release the pressure. Never drain or refill the cooling system when engine is hot. Loss of fluid and possibility of severe burns could occur, if this notice is disregarded.


- Check injection oil level.
- Check fuel level.
- Verify that the path ahead of the vehicle is clear of bystanders and obstacles.

◆ **WARNING:** Only start your snowmobile once all components are checked and functioning properly.

STARTING PROCEDURE

Test throttle control lever.

Check that the emergency cut-out switch is in the ON position.



Upper position
before starting engine

Ensure the tether cut-out cap is in position and that the cord is attached to your clothing.

Activate the primer (2 or 3 times).

○ **NOTE:** Primer is not necessary when the engine is warm.

Manual Starting

Insert the key in the ignition and turn to ON position.

Grasp manual starter handle firmly and pull slowly until a resistance is felt then pull vigorously. Slowly release the re-wind starter handle.

◆ **WARNING:** Do not apply throttle while starting.

Before riding

Check operation of the emergency cut-out switch, and tether switch. Restart engine.

◆ **WARNING:** If engine does not shut-off when applying the emergency cut-out switch and or when pulling the tether cut-out cap, stop the engine by turning off the ignition key. Do not operate the vehicle further, see your dealer.

Allow the engine to warm before operating at full throttle.


Emergency Starting

Should the rewind starter rope fray and break, the engine can be started with an emergency starter rope.

◆ **WARNING:** Do not start the vehicle by the drive pulley unless it is a true emergency situation, have the vehicle repaired as soon as possible.

Attach emergency rope to starter grip. Remove the belt guard from the vehicle and wind the emergency rope tight around the drive pulley between the sliding half and the roller guard. Start the engine as per usual manual starting.

◆ **WARNING:** When starting the vehicle in an emergency situation by the drive pulley, do not make a knot at the end of the emergency rope and do not reinstall the belt guard.



LUBRICATION

Frequency


Routine maintenance is necessary for all mechanized products, and the snowmobile is no exception. A weekly vehicle inspection contributes to the life span of the snowmobile as well as retains safe and dependable operation. It is recommended that the steering system and suspension be lubricated monthly or every 40 hours of operation. If the vehicle is operated in wet snow or in severe conditions these items should be lubricated more frequently.

Penetrating lubricant is recommended on ball joints and moving parts. May be used either:

- chain lube from Bardahl (BCS 362 dry)
- WD-40

Other grease fittings require low temperature grease using usual grease gun.

The following symbols will be used to show what type of lubricant should be used at the suitable locations.



Chain lube
or
WD-40




Usual grease
gun

○ **NOTE:** When lubricating at grease fittings, grease until grease appears at joints.

◆ **WARNING:** Only perform such procedures as detailed in this manual. It is recommended that dealer assistance be periodically obtained on other components/systems not covered in this manual. Unless otherwise specified, engine should be turned OFF for all lubrication and maintenance procedures.


Drive Axle

Lubricate at grease fitting.



Countershaft (disk brake & driven pulley)


For proper operation, disk and driven pulley must slide freely on countershaft. So lubricate slightly and evenly.



▼ **CAUTION:** Do not lubricate excessively as the lubricant could contact and soil brake pads and/or drive belt.

Chaincase Oil Level

Check the oil level by removing the oil filler cap. Oil level must be within lower and upper mark on dipstick. Refill as required using Bombardier chaincase oil (P/N 413 8019 00 - 200 ml).



○ **NOTE:** The chaincase oil capacity is approximately 256 ml (9 imp. oz.).


Steering and Front Suspension


◆ **WARNING:** Do not lubricate throttle and/or brake cables and housings.

- Lubricate upper and lower control arms and tie rod ends.

- Grease ski legs, ski pivots and idler arm.
- Coat stabilizer sliders with grease and oil their ball joints.

○ **NOTE:** There are 31 places to lubricate.






Slide Suspension

Lubricate rear suspension at grease fittings:


- Front arm: upper and lower axle.
- Front swing arm: upper and lower axle.
- Front shackles.
- Rear arm: upper and lower axle.
- Rear shackle.



○ NOTE: There are 9 grease fittings.


Rotary Valve System

Check reservoir oil level frequently. Maximum level should be as shown in illustration. If necessary replenish using Bombardier Snowmobile Injection Oil available from your dealer.



Oil Injection System

Check reservoir frequently. Replenish as required, using Bombardier Snowmobile Injection Oil, available from your dealer.




MAINTENANCE

The following Maintenance Chart indicates regular servicing schedules to be performed by you or your servicing dealer. If these services are performed as suggested, your snowmobile will give you many years of low-cost use.

WARNING: Only perform such procedures as detailed in this manual. It is recommended that dealer assistance be periodically obtained on other components/systems not covered in this manual. Unless otherwise specified, engine should be turned OFF for all lubrication and maintenance procedures.


| SERVICE AND MAINTENANCE CHART | Weekly or every 240 km (150 m) | Monthly or every 800 km (500 m) | Once a year or every 3200 km (2000 m) | Refer to page |
|---|--------------------------------|---------------------------------|---------------------------------------|---------------|
| Drive belt condition | • | | | 24 |
| Brake condition | • | | | 25 |
| Brake adjustment | | • | | 25 |
| Spark plugs | | • | | 25 |
| Suspension condition | | • | | 26 |
| Suspension adjustment | (as required) | | | 26 |
| Track condition | | • | | 27 |
| Track tension and alignment | | • | | 27 |
| Drive pulley | | • | | 28 |
| Drive chain tension | | • | | 28 |
| Steering and front suspension mechanism | | • | | 29 |
| Steering and ski legs camber adjustment | | • | | 29 |
| Muffler attachment | | • | | 29 |
| Engine head nuts | | | • | 29 |
| Engine mount nuts | | | • | 29 |
| Carburetors adjustment | | | • | 29 |
| Injection oil filter condition | | • | | 30 |
| Oil injection pump adjustment | | | • | 30 |
| Cooling system | | | • | 30 |
| Headlamp beam aiming | | | • | 31 |
| General inspection | | • | | 31 |

 **NOTE:** The ten hour inspection is a very important part of proper service and maintenance.


Belt Guard Removal

◆ **WARNING:** Engine should be running only when belt guard is secured in place.

1. Tilt the hood.
2. Pull out both retaining pins.
3. Lift and remove the belt guard.



Retaining pins




4. Slip the belt out from the drive pulley and remove completely from the vehicle. To install the drive belt, reverse the procedure.


Drive Belt Removal

◆ **WARNING:** Never start or run engine without the drive belt installed. Running an unloaded engine is dangerous.

1. Tilt the hood and remove the belt guard.
2. Open the driven pulley by twisting and pushing the sliding half. Hold in fully open position.



3. Slip the belt over the top edge of the fixed half.



Drive Belt Condition

Inspect belt for cracks, fraying or abnormal wear (uneven wear, wear on one side, missing cogs, cracked fabric). If abnormal wear is noted, probable cause could be pulley misalignment, excessive R.P.M. with frozen track, fast starts without warm-up period, burred sheave, oil on belt or distorted spare belt. Contact your dealer.

Check the drive belt width. Replace it if less than 32 mm (1 1/4").

New Drive Belt



When installing a new drive belt, break-in period of 25 km (15 miles) is strongly recommended.

○ **NOTE:** Always store a spare belt in a manner to allow its natural shape to be maintained.

Brake Condition


The brake mechanism on your snowmobile is an essential safety device. Keep this mechanism in proper working condition. Above all, do not operate your snowmobile without an effective brake system.

◆ **WARNING:** If less than 1 mm ($1/32''$) of the fixed pad is projected out of caliper **OR** there is less than 13 mm ($1/2''$) between lever and handlebar grip, brake pads must be replaced. Replacement must be performed by an authorized dealer.




Brake Adjustment

The brake mechanism is a self-adjusting type. If a quicker brake response is desired, strongly pull the brake lever several times, this will actuate the self adjusting mechanism.



After the adjustment, brake should apply fully when lever is approximately 13 mm ($1/2''$) from handlebar grip. If not, do not tamper with the brake, contact your servicing dealer.




Spark Plugs

Disconnect the spark plug wires and remove the spark plugs.

Check the condition of the plugs.

- A brownish tip reflects ideal conditions. (Carburetor adjustments, spark plug heat range, etc.; are correct).
- A black insulator tip indicates fouling caused by: carburetor idle speed mixture and/or high speed mixture too rich, incorrect fuel mixture ratio, wrong type of spark plug (heat range), or excessive idling.
- A light grey insulator tip indicates a lean mixture caused by: carburetor high speed mixture adjusted too lean, wrong spark plug heat range, incorrect fuel mixture ratio, or a leaking seal or gasket.



CAUTION: If spark plug condition is not ideal, contact your authorized dealer.

Check spark plug gap using a wire feeler gauge.

Reinstall plugs and connect wires.

Suspension Condition

Check all front suspension components for excessive play or wear including ball joints, control arms and links etc.


Visually inspect all rear suspension components including slider shoes, springs, wheels, etc.

NOTE: During normal driving, snow will act as a lubricant and coolant for the slider shoes. Extensive riding on ice or sanded snow will create excessive heat build-up and cause premature slider shoe wear.


Suspension Adjustment

The rear suspension has 2 preload adjustments:

- The front shock spring for surface condition.
- The rear shock spring (twin shocks) for driver's weight.



Each shock absorber has a 5 position cam located at the bottom of the shock. If a stiffer or softer action is desired, the spring preload may be increased or decreased by adjusting the cam.



Front spring

When the front spring cam is at the lowest elevation more weight is distributed on the skis.

At the highest position the weight is transferred from the skis to the track.

NOTE: For deep snow condition or hill climbing it is recommended to place the front spring cam at position 4 or 5. For hard surface riding place it at position 1 - 2 or 3.

Rear Spring

| Driver's Weight kg (lb) | | Cam Position |
|----------------------------|----------|-----------------|
| From | Up to | |
| — | 64 (140) | 1 |
| 64 (140) | 73 (160) | 2 |
| 73 (160) | 82 (180) | 3 |
| 82 (180) | — | 4-5 |

To adjust turn the spring cam accordingly at the same elevation on each shock. An adjustment key is available from your dealer.

Track Condition


Lift the rear of the vehicle and support it off the ground. With the engine off, rotate the track by hand, and inspect condition. If worn or cut, or if track fibers are exposed, or if missing or defective cleats or guides are noted, contact your dealer.

WARNING: Do not operate a snowmobile with a cut, torn or damaged track.

Track Tension and Alignment

Tension:

Lift the rear of vehicle and support with a mechanical stand. Allow the slide to extend normally. The gap should be from 13 mm (1/2") between the slider shoe and the bottom inside of the track.




If the track tension is too loose, the track will have a tendency to thump.

CAUTION: Too much tension will result in power loss and excessive stresses on suspension components.

If necessary to adjust; loosen the rear idler wheel retaining screws and the adjuster screw lock nuts, then loosen or


tighten the adjuster screws located on the inner side of the rear idler wheels. If correct tension is unattainable, contact your dealer.




NOTE: Track tension and alignment are inter-related. Do not adjust one without the other.

Alignment:


Start the engine and accelerate slightly so that track turns **slowly**. Check that the track is well centered; equal distance on both sides between edges of track guides and slider shoes.






WARNING: Before checking track alignment, ensure that the track is free of particles which could be thrown out while it is rotating. Keep hands, tools, feet and clothing clear of track. Ensure no-one is standing in close proximity to the vehicle.

To correct, stop the engine, loosen the rear idler wheels retaining screws then loosen the lock nuts and tighten the adjuster screw on side where the slider shoe is the farthest from the track insert guides.




Tighten lock nuts and recheck the alignment. Ensure to retighten the idler wheel retaining screws.



Drive Pulley


Inspect the Duralon bushing condition by checking the free-play of the sliding half pulley. This is achieved by restraining the inner half and checking if the sliding half moves in the direction of the arrows more than 3 mm (1/8"). If so, contact your dealer.




WARNING: The drive pulley should be inspected by an authorized dealer at least annually.

Drive Chain Tensioner

Run vehicle forward so that true freeplay can be taken. Check free-play then turn driven pulley 1/2 turn forward and recheck. The movement should be within 3-6 mm (1/8 - 1/4).



To adjust remove the hair pin in adjusting screw. Turn the screw clockwise to tighten the chain. Secure hair pin then recheck free-play.



Steering and Front Suspension Mechanism

Inspect steering and front suspension mechanism tightness of components (steering arms, control arms and links, tie rods, ball joints, ski coupler bolts etc.). If necessary replace or retighten.

Check the condition of the skis and the ski runners. Replace if worn more than half.

Steering and Ski Legs Camber Adjustment

There are many adjustments to perform on this vehicle and they should be done only by an authorized dealer.

Muffler attachment


The engine/exhaust system parts are vital toward efficient muffler function. Check all attachments. Replace the springs and/or tighten if necessary.

CAUTION: Do not operate vehicle with muffler disconnected otherwise serious engine damage will occur.


Engine Head Nuts

With the engine cold, check that the engine head nuts are tight and equally torqued to 20 N•m (15 lbf•ft). Follow the illustrated sequence.

467 engine type



537 engine type



IMPORTANT: The engine head nut torque should be checked after the first 5 hours of operation.

Engine Mount Nuts

Check the engine mount nuts for tightness. Retighten if necessary.


Carburetors Adjustment

CAUTION: Never operate your snowmobile with the air intake silencer disconnected. Serious engine damage will occur if this notice is disregarded.

A) Air Screw Adjustment

Completely close the air screw (until a slight reseating resistance is felt) then back off screw:

467 engine type: 1 1/2 turn
537 engine type: 2 turns



B) Idle Speed Adjustment

Turn idle speed screw clockwise until it contacts the throttle slide then continue turning two (2) additional turns. This will provide a preliminary idle speed setting. Start engine and allow it to warm then adjust idle speed to 1800-2000 R.P.M. by turning idle speed screw clockwise or counter-clockwise.

▼ **CAUTION:** Do not attempt to set the idle speed by using the air screw. Severe engine damage can occur. If idle speed is unattainable contact your authorized dealer.

Oil Injection System

Injection Oil Filter Condition

Inspect oil filter at least once a month. Insure that filter is not obstructed by foreign particles; if so, see your dealer.

▼ **CAUTION:** An obstructed injection oil filter will cause oil starvation resulting in serious engine damage.

○ **NOTE:** After a storage period, it is important that your dealer replaces the injection oil filter and that he verifies the oil flow of the injection pump.

Injection Pump Adjustment


Proper oil injection pump adjustment is very important. Any delay in the opening of the pump can result in serious engine damage.

To check adjustment: eliminate the throttle cable free-play by pressing the throttle lever until a light resistance is

felt then hold in place. The aligning marks on the pump casting and lever must align perfectly. If not, contact your dealer.

Injection pump should be adjusted by your dealer.

▼ **CAUTION:** The carburetor must be adjusted before adjusting the oil injection pump. Make sure the idle speed is 1800-2000 RPM.




Cooling System

Check condition of hoses and clamps tightness. Using a hydrometer check that the anti-freeze solution is strong enough for the temperature in which the vehicle is operated.


○ **NOTE:** Should the coolant temperature raise above recommended range 60° - 100°C (140° - 210°F), hose off grime from the heat exchanger (underneath the frame above the track).

Headlamp Beam Aiming


The angle of the headlamp beam has been pre-adjusted prior to delivery. Should you wish re-adjustment, place the vehicle on a flat surface 7.6 m (25') from a wall or screen.



With the suspension correctly adjusted, the rider seated on the vehicle and the high beam ON check that the center of high intensity zone of high beam is 50 mm (2") below horizontal line of headlamp height.




To adjust, remove headlamp ring, turn upper or lower adjusting screws to obtain desired beam position.



Bulb Replacement

If the headlamp bulb is burnt, tilt hood, unplug the connector from the headlamp. Remove the rubber boot and unfasten bulb retainer clips. Detach the bulb and replace.



If taillight bulb is burnt, expose the bulb by removing the red plastic lens. To remove, unfasten the two (2) screws.

WARNING: Always check light operation after bulb replacement.

General Inspection

Check the electrical wiring and components, retighten loose connections. Check for stripped wires or damaged insulation. Thoroughly inspect the vehicle and tighten loose bolts, nuts and linkage. Inspect skis and ski runners for wear.

STORAGE

IMPORTANT: It is during summer, or when a vehicle is not in use for any length of time that proper storage is a necessity. Storage of the snowmobile during long period of inactivity consists of checking and replacing missing, broken or worn parts: Proper lubrication and treatment to insure that parts do not become rusted; cleaning items such as carburetor of oil mixtures, to prevent gum varnish formation within the carburetor; and in general, preparing the vehicle so that when the time comes to use the snowmobile again it will be in top condition.

◆ **WARNING:** Only perform such procedures as detailed in this manual. It is recommended that dealer assistance be periodically obtained on other components/systems not covered in this manual. Unless otherwise specified, engine should be turned OFF for all lubrication and maintenance procedures.

Track

Inspect the track for wear, cuts, missing track guides and broken rods. Make any necessary replacement.

◆ **WARNING:** Do not operate a snowmobile with a cut, torn or damage track.

Lift the rear of vehicle until track is clear of the ground then support with a brace or trestle. The snowmobile should be stored in such a way that the track does not stay in contact with the cement floor or bare ground.

○ **NOTE:** The track should be rotated periodically, (every 40 days). Do not release track tension.

▼ **CAUTION:** To prevent track damage, temperature in the storage area must not exceed 38° C (100° F).

Slide Suspension

Remove any dirt or rust. Grease at all grease fittings. Wipe off surplus. Replace worn slider shoes.

Skis

Wash or brush all dirt or rust accumulation from the skis and springs. Grease at all grease fittings. Check the condition of the skis, and ski runners. Replace if worn more than half.

Controls

Lubricate the steering mechanism. Inspect all components for tightness, (spring coupler bolts, steering arm locking bolts, tie rods, ball joints, etc.). Tighten if necessary. Oil moving joints of the brake mechanism.

◆ **WARNING:** Do not lubricate the throttle and/or brake cables and housings. Avoid getting oil on the brake pads.

Coat all electrical connections and switches with a greaseless metal protector. If unavailable, use petroleum jelly.

Chaincase

Drain the chaincase and refill to proper level, using fresh chaincase oil. To drain, remove the chaincase cover.

Drive Pulley

Inspection and cleaning must be performed by the dealer at the end of each season.

Engine and Primer Lubrication


Engine internal parts must be lubricated to protect them from possible rust formation during the storage period.

To perform the storage procedures (engine and primer valve) proceed as follows:

1. Lift the rear of the vehicle and support it off the ground.

◆ **WARNING:** Ensure the track is free of all particles which could be thrown out while it is rotating. Keep hands, tools, feet and clothing clear of track. Ensure no-one is standing in close proximity to the vehicle.

2. Start the engine and allow it to run at idle speed until the engine reaches its operational temperature.
3. Stop the engine.
4. Disconnect the inlet primer hose from the primer valve.



5. Plug inlet primer hose to prevent gasoline from draining.
6. Using an appropriate hose, connect one end of the hose to the inlet of the primer valve and place the other end in a Bombardier Snowmobile Injection Oil container.
7. Activate the primer in order to fill it with oil.
8. Restart engine and run at idle.
9. Using the primer valve, inject oil until the engine dies or until a sufficient quantity of oil has entered the engine (approximately 25 complete strokes of the primer).
10. The engine stopped, remove the sparks plugs and pour approximately 85 ml (3 Imp. oz.) of oil into the cylinders.
11. Crank the engine to allow the crankshaft to turn 2 or 3 revolutions.


Fuel Tank and Carburetors

Remove the cap then using a syphon, remove the gasoline from tank.

WARNING: Gasoline is flammable and explosive under certain conditions. Always manipulate in a well ventilated area. Do not smoke or allow open flames or sparks in the vicinity.

Carburetors must be dried out completely to prevent gum formation during the storage period.

Once the fuel tank is emptied, remove the float chamber drain plug on each carburetor. Drain carburetor.



Reinstall plugs.

Check all fuel lines, replace if necessary.


Cooling System

The engine cooling system should be drained and refilled with a new coolant mixture before each storage period.

WARNING: Never drain or refill the cooling system when engine is hot.

To drain the cooling system, siphon the coolant mixture from the coolant tank, using a primer pump and a length of plastic hose and steel tubing inserted as deep as possible into the lower hose of the tank.

WARNING: Use PRIMER PUMP to siphon the coolant mixture. Do not siphon with your mouth. The coolant mixture is poison and can be fatal if swallowed.



4.54 liters
160 Imp. ounces
154 U.S. ounces


When the coolant level is low enough, remove the engine bleed screw and lift the rear of vehicle to drain the heat exchangers.

CAUTION: To prevent rust formation in the cooling system, always replenish the system with the recommended solution (55% antifreeze 45% water). Pure antifreeze without water produces premature freezing. Always use ethylene-glycol antifreeze containing corrosion inhibitors specifically recommended for aluminum engines.

To refill the cooling system:


- Put back the rear of vehicle on the ground.

467 engine type



- Refill tank slowly until coolant overfills at bleed hole.
- Reinstall bleed screw.

537 engine type



Continue to pour the coolant in the tank until level reaches 2.5 mm (1") below filler neck. With the coolant tank still removed start the engine and let it warm up to reach its operating temperature and thermostat open. Allow it running a few minutes more. Stop engine and check coolant level, refill as required then put back the cap.

WARNING: Before removing the cap place a cloth over the coolant tank and release the cap to the first step to release the pressure. Loss of fluid and possibility of severe burns could occur, if this notice is disregarded.

Chassis


Clean the vehicle thoroughly, removing all dirt and grease accumulation.

CAUTION: Plastic alloy components such as fuel tank, windshield, controls, etc., can be cleaned using mild detergents or isopropyl alcohol. Do not use strong soaps, degreasing solvents, abrasive cleaners, paint thinners, etc.

Inspect the hood and repair any damage. Repair kits are available at your authorized dealer. Clean the frame. For the aluminum portion use only "Aluminum cleaner" and follow instructions on the container.

Touch up all metal spots where paint has been scratched off. Spray all bare metal parts with metal protector. Wax the hood for better protection.


NOTE: Apply wax on glossy finish of hood only. Protect the vehicle with a cover to prevent dust accumulation during storage.

 **CAUTION:** If for some reason the snowmobile has to be stored outside it is necessary to cover it with an opaque tarpaulin. This caution will prevent the sun rays and the grime from affecting the plastic components and the vehicle finish.

General Inspection

Check the electrical wiring and components, retighten loose connections. Check for stripped wires or damaged insulation.

Thoroughly inspect the vehicle and tighten loose bolts, nuts and linkage.

 **NOTE:** Leave the drive belt **off** the pulleys for the entire storage period.

PRE-SEASON PREPARATION


To simplify the pre-season preparation we have drawn up a small chart. The chart indicates servicing points to be performed by you and your servicing dealer. If these services are performed as suggested, your vehicle will give you many hours of fun and low cost use.

IMPORTANT: Observe all Warnings and Cautions mentioned throughout this manual which are pertinent to the item being checked. When component conditions seem less than satisfactory, replace with genuine Bombardier parts or suitable equivalents.

| PRE-SEASON PREPARATION CHART | TO BE PERFORMED BY DEALER | ● |
|---|---------------------------|---|
| | TO BE PERFORMED BY OWNER | ○ |
| Change spark plugs* | | |
| Check chaincase oil level | | ○ |
| Check drive chain tension | | ○ |
| Check rotary valve oil level | | ○ |
| Replace fuel filter (filter is located inside fuel tank) | | ○ |
| Refill gas tank | | ○ |
| Check track condition, tension and alignment | | ○ |
| Check and lubricate suspension | | ○ |
| Inspect drive belt and install | | ○ |
| Check throttle cable for damage and free operation | | ○ |
| Check steering, ski legs camber adjustments and ski runners condition | | ● |
| Check electrical wiring (broken wire, damaged insulation) | | ○ |
| Inspect condition of starting rope | | ○ |
| Check tightness of all bolts, nuts and links | | ○ |
| Check coolant condition and level | | ● |
| Inspect seals for possible cuts or leaks | | ● |
| Inspect brake condition and operation | | ● |
| Replace injection oil filter | | ● |
| Refill injection oil tank | | ● |
| Adjust oil injection pump | | ● |
| Set engine timing | | ● |
| Check pulleys, verify components and clean. Lubricate. | | ● |
| Adjust carburetors | | ● |

○ ***NOTE:** Before installing new spark plugs, it is suggested to burn excess storage oil by starting the engine, using the old spark plugs. Only perform this operation in a well ventilated area.

TROUBLE SHOOTING

 **NOTE:** The possible causes have been listed in an order of frequency. Therefore, items should be checked out in the same order as mentioned in the trouble shooting guide.


| SYMPTOMS | POSSIBLE CAUSES | WHAT TO DO |
|--|--------------------------------------|--|
| Engine turns over but fails to start or starts with difficulty | 1. No fuel to the engine | Check the tank level and fill it up. Check for possible clogging of fuel line, item 4. |
| | 2. Flooded engine | Remove wet spark plugs, turn ignition to OFF and crank engine several times. Install clean dry spark plugs. Start engine following usual starting procedure. If engine continues to flood, contact your dealer. |
| | 3. Spark plug/ignition | Check for fouled or defective spark plug. Disconnect spark plug wire, unscrew plug and remove from cylinder head. Reconnect wire and ground exposed plug on engine cowl, being careful to hold away from spark plug hole . Follow engine starting procedure and check for spark. If no sparks appear, replace spark plug. If trouble persists, contact your dealer. |
| | 4. Clogged fuel line (water or dirt) | Remove and clean the fuel filter. Change filter cartridge if necessary. Check condition and connections of fuel lines. Check the cleanliness of fuel tank. |
| | 5. Incorrect carburetor adjustment | Contact your dealer. |
| | 6. Too much oil in fuel | Contact your dealer. |
| | 7. Engine timing | Engine timing may be faulty or out of adjustment. Contact your dealer. |
| | 8. Poor engine compression | Running with a lean fuel mixture may produce excessive engine wear resulting in poor engine compression. If this occurs, contact your dealer at once. |
| Engine will not turn manually | 1. Seized engine | In the case of a seized engine contact your dealer. |

| SYMPTOMS | POSSIBLE CAUSES | WHAT TO DO |
|------------------------------------|--------------------------------------|---|
| Engine lacks acceleration or power | 1. Fouled or defective spark plug | Check item 3 of "Engine turns over but fails to start or starts with difficulty" |
| | 2. Clogged fuel line (water or dirt) | Check fuel line condition. (See item 4 of "Engine turns over but fails to start or starts with difficulty"). |
| | 3. Carburetors | Contact your dealer. |
| | 4. Ignition | First check item 2 and 3 of "Engine turns over but fails to start or starts with difficulty". If the ignition system still seems faulty, contact your dealer. |
| | 5. Engine | If unable to locate specific symptoms, contact your dealer. |
| Engine continually backfires | 1. Spark plug | Check item 3 of "Engine turns over but fails to start or starts with difficulty". |
| | 2. Overheated | Coolant level too low. Refill. Carburetor too lean, contact your dealer. |
| | 3. Engine timing incorrectly set | Contact your dealer. |
| Snowmobile cannot reach full speed | 1. Drive Belt | Check for damaged or worn drive belt. Replace if necessary. |
| | 2. Incorrect track adjustment | Check track tension and alignment. Readjust to specifications. (See Maintenance Section). |
| | 3. Engine | Check item 1 to 5 of "Engine lacks acceleration or power." |
| | 4. Pulley misaligned | Contact your dealer. |

TOOLS

As standard equipment each new snowmobile is supplied with a basic tool kit such as screwdriver, wrenches, emergency starter rope, etc...

Standard Tools



A. Screwdriver

B. Socket 10/13 mm

C. Open end wrench 10/13 mm

D. Socket wrench handle

E. Starter rope

F. Socket 21/26 mm

SPECIFICATIONS

| | FORMULA MX | FORMULA PLUS |
|--|--|--|
| ENGINE | | |
| Type | 467 | 537 |
| No. of cylinders | 2 | 2 |
| Bore | 69.5 mm (2.736") | 72.0 mm (2.835") |
| Stroke | 61.0 mm (2.402") | 64.0 mm (2.520") |
| Displacement | 462.8 cm ³ (28.24 in ³) | 521.2 cm ³ (31.81 in ³) |
| Compression ratio (effective) | 6.5:1 | 7.5:1 |
| Maximum R.P.M | 8500 | 9000 |
| Carburetor type | PTO Mikuni VM 34-320 MAG. Mikuni VM 34-321 | PTO Mikuni VM 40-29 MAG. Mikuni VM 40-30 |
| Carburetor adjustment: | | |
| — air screw | 1 1/2 turn | 2 turns |
| — idle screw | 1800-2000 R.P.M. | 1800-2000 R.P.M. |
| Rotary valve oil reservoir | — SI 455 ml — Imp. 16 oz | 455 ml 16 oz |
| Cooling system capacity | — SI 4.2 l — Imp. 148 oz — U.S. 142 oz | 4.2 l 148 oz 142 oz |
| Antifreeze/water mixture (% by volume) | 55/45 | 55/45 |
| Thermostat | 37° C (98° F) | 42° C (108° F) |
| Radiator pressure cap | 13 lb/in ² (90 kPa) | 13 lb/in ² (90 kPa) |
| Torque: | | |
| — engine head nuts | M8: 20 N•m (15 lbf•ft) | |
| — crankcase nuts | M8: 20 N•m (15 lbf•ft) M6: 9 N•m (7 lbf•ft) | |
| — magneto ring nut | M22: 100 N•m (74 lbf•ft) | |
| CHASSIS | | |
| Overall length | 271.8 cm (107") | |
| Overall width | 104.1 cm (41") | |
| Overall height | 91.4 cm (36") | |
| Ski stance (center to center) | 92.1 cm (36.25") | |
| Weight | 198.7 kg (438 lb) | 203.2 kg (448 lb) |
| Bearing area | 5968 cm ² (925 in ²) | 6348 cm ² (984 in ²) |
| Ground pressure | 3.33 kPa (.474 lb/in ²) | 3.20 kPa (.455 lb/in ²) |

| | FORMULA MX | FORMULA PLUS |
|---------------------------------|---|----------------------|
| POWER TRAIN | | |
| Track: | | |
| — width | 38.1 cm (15'') | 41.9 cm (16.5'') |
| — length | 290 cm (114'') | 290 cm (114'') |
| — tension | 13 mm (1/2'') gap between slider shoe and bottom inside of track. | |
| — alignment | Equal distance between edges of track guides and slider shoes. | |
| Standard gear ratio | 26/40 | 26/38 |
| Drive belt | | |
| — number | 414 5233 00 | |
| — MAX. width | 34.9 mm (1 3/8'') | |
| — MIN. width | 31.7 mm (1 1/4'') | |
| Chaincase oil | 256 ml (9 oz) | |
| ELECTRICAL | | |
| Lighting system (output) | 12 V. 160 W | 12 V. 160 W |
| Bulb: | | |
| — headlamp | 60/60 W | 60/55 W halogen |
| — tail/stop | 5/21 W | 5/21 W |
| — speedometer | 5W | 5W |
| — tachometer | N.A. | 5W |
| — temperature gauge | 5W | 5W |
| — fuel gauge | N.A. | 2W |
| Fuse: | | |
| — tachometer | N.A. | 0.1 A |
| Spark plug | | |
| — type | NGK BR8ES | NGK BR8ES |
| — gap | 0.4 mm (0.016'') | 0.4 mm (0.016'') |
| Ignition timing: | | |
| — timing mark (B.T.D.C.) direct | 2.5 mm (.098'') 21° | 1.75 mm (.069'') 17° |
| — stroboscopic timing | 6000 R.P.M. | 6000 R.P.M. |

| FORMULA MX | | FORMULA PLUS |
|-----------------------------|---|-------------------------------------|
| FUEL | | |
| Gas type | | Premium |
| Fuel tank capacity | | |
| | — SI | 40.9 l |
| | — Imp. | 9.0 gal |
| | — U.S. | 10.8 gal |
| Recommended oil | | Bombardier snowmobile injection oil |
| Injection oil tank capacity | — SI | 2.9 l |
| | — Imp. | 102 oz |
| | — U.S. | 98 oz |
| BRAKE | | |
| Type | | Disc, self adjusting |
| Lining minimum thickness | | See "Maintenance" section |
| Control lever adjustment | 13 mm (1/2") minimum distance from handlebar grip when fully applied. | |


Bombardier Inc. reserves the right to make changes in design and specifications and/or to make additions to, or improvements in its product without imposing any obligation upon itself to install them on its products previously manufactured.

N.A.: Not applicable

WIRING DIAGRAM

Formula MX, Formula Plus

- ① LIGHTING COIL
- ② GENERATOR COIL
- ③ IGNITION COIL
- ④ AMPLIFIER
- ⑤ BULB 5-21W
- ⑥ BULB 60-55W
- ⑦ BULB 5W
- ⑧ BULB 2W
- ⑨ LAMP 10 W
- ⑩ FUSE 0.1 A
- ⑪ RESISTOR 30 Ω
- ⑫ TEMPERATURE SENSOR



COLOUR CODE

| | |
|-------------|-------------|
| BK — BLACK | GN — GREEN |
| WH — WHITE | GY — GREY |
| RD — RED | VI — VIOLET |
| BL — BLUE | OR — ORANGE |
| YL — YELLOW | BR — BROWN |

WARNING: Ensure all terminals are properly crimped on the wires and all connector housings are properly fastened.

**SI* METRIC
INFORMATION GUIDE**_____

BASE UNITS

| DESCRIPTION | UNIT | SYMBOL |
|-------------|--------------------|--------|
| length | meter | m |
| mass | kilogram | kg |
| liquid | liter | l |
| temperature | celsius | °C |
| pressure | kilopascal | kPa |
| torque | Newton meter | N•m |
| speed | kilometer per hour | km/h |

PREFIXES

| PREFIX | SYMBOL | MEANING | VALUE |
|--------|--------|---------------------|-------|
| kilo | k | one thousand | 1,000 |
| centi | c | one hundredth of a | 0.01 |
| milli | m | one thousandth of a | 0.001 |

*THE INTERNATIONAL SYSTEM OF UNITS (SYSTEME INTERNATIONAL)
ABREVIATES "SI" IN ALL LANGUAGES.

NOTES_____

NOTES_____

CHANGE OF ADDRESS AND OWNERSHIP

Any change in address or ownership should be brought to the attention of the manufacturer by completing and sending out the card supplied below.

NOTICE TO ALL NEW OWNERS: Make sure to receive the warranty registration card from the previous owner, at the time the ownership is transferred. Also enclose a photocopy of this registration card when informing of a change of ownership.



CHANGE OF ADDRESS

VEHICLE IDENTIFICATION NUMBER

| | | | | | | | | | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|

OLD ADDRESS:

NAME

NO

STREET

APT.

CITY

STATE/PROVINCE

ZIP / POSTAL CODE

NEW ADDRESS:

NAME

NO

STREET

APT.

CITY

STATE/PROVINCE

ZIP / POSTAL CODE



CHANGE OF OWNERSHIP

VEHICLE IDENTIFICATION NUMBER

| | | | | | | | | | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|

The ownership of this vehicle is transferred

FROM:

NAME

NO

STREET

APT.

CITY

STATE/PROVINCE

ZIP / POSTAL CODE

TO:

NAME

NO

STREET

APT.

CITY

STATE/PROVINCE

ZIP / POSTAL CODE



BOMBARDIER INC.

ATT.: WARRANTY DEPARTMENT
VALCOURT, QUEBEC
CANADA, J0E 2L0

BOMBARDIER INC.

ATT.: WARRANTY DEPARTMENT
VALCOURT, QUEBEC
CANADA, J0E 2L0
