



VIEW SHOWING ARRANGEMENT OF CONNECTORS IN ENGINE PORTION OF MULTIPLE CIRCUIT CONNECTOR

Fig. 26 - Schematic - Manual Start Wiring - Model 500 SST