



WIRING SCHEMATIC (COLOR CODED)
ELECTRICAL DISTRIBUTION & CONTROL
1975 SUPER STINGER

SERVICE MANUAL - 1975 SCORPION SUPER STINGER

WIRING CODE (ELECTRICAL DISTRIBUTION & CONTROL)

COLOR	FUNCTION	FROM	TO
BROWN	GROUND		
YELLOW/RED	HOT	ENGINE CONNECTOR	REGULATOR
YELLOW/BLACK	GROUND	ENGINE CONNECTOR	REGULATOR
RED	HOT	VOLTAGE REGULATOR	BRAKE SWITCH CONN. IGNITION SWITCH
TAN	HOT	BRAKE LIGHT SWITCH	BRAKE LIGHT
YELLOW	HOT	IGNITION SWITCH	HI-LO SWITCH TAILLIGHT SPEEDOMETER LIGHT TACHOMETER LIGHT
GREEN	HOT	IGNITION SWITCH	ELECTRIC START
BLUE	HOT (HI)	HI-LO SWITCH	HEADLIGHT
WHITE	HOT (LO)	HI-LO SWITCH	HEADLIGHT
ORANGE	HOT	ENGINE CONNECTOR	TACHOMETER
ORANGE/BLACK	GROUND	ENGINE CONNECTOR	TACHOMETER

RECOMMENDED TOOLS FOR SERVICING:

1. Standard Screwdriver, 1/4" blade
2. Phillip's Screwdriver
3. 7/16" open-end Wrench
4. See Engine Section for removing & installing stator